1990 Porsche 911 - International



Wiring Information

Item	Wire Color	Polarity	Wire Location
Starter	yellow		ignition harness
Ignition	red/blk or black		ignition harness
Accessory	blue		ignition harness
Power Lock	brown/lt blue	-	entry point from door to veh
Power Unlock	brown/green	-	entry point from door to veh
Factory Alarm Arm	arms with lock		
Factory Alarm Disarm	disarms with unlock		
Parking Lights (+)	blk/grn & blk/wht		in fusebox on E conn
Headlight	white/black		headlight switch
Left Front Door Trigger	brown/white	-	door switch in kick panel
Trunk/Hatch Pin	brown		at the bootlight
Hood Pin	red/brown	-	factory alarm
Brake Wire	black/yellow		brake pedal switch

1990 Porsche 911 - International



What Fits

Item Siz	ize	Depth	Location

1990 Porsche 911 - International



Additional Wiring Notes

ltem	Note
Hood Pin	Factory alarm is under the bonnet, blue module.