



Wiring Information

Item	Wire Color	Polarity	Wire Location
12 Volts	Red	+	Ignition Harness
Ground	(chassis ground)		
Starter	Violet	+	Ignition Harness
Ignition	Pink/Red	+	Ignition Harness
Accessory	Pink/Green	+	Ignition Harness
Power Lock	Green		Passenger Kick Panel
Power Unlock	Green		Passenger Kick Panel
Factory Alarm Arm	White	-	At Alarm Module
Factory Alarm Disarm	White	-	At Alarm Module
Parking Lights	Gray and Gray/White	+	At light Switch Harness
Trunk/Hatch Release	Manual release		
Trunk Release Motor	Manual release		
Tachometer	Green/Yellow		At Coil on inner fender
Brake Wire	Black/Red	+	At Switch Above Brake Pedal

1993 MercedesBenz 500SL - Requested by: ampire.de



What Fits

Item	Size	Depth	Location
------	------	-------	----------

***Additional Wiring Notes***

Item	Note
Factory Alarm Arm	Factory alarm located in passenger side foot well under panel.
Factory Alarm Disarm	Factory alarm located in passenger side foot well under panel.
Parking Lights	Left & right parklight wires are independent, isolate them with 2 IN4001 6amp diodes
Power Lock	One wire system requires 2 relays, see doorlock diagram
Power Unlock	One wire system requires 2 relays, see doorlock diagram