

1996 Mercedes Benz 500 SL - International**Wiring Information**

Item	Wire Color	Polarity	Wire Location
Starter	violet		ignition harness
Ignition	pnk/grn or vio/red		ignition harness
Accessory	pink/green		ignition harness
Second Accessory	pink/yellow		ignition harness
Power Lock	green	E	either floor pan or at pump
Power Unlock	same wire		
Parking Lights	blk/grn & blk/wht		under the fusebox
Left Front Door Trigger	brown/grey	-	passenger door switch
Trunk/Hatch Pin	brn/grn or vio/grn		passenger sill loom
Tachometer	green/white		driver side underdash
Brake Wire	black/red		brake pedal switch

1996 Mercedes Benz 500 SL - International



What Fits

Item	Size	Depth	Location
------	------	-------	----------

1996 Mercedes Benz 500 SL - International***Additional Wiring Notes***

Item	Note
Factory Alarm Arm	Factory alarm is located next to the C/L pump or behind the glovebox.
Left Front Window (Up/Down)	Total closure is white wire, pulse at same as the locking.