

# DirectWire

1999 Dodge/Ram Ram Van Diesel - North America - Requested by ampire.de

## Wiring Information

Item	Wire Color	Polarity	Wire Location
12 Volts	Red or Pink/Black	+	At steering Collumn
Starter	Yellow/Blue	+	At steering Collumn
Ignition	Blue	+	At steering Collumn
Accessory	Black/Orange	+	At steering Collumn
Keysense	Lt. Blue	-	Ignition Harness
Power Lock	Orange/Violet	+	Drivers Kick Panel
Power Unlock	Pink/Violet	+	Drivers Kick Panel
Parking Lights	Black/Yellow	+	At Light Switch
Dome Light	Yellow or Black/Blue	-	At door pin switch
Tachometer	Black/Gray	8Cyl.	At Coil
Wait to Start	Orange/Black	-	Behind instrument Cluster
Brake Wire	White/Tan	+	At Brake Switch (Above Brake Pedal)
Parking Brake	White/Black	-	At Park Brake Switch
Horn Trigger	Black/Red	-	At steering Collumn