

# DirectWire

1990 Audi 100 - North America - Requested by [ampire.de](http://ampire.de)

## Wiring Information

Item	Wire Color	Polarity	Wire Location
12 Volts	Red	+	Ignition Harness
Starter	Red/Black	+	Ignition Harness
Ignition	Black	+	Ignition Harness
Accessory	Black/Yellow	+	Ignition Harness
Factory Alarm Arm	Brown/Green	-	Driver's Kick Panel
Factory Alarm Disarm	Brown/White	-	Driver's Kick Panel
Parking Lights	Green/Black & Green/Red	+	At Parking Light Switch Harness
Dome Light	Brown/Blue	-	Driver's Kick Panel
Brake Wire	Red/Black	+	At Brake Switch (Above Brake Pedal)
Horn Trigger	Brown/Yellow	-	At Steering Column

# DirectWire

1990 Audi 100 - North America - Requested by ampire.de



## Additional Wiring Notes

Item	Note
Parking Lights	he left and right circuit are independant, isolate the 2 wires with diodes.