

1991 Toyota Supra - North America			
Item	Wire Color	Polarity	Wire Location
12 Volts	white - white/red	+	ignition harness
Ground	(chassis ground)		
Starter	black/white	+	ignition harness
Ignition	black/yellow	+	ignition harness
Second Ignition	black/orange	+	ignition harness
Accessory	pink/blue	+	ignition harness
Power Lock	green/yellow	-	either kick panel
Power Unlock	blue/black	-	either kick panel
Factory Alarm Arm	brown/yellow	-	either kick panel
Factory Alarm Disarm	violet/yellow	-	either kick panel
Parking Lights	green	+	drivers kick panel
Parking Lights -	pink	-	steering column
Headlight	violet/white and green/red	-	steering column
Left Front Door Trigger	red/white	-	drivers kick panel
Trunk/Hatch Pin	yellow/black	-	drivers kick panel
Hood Pin	tied with trunk		
Tachometer	black	ac	check/diagnostic connector in front of driver strut tower
Brake Wire	green/white	+	drivers kick panel
Horn Trigger	blue/red	-	steering column
Wipers	blue/red (L), red/blue (H)	+	steering column
Left Front Window (Up/Down)	red - green/yellow	A	in drivers door
Right Front Window (Up/Down)	blue/black - blue/yellow	A	in drivers door or driver kick

© 2018 Directed. All rights reserved.

DirectWire and its vehicle information are for the sole use of authorized Directed personnel and it's participating dealers and distributors. The information contained on these pages may contain confidential and privileged information. Any unauthorized review, use, disclosure or distribution is prohibited.