

DirectWire

1991 Pontiac Firebird - North America - Requested by [ampire.de](#)

Wiring Information

Item	Wire Color	Polarity	Wire Location
12 Volts	red	+	ignition harness
Starter	yellow	+	ignition harness
Ignition	pink	+	ignition harness
Accessory	orange	+	ignition harness
R Code	white to white/black	VATS	ignition key cylinder
Reference Ground	white to violet/white	VATS	ignition key cylinder
Power Lock	lt. blue	+	drivers kick panel
Power Unlock	black	+	drivers kick panel
Parking Lights	brown	+	switch or rear harness
Headlight	yellow	+	at switch
Left Front Door Trigger	white	-	underdash light
Trunk/Hatch Pin	black/orange (only if equipped with cargo light)	-	at cargo light
Trunk/Hatch Release	black	+	hatch release relay in convenience center right of steering column
Tachometer	white, violet/white	AC	at coil
Brake Wire	lt. blue or yellow	+	at brake pedal switch
Horn Trigger	black	-	steering column
Wipers	violet	+	left of steering column

Item	Wire Color	Polarity	Wire Location
Left Front Window (Up/Down)	dk. blue - brown	C	at window switch
Right Front Window (Up/Down)	blu/wht - tan	C	at window switch