1990 Chevrolet Van - Requested by: ampire.de





Wiring Information

Item	Wire Color	Polarity	Wire Location
12 Volts	red	+	ignition harness
Ground	(chassis ground)		
Starter	yellow or violet	+	ignition harness
Ignition	pink	+	ignition harness
Accessory	orange	+	ignition harness
Power Lock	It. blue	+	drivers kick panel
Power Unlock	black/white	+	drivers kick panel
Parking Lights	brown		switch or rear harness
Headlight	yellow	+	at switch
Left Front Door Trigger	white	-	pin or courtesy light
Trunk/Hatch Pin	common with doors		
Tachometer	white	AC	coil on top of engine
Brake Wire	white	+	at brake pedal switch
Horn Trigger	black	-	steering column
Wipers	violet		at switch
Left Front Window (Up/Down)	dk. blue - brown	A	in drivers door
Right Front Window (Up/Down)	blu/wht - tan	A	in drivers door

1990 Chevrolet Van - Requested by: ampire.de





http://www.directechs.com

What Fits

Item	Size	Depth	Location
------	------	-------	----------