

1998 Toyota Land Cruiser - North America

**Wiring Information**

Item	Wire Color	Polarity	Wire Location
12 Volts	white/red	+	ignition harness
Second 12 Volts	black/red	+	ignition harness
Starter	black/white	+	ignition harness
Ignition	black/red	+	ignition harness
Second Ignition	blue/black	+	ignition harness
Accessory	black	+	ignition harness
Keysense	red/black	-	ignition switch
IMMO Data	blue/black	data	Immobilizer Module on ignition switch
IMMO Clock	purple/green	data	Immobilizer Module on ignition switch
IMMO Synchro	red/yellow	data	Immobilizer Module on ignition switch
Power Lock	blue/white	-	passenger kick, 20 pin plug
Power Unlock	green/black	-	passenger kick, 20 pin plug
Lock Motor	blue/white	5 wire	fuse box, bottom left, 13 pin plug
Driver Unlock Motor	blue/black	5 wire	fuse box, bottom left, 13 pin plug
Passenger Unlock Motor	blue/black	5 wire	fuse box, bottom right, 18 pin plug
Factory Alarm Arm	arms with lock		
Factory Alarm Disarm	disarms with unlock		
Disarm No Unlock	blue/yellow	-	drivers kick panel
Parking Lights (+)	green	+	fuse box, bottom right, 15 pin plug
Parking Lights (-)	brown/black or green/white	-	fuse box, top middle 20 pin plug
Headlight	red/white	-	steering column
Left Front Door Trigger	green/white	-	fuse box, top left, 13 pin plug
Dome Light	use door trigger		
Trunk/Hatch Pin	green/yellow	-	fuse box, top left, 13 pin plug
Hood Pin	blue/black	-	behind the glove box, right side, gray plug
Tachometer	black	ac	ECM behind the glove box, 28 pin plug
Speed Sense	purple	ac	ECM behind the glove box, 28 pin plug

1998 Toyota Land Cruiser - North America



Item	Wire Color	Polarity	Wire Location
Brake Wire	green/white	+	fuse box, bottom, black plug
Horn Trigger	green/orange	-	fuse box, right side, 14 pin plug
Wipers	blue/black and blue/red	+	wiper switch or motor
Left Front Window (Up/Down)	yellow - green	A	at the drivers door switch
Right Front Window (Up/Down)	black - red/green	A	driver kick, orange plug
Left Rear Window (Up/Down)	red/yellow - green/yellow	A	driver kick, orange plug
Right Rear Window (Up/Down)	red/black - red/black	A	driver kick, orange plug
Sun Roof (Open/Close)	not recommended		
Radio 12V	blue/yellow	+	radio or amplifier
Radio Ground	brown	-	radio or amplifier
Radio Ignition	grey	+	radio or amplifier
Power Antenna	black/red	+	radio
Left Front Speaker (+/-)	pink - purple		amplifier
Right Front Speaker (+/-)	green - blue		amplifier
Left Rear Speaker (+/-)	black - yellow		amplifier
Right Rear Speaker (+/-)	red - white		amplifier

1998 Toyota Land Cruiser - North America



What Fits

Item	Size	Depth	Location
------	------	-------	----------