

## 2012 Subaru Impreza - North America

**Wiring Information**

Item	Wire Color	Polarity	Wire Location
12 Volts	white (common 50A)	+	ignition switch, white 8 pin plug, pin 4
Second 12 Volts	white (common 50A)	+	ignition switch, white 8 pin plug, pin 5
Starter	black/white	+	ignition switch, white 8 pin plug, pin 3
Second Starter	white	+	ignition switch, white 8 pin plug, pin 7
Ignition	green	+	ignition switch, white 8 pin plug, pin 1
Second Ignition	blue	+	ignition switch, white 8 pin plug, pin 6
Accessory	yellow	+	ignition switch, white 8 pin plug, pin 2
Keysense	black/white	+	BIU behind dash fuse box, white 34 pin plug (A), pin 4
CAN Bus High	red	data	BIU behind dash fuse box, white 35 pin plug (B), pin 20
CAN Bus Low	blue	data	BIU behind dash fuse box, white 35 pin plug (B), pin 28
IMMO Data	white/blue	data	BIU behind dash fuse box, white 34 pin plug (A), pin 31
Security Light	brown/red	-	BIU behind dash fuse box, white 31 pin plug (D), pin 26
Door Lock Data	red (keyless data)	data	BIU behind dash fuse box, white 31 pin plug (D), pin 11
Power Lock	lt. green/black	-	driver kick, white 28 pin plug, pin 15
Power Unlock	blue/black	-	driver kick, white 28 pin plug, pin 16
Lock Motor	red/green	5 wire	driver kick, white 28 pin plug, pin 17
Driver Unlock Motor	lt. green	5 wire	driver kick, white 28 pin plug, pin 18
Passenger Unlock Motor	lt. green	5 wire	driver kick, white 24 pin plug, pin 13
Factory Alarm Arm	(arms on lock with driver door open)		
Factory Alarm Disarm	(see disarm no unlock)		
Disarm No Unlock	(transponder and ignition)		

## 2012 Subaru Impreza - North America



Item	Wire Color	Polarity	Wire Location
Parking Lights (+)	black/white	+	dash fuse box, white 20 pin plug, pin 12
Parking Lights (-)	black/blue	-	BIU behind dash fuse box, white 35 pin plug (B), pin 17
Hazards	green	-	BIU behind dash fuse box, white 31 pin plug (D), pin 18
Turn Signal (Left)	white/red	+	dash fuse box, white 20 pin plug, pin 20
Turn Signal (Right)	gray	+	dash fuse box, white 20 pin plug, pin 3
Headlight	blue/black	-	BIU behind dash fuse box, white 35 pin plug (B), pin 34
AutoLights	blue/orange (interrupt to turn off)	-	BIU behind dash fuse box, white 35 pin plug (B), pin 16
Reverse Light	brown/yellow	+	passenger kick, white 20 pin plug, pin 4
Left Front Door Trigger	blue/orange to blue/white	-	driver kick, white 10 pin plug, pin 8
Right Front Door Trigger	blue/orange	-	BIU behind dash fuse box, white 35 pin plug (C), pin 13
Left Rear Door Trigger	yellow/white	-	driver kick, white 10 pin plug, pin 9
Right Rear Door Trigger	white/red	-	BIU behind dash fuse box, white 35 pin plug (C), pin 25
Dome Light	green/yellow	-	BIU behind dash fuse box, white 35 pin plug (C), pin 4
Trunk/Hatch Pin	yellow/blue	-	BIU behind dash fuse box, white 35 pin plug (C), pin 33
Hood Pin	yellow/black (with remote start only)	-	Remote Start Module above brake pedal, white 4 pin plug, pin 4
Trunk/Hatch Release	grn/red (5dr rear handle sw) (4dr use trk rel mtr)	-	BIU behind dash fuse box, white 35 pin plug (C), pin 10
Trunk Release Motor	black/blue	5 wire	BIU behind dash fuse box, white 31 pin plug (D), pin 7
Tachometer	white, black/yellow, black/red, or black/blue	ac	passenger rear of engine, black 54 pin plug, pin 54, 53, 52, or 51

## 2012 Subaru Impreza - North America



Item	Wire Color	Polarity	Wire Location
Neutral Safety	green/black (M/T)	-	ECM behind glove box, white 35 pin plug (C), pin 35
Clutch Pedal	lt. green	+	clutch switch, white 2 pin plug, pin 2
Fuel Pump	red/black	+	passenger kick, white 20 pin plug, pin 5
Rear Defroster	purple/green	- latched	BIU behind dash fuse box, white 34 pin plug (A), pin 26
Mirror Defroster	(mirror same as rear defrost); blue (wiper deicer)	- latched	BIU behind dash fuse box, white 31 pin plug (D), pin 9
Left Front Heated Seat	red/blue (LO); lt. green (HI)	5 wire	seat heater switch, white 8 pin plug, pins 1, 4
Right Front Heated Seat	red/white (LO); white (HI)	5 wire	seat heater switch, white 8 pin plug, pins 3, 8
Speed Sense	pink/green (some models only)	ac	radio, white 20 pin plug, pin 19 or white 28 pin plug, pin 17
Brake Wire	brown	+	dash fuse box, white 20 pin plug, pin 15
Parking Brake	gray	-	driver kick, white 24 pin plug, pin 16
Horn Trigger	red	-	horn switch, white 14 pin plug, pin 9
Wipers	red/blue (LO); black/blue (HI); green/black (ign)	+	wiper switch, white 10 pin plug, pins 3, 4, 2
Left Front Window (Up/Down)	blue/red - blue/green	A	power window main switch, white 16 pin plug, pins 16 - 13
Right Front Window (Up/Down)	red - red/yellow	A	driver kick, white 28 pin plug, pins 5 - 6
Left Rear Window (Up/Down)	green/red - black/yellow	A	driver kick, white 28 pin plug, pins 9 - 10
Right Rear Window (Up/Down)	blue - blue/yellow	A	driver kick, white 28 pin plug, pins 7 - 8
Sun Roof (Open/Close)	blue - red (function with ignition on only)	+	sunroof switch, white 5 pin plug, pins 1 - 4
Radio 12V	blue/red	+	radio, white 20 pin plug, pin 20 or white 10 pin plug, pin 4
Radio Ground	black/blue	-	radio, white 20 pin plug, pin 10 or white 10 pin plug, pin 7
Radio Ignition	yellow/red	+	radio, white 20 pin plug, pin 3 or white 10 pin plug, pin 3

## 2012 Subaru Impreza - North America



Item	Wire Color	Polarity	Wire Location
Radio Illumination	purple (parking lights); black/white (dimmer)	+,-	radio, white 20 pin plug, pins 1, 2
Power Antenna	yellow/black	+	radio, white 20 pin plug, pin 9 or white 10 pin plug, pin 8
Left Front Speaker (+/-)	white/black - blue/orange	+,-	radio, white 20 pin plug, pins 7 - 8 or white 10 pin plug, pins 6 - 2
Right Front Speaker (+/-)	green - brown/yellow	+,-	radio, white 20 pin plug, pins 17 - 18 or white 10 pin plug, pins 5 - 1
Left Rear Speaker (+/-)	red/black - white/red	+,-	radio, white 20 pin plug, pins 5 - 6 or white 6 pin plug, pins 6 - 2
Right Rear Speaker (+/-)	red/white - gray/green	+,-	radio, white 20 pin plug, pins 15 - 16 or white 6 pin plug, pins 3 - 1
Aux. Audio Input Left (+/-)	white - (shield)	+,-	radio, black 8 pin plug, pins 1 - 5
Aux. Audio Input Right (+/-)	black - (shield)	+,-	radio, black 8 pin plug, pins 2 - 5
Satellite Radio 12 Volts	(built into radio)		

## 2012 Subaru Impreza - North America

***What Fits***

Item	Size	Depth	Location
Headunit	double DIN		center of dash
Left Front Speaker	6.3		left front door
Left Front Tweeter	2.56		left front dash
Right Front Speaker	6.3		right front door
Right Front Tweeter	2.56		right front dash
Left Rear Speaker	6.3		left rear door
Right Rear Speaker	6.3		right rear door
Satellite Radio Tuner	(built into radio)		

**2012 Subaru Impreza - North America*****Additional Wiring Notes***

Item	Note
Aux. Audio Input Left (+/-)	On models with handsfree microphone, they are at the radio, white 16 pin plug, pins 3 - 11. On models with navigation, they are at the radio, white 28 pin plug, pins 28 - 27.
Aux. Audio Input Right (+/-)	On models with handsfree microphone, they are at the radio, white 16 pin plug, pins 4 - 11. On models with navigation, they are at the radio, white 28 pin plug, pins 26 - 27.
Radio Illumination	On models with navigation, they are at the radio, white 10 pin plug, pin 10 and white 6 pin plug, pin 5.