

Wiring Information

| Item | Wire Color | Polarity | Wire Location |
|---------------------------|--|------------|--|
| 12 Volts | red/violet (40A) | + | VESCM under driver dash, brown 52 pin plug, pin 42 |
| Starter | red/black | + | Steering Column Module, black 20 pin plug, pin 18 |
| Ignition | black/white | + | Steering Column Module, black 20 pin plug, pin 17 |
| CAN Bus High | orange/red | data | data link connector, black 16 pin plug, pin 6 |
| CAN Bus Low | orange/brown | data | data link connector, black 16 pin plug, pin 14 |
| CAN Bus High 2 | orange/green | data | Steering Column Module, black 20 pin plug, pin 14 |
| CAN Bus Low 2 | orange/brown | data | Steering Column Module, black 20 pin plug, pin 15 |
| IMMO Antenna | blue | RF | Immobilizer Reader Coil on ignition switch, 2 pin plug, pin 1 |
| Power Lock | violet/blue | - resistor | Driver Door Module, gray 32 pin plug, pin 32 |
| Power Unlock | (same as power lock) | - resistor | |
| Lock Motor | brown/blue | 5 wire | Driver Door Module, black 20 pin plug, pin 13 |
| Driver Unlock Motor | gray/green | 5 wire | Driver Door Module, black 20 pin plug, pin 12 |
| Passenger Unlock Motor | gray/green | 5 wire | Passenger Door Module, black 20 pin plug, pin 12 |
| Factory Alarm Arm | blue/white (driver door key lock) | - | Driver Door Module, black 20 pin plug, pin 16 |
| Factory Alarm Disarm | (same as factory alarm arm) | - 250 ohms | |
| Disarm No Unlock | (see factory alarm disarm) | | |
| Parking Lights (+) | gray/black (LF); gray/red (RF); gray/black (LR); gray/black or gray/white (RR) | + | VESCM under driver dash, brown 52 pin plug, pin 26; black 52 pin plug, pins 44, 27; brown 52 pin plug, pin 3 |
| Parking Lights (-) | gray/yellow | - | VESCM under driver dash, black 52 pin plug, pin 19 |
| Hazards | brown/red | - | VESCM under driver dash, brown 52 pin plug, pin 7 |
| Turn Signal (Left) | black/white (F); gray/red (R) | + | VESCM, black 52 pin plug, pin 10; brown 52 pin plug, pin 51 |



| Item | Wire Color | Polarity | Wire Location |
|-----------------------------|---|-----------|--|
| Turn Signal (Right) | black/green (F); gray/red (R) | + | VESCM, brown 52 pin plug, pin 50; black 52 pin plug, pin 9 |
| Headlight | white/black | - | VESCM under driver dash, black 52 pin plug, pin 22 |
| AutoLights | yellow/blue (interrupt to turn off autolights) | - | VESCM under driver dash, black 52 pin plug, pin 20 |
| Reverse Light | black/blue | + | VESCM under driver dash, black 52 pin plug, pin 28 |
| Left Front Door Trigger | gray/violet | - | Driver Door Module, black 20 pin plug, pin 7 |
| Right Front Door Trigger | gray/violet | - | Passenger Door Module, black 20 pin plug, pin 7 |
| Dome Light | blue/gray | - | VESCM under driver dash, brown 52 pin plug, pin 10 |
| Trunk/Hatch Pin | black/red | - | VESCM under driver dash, black 52 pin plug, pin 29 |
| Hood Pin | brown/red | - | VESCM under driver dash, black 52 pin plug, pin 14 |
| Trunk/Hatch Release | brown/violet | - | Driver Door Module, gray 32 pin plug, pin 30 |
| Trunk Release Motor | yellow/red | 5 wire | VESCM under driver dash, yellow 52 pin plug, pin 11 |
| Fuel Door Release | violet/green | - | Driver Door Module, gray 32 pin plug, pin 13 |
| Tachometer | bn/bk, bn/wh, bn/pu, bn/gy, bn/bu, bn/ye, or bn/rd | ac | any fuel injector, 2 pin plug, pin 1 |
| Clutch Pedal | violet/black | - | VESCM under driver dash, brown 52 pin plug, pin 30 |
| Fuel Pump | black/blue or red/blue | + | driver kick, harness to rear |
| Rear Defroster | brown/violet | - latched | VESCM under driver dash, yellow 52 pin plug, pin 22 |
| Mirror Defroster | (CAN bus) | | |
| Left Front Heated Seat | black/green | 5 wire | Climatronic Control Module, black 3 pin plug, pin 1 |
| Right Front Heated Seat | black/yellow | 5 wire | Climatronic Control Module, black 3 pin plug, pin 3 |



| Item | Wire Color | Polarity | Wire Location |
|---------------------------------|--|----------|--|
| Speed Sense | (wheel speed sensor) | | |
| Brake Wire | black/yellow | + | VESCM under driver dash, brown 52 pin plug, pin 17 |
| Parking Brake | brown/yellow | - | VESCM under driver dash, black 52 pin plug, pin 12 |
| Horn Trigger | brown/yellow | - | VESCM under driver dash, yellow 52 pin plug, pin 41 |
| Wipers | (LIN bus) | | |
| Left Front Window (Up/Down) | (use factory alarm arm/disarm) | | |
| Right Front Window (Up/Down) | (see left front window) | | |
| Sun Roof (Open/Close) | blue/white - green/white (conv) (with ign on only) | - | convertible top switch, 4 pin plug, pins 1 - 2 |
| Radio 12V | red/white | + | radio, black 8 pin plug, pins 7, 8 |
| Radio Ground | brown | - | radio, black 8 pin plug, pin 4 |
| Radio Ignition | (CAN bus) | | |
| Radio Illumination | (CAN bus) | | |
| Factory Amp Turn-on | green/yellow | + | radio, black 8 pin plug, pin 5 |
| Left Front Speaker (+/-) | red - brown (preamp) | +,- | radio, green 12 pin plug, pins 11 - 8 |
| Right Front Speaker (+/-) | yellow - brown (preamp) | +,- | radio, green 12 pin plug, pins 9 - 8 |
| Left Rear Speaker (+/-) | green - brown (preamp) | +,- | radio, green 12 pin plug, pins 5 - 8 |
| Right Rear Speaker (+/-) | blue - brown (preamp) | +,- | radio, green 12 pin plug, pins 3 - 8 |
| Center Channel (+/-) | red/gray - brown/gray | +,- | amp in LR qrtr panel, 38 pin plug, pins 22-10 or 32 pin plg, pins 8-20 |
| Subwoofer (+/-) | white/black - brown/black (BOSE) | +,- | amplifier in LR quarter panel, black 32 pin plug, pins 5 - 17 |
| Aux. Audio Input Left (+/-) | yellow - green | +,- | radio, blue 12P plg, pins 3-1; 32P plg, pins 21-22 |
| Aux. Audio Input Right (+/-) | gray - green | +,- | radio, blue 12P plg, pins 7-1; 32P plg, pins 6-22 |
| RSE Audio Left (+/-) | violet - blue or yellow - grn (sat/CD/iPod audio) | +,- | radio, blue 12 pin plug, pins 8 - 2 |
| RSE Audio Right (+/-) | white - blue or gray - green (sat/CD/iPod audio) | +,- | radio, blue 12 pin plug, pins 9 - 2 |



| Item | Wire Color | Polarity | Wire Location |
|-----------------------------|-----------------|----------|---|
| Satellite Radio 12 Volts | red/white | + | sat radio in LR cargo floor, blk 8 pin plug, pin 2 |
| Satellite Radio Ground | brown | - | sat radio in LR cargo floor, blk 8 pin plug, pin 1 |
| Satellite Radio Ignition | (CAN bus) | | |
| Satellite Radio Antenna | (coaxial cable) | | |
| Satellite Audio Left (+/-) | violet - blue | +,- | Satellite Radio, black 8 pin plug, pins 6 - 5 |
| Satellite Audio Right (+/-) | white - blue | +,- | Satellite Radio, black 8 pin plug, pins 7 - 5 |



What Fits

| Item | Size | Depth | Location |
|-----------------------|-----------------------------|-------|--|
| Headunit | irregular | | center of dash |
| Left Front Speaker | 6.5 | 3 | left front door |
| Left Front Tweeter | 1.5 (tweeter); 3 (midrange) | 1; 2 | left front dash; left front door |
| Right Front Speaker | 6.5 | 3 | right front door |
| Right Front Tweeter | 1.5 (tweeter); 3 (midrange) | 1; 2 | right front dash; right front door |
| Left Rear Speaker | 6.5 | 3 | left rear side panel (cpe); rear wall (cnv) |
| Left Rear Tweeter | 1.5 | 1 | left rear side panel |
| Right Rear Speaker | 6.5 | 3 | right rear side panel (cpe); rear wall (cnv) |
| Right Rear Tweeter | 1.5 | 1 | right rear side panel |
| Center Channel | 3 | 2 | top center of dash |
| Subwoofer | | | left rear quarter panel (cpe); ctr rear wall (cnv) |
| Satellite Radio Tuner | | | left rear cargo floor |



Additional Wiring Notes

| Item | Note |
|------------------------------|---|
| Left Front Speaker (+/-) | The low wires are red - brown/red at the amplifier in LR quarter panel, black 38 pin plug, pins 5 - 17 (base) or black 32 pin plug, pins 3 - 15 (BOSE). The mid/high wires are red - brown at the amplifier, black 38 pin plug, pins 5 - 17 (base) or black 32 pin plug, pins 7 - 19 (BOSE). |
| Left Rear Speaker (+/-) | The speaker wires are red/green - brown/green at the amplifier in LR quarter panel, black 38 pin plug, pins 8 - 20 (base) or black 32 pin plug, pins 12 - 11 (BOSE). |
| Right Front Speaker (+/-) | The low wires are red/gray - brown/gray at the amplifier in LR quarter panel, black 38 pin plug, pins 4 - 16 (base) or black 32 pin plug, pins 4 - 16 (BOSE). The mid/high wires are white - brown at the amplifer, black 38 pin plug, pins 4 - 16 (base) or black 32 pin plug, pins 6 - 18 (BOSE). |
| Right Rear Speaker (+/-) | The speaker wires are blue/white - brown/white at the amplifier in LR quarter panel, black 38 pin plug, pins 19 - 7 (base) or black 32 pin plug, pins 14 - 13 (BOSE). |