



## Wiring Information

Item	Wire Color	Polarity	Wire Location
12 Volts	green (60A)	+	dash fuse box, black 3 pin plug (D), pin 1
Second 12 Volts	red (60A)	+	dash fuse box, black 3 pin plug (D), pin 2
Ground	(chassis ground)		
Starter	green	+	driver kick, white 58 pin plug, pin 49
Ignition	pink	+	driver kick, white 58 pin plug, pin 58
Accessory	white	+	driver kick, white 58 pin plug, pin 32
Second Accessory	blue	+	driver kick, white 58 pin plug, pin 26
PTS 1	yellow/black	-	start stop button switch, white 12 pin plug, pin 1
PTS 2	yellow/orange	-	start stop button switch, white 12 pin plug, pin 8
CAN Bus High	white (C-CAN)	data	OBD-Data Link Connector, black 16 pin plug, pin 6
CAN Bus Low	brown (C-CAN)	data	OBD-Data Link Connector, black 16 pin plug, pin 14
CAN Bus High 2	orange (B-CAN)	data	dash fuse box, rear, white 24 pin plug (G), pin 13
CAN Bus Low 2	blue (B-CAN)	data	dash fuse box, rear, white 24 pin plug (G), pin 1
OBD 12 Volts	red (10A)	+	OBD-Data Link Connector, black 16 pin plug, pin 16
OBD Ground	black	-	OBD-Data Link Connector, black 16 pin plug, pin 4
IMMO Data	blue/orange (EMS COM)	data	driver kick, white 58 pin plug, pin 37
Power Lock	pink/black	-	dash fuse box, white 24 pin plug (C), pin 19
Power Unlock	yellow/black	-	dash fuse box, white 24 pin plug (C), pin 20
Lock Motor	gray/black	reverse	dash fuse box, white 39 pin plug (B), pin 30
Driver Unlock Motor	red	reverse	driver kick, white 56 pin plug, pin 19
Passenger Unlock Motor	brown/black	reverse	dash fuse box, white 39 pin plug (B), pin 37



Left Rear Door

Right Rear Door

Trunk/Hatch Pin

Trunk/Hatch Release

Trunk Release Motor

Trigger

Trigger

Dome Light

Hood Pin

**Tachometer** 

gray

orange

yellow

green

green

gray

red/orange

white (rear handle switch)



Item	Wire Color	Polarity	Wire Location
Factory Alarm Arm	yellow/black (see Tech Doc 1300)	-	dash fuse box, white 24 pin plug (C), pin 23
Factory Alarm Disarm	orange (see Tech Doc 1300)	double -	dash fuse box, white 24 pin plug (C), pin 16
Lock Detection	pink (see Tech Doc 1300)	open	dash fuse box, white 24 pin plug (C), pin 6
Unlock Detection	(same as lock detection)	-	
Parking Lights	green/black (LF/LR); brown/black (RF/RR)	+	dash fuse box, white 39 pin plug (B), pin 9 (LF/LR); pin 10 (RF/RR)
Parking Lights -	pink	-	headlight switch, white 16 pin plug, pin 14
Hazards	red	-	dash fuse box, rear, white 24 pin plug (G), pin 14
Turn Signal (Left)	blue/orange (LF); blue/red (LR)	+	dash fuse box, white 34 pin plug (E), pin 25 (LF); white 39 pin plug (B), pin 7 (LR)
Turn Signal (Right)	red (RF); red/black (RR)	+	dash fuse box, white 34 pin plug (E), pin 16 (RF); white 39 pin plug (B), pin 8 (RR)
Headlight	blue	-	headlight switch, white 16 pin plug, pin 15
AutoLights	green	cut	headlight switch, white 16 pin plug, pin 13
Reverse Light	blue	+	dash fuse box, white 39 pin plug (B), pin 22
Left Front Door Trigger	brown	-	dash fuse box, white 24 pin plug (C), pin 7
Right Front Door Trigger	blue	-	dash fuse box, white 24 pin plug (C), pin 11

+

ac

dash fuse box, white 24

dash fuse box, white 24

left front pillar, white 24

dash fuse box, white 24

dash fuse box, white 39 pin plug (B), pin 38

driver kick, white 58 pin

pin plug (C), pin 12

pin plug (C), pin 15

pin plug (C), pin 21 dash fuse box, white 34

pin plug (E), pin 34 dash fuse box, white 24

pin plug (C), pin 5

plug, pin 52

pin plug, pin 5





Item	Wire Color	Polarity	Wire Location
Clutch Pedal	green	-	clutch switch, black 2 pin plug, pin 2
Fuel Pump	pink	+	driver kick, white 24 pin plug, pin 1
Rear Defroster	blue/orange	- latched	dash fuse box, white 34 pin plug (E), pin 12
Mirror Defroster	(same as rear defroster)		
Wiper Deicer	blue/orange	- latched	dash fuse box, white 34 pin plug (E), pin 6
Left Front Heated Seat	brown	+	left seat warmer switch, white 16 pin plug, pin 13
Right Front Heated Seat	brown	+	right seat warmer switch, white 12 pin plug, pin 7
Speed Sense	yellow	4-Pulse	OBD-Data Link Connector, black 16 pin plug, pin 3or radio, white 24 pin plug, pin 16
Brake Wire	white	+	brake switch, white 4 pin plug, pin 1
Parking Brake	orange (without electric parking brake)	-	dash fuse box, white 24 pin plug (C), pin 22
Horn Trigger	white	-	driver kick, white 58 pin plug, pin 17
Wipers	yellow (LO); white (HI); pink (ignition)	+	wiper switch, white 14 pin plug, pin 5 (LO); pin 8 (HI); pin 7 (ignition)
Left Front Window (Up/Down)	yellow - green (without auto up/down only)	А	power window main switch, white 18 pin plug, pins 7 - 8
Right Front Window (Up/Down)	brown - white (without auto up/down only)	A	driver kick, door harness
Left Rear Window (Up/Down)	blue - gray (without auto up/down only)	A	driver kick, door harness
Right Rear Window (Up/Down)	yellow/black - pink (without auto up/down only)	A	driver kick, door harness
Sun Roof (Open/Close)	orange and gray (open) (functions with ignition on only)	both -	sunroof switch, black 6 pin plug, pins 6, 2
Sun Roof (Limit/Close)	green and gray (close) (functions with ignition on only)	both -	sunroof switch, black 6 pin plug, pins 3, 2
Radio 12V	red	+	radio, white 24 pin plug, pin 12
Radio Ground	black	-	radio, white 24 pin plug, pin 24
Radio Ignition	blue	+	radio, white 24 pin plug, pin 11
Radio Illumination	blue (parking lights); gray (dimmer)	+,-	radio, white 18 pin plug, pin 8 (parking lights); pin 17 (dimmer)





http://www.directechs.com

Item	Wire Color	Polarity	Wire Location
Factory Amp Turn-on	(M-CAN)		
Power Antenna	red	+	radio, white 18 pin plug, pin 18
Left Front Speaker (+/-)	orange - green	+,-	radio, white 18 pin plug, pins 2 - 11
Right Front Speaker (+/-)	yellow - black	+,-	radio, white 18 pin plug, pins 3 - 12
Left Rear Speaker (+/-)	red - blue	+,-	radio, white 18 pin plug, pins 1 - 10
Right Rear Speaker (+/-)	brown - white	+,-	radio, white 18 pin plug, pins 4 - 13
Left Front Speaker - With Amp	orange - green	+,-	amplifier under passenger seat, white 12 pin plug, pins 6 - 12
Right Front Speaker - With Amp	yellow - black	+,-	amplifier under passenger seat, white 12 pin plug, pins 5 - 11
Left Front Tweeter - With Amp	orange - green	+,-	amplifier under passenger seat, white 12 pin plug, pins 4 - 10
Right Front Tweeter - With Amp	white - black	+,-	amplifier under passenger seat, white 12 pin plug, pins 3 - 9
Left Rear Speaker - With Amp	red - blue	+,-	amplifier under passenger seat, white 12 pin plug, pins 2 - 8
Right Rear Speaker - With Amp	brown - white	+,-	amplifier under passenger seat, white 12 pin plug, pins 1 - 7
Subwoofer - With Amp	brown - white (coil 1); blue - red (coil 2)	+,-	amplifier under passenger seat, white 26 pin plug, pins 13 - 26 (coil 1); pins 12 - 25 (coil 2)
Aux. Audio Input Left (+/-)	red - black/orange	+,-	radio, white 24 pin plug, pins 21 - 9
Aux. Audio Input Right (+/-)	black - black/orange	+,-	radio, white 24 pin plug, pins 8 - 9
Rearview Camera Video	green - white	+,-	radio, white 24 pin plug, pins 6 - 18 or white 18 pin plug, pins 2 - 3





# What Fits

Item Size Depth Location
--------------------------