



### Wiring Information

| Item                      | Wire Color            | Polarity | Wire Location  |
|---------------------------|-----------------------|----------|--|
| 12 Volts                  | green (40A)           | +        | ignition switch, black 6 pin plug, pin 1                 |
| Second 12 Volts           | red (40A)             | +        | ignition switch, black 6 pin plug, pin 5                 |
| Ground                    | (chassis ground)      |          |  |
| Starter                   | black                 | +        | ignition switch, black 6 pin plug, pin 3                 |
| Ignition                  | pink                  | +        | ignition switch, black 6 pin plug, pin 4                 |
| Accessory                 | white                 | +        | ignition switch, black 6 pin plug, pin 2                 |
| Second Accessory          | blue                  | +        | ignition switch, black 6 pin plug, pin 6                 |
| Keysense                  | yellow                | -        | key switch, white 6 pin plug, pin 4                      |
| CAN Bus High              | white (C-CAN)         | data     | OBD-Data Link<br>Connector, black 16 pin<br>plug, pin 6  |
| CAN Bus Low               | brown (C-CAN)         | data     | OBD-Data Link<br>Connector, black 16 pin<br>plug, pin 14 |
| CAN Bus High 2            | orange (B-CAN)        | data     | dash fuse box, rear, white 24 pin plug (G), pin 13       |
| CAN Bus Low 2             | blue (B-CAN)          | data     | dash fuse box, rear, white 24 pin plug (G), pin 1        |
| OBD 12 Volts              | red (10A)             | +        | OBD-Data Link<br>Connector, black 16 pin<br>plug, pin 16 |
| OBD Ground                | black                 | -        | OBD-Data Link<br>Connector, black 16 pin<br>plug, pin 4  |
| IMMO Data                 | blue/orange (EMS COM) | data     | driver kick, white 58 pin plug, pin 37                   |
| K Line                    | blue/black            | data     | OBD-Data Link<br>Connector, black 16 pin<br>plug, pin 12 |
| Power Lock                | pink/black            | -        | dash fuse box, white 24 pin plug (C), pin 19             |
| Power Unlock              | yellow/black          | -        | dash fuse box, white 24 pin plug (C), pin 20             |
| Lock Motor                | gray/black            | reverse  | dash fuse box, white 39 pin plug (B), pin 30             |
| Driver Unlock Motor       | red                   | reverse  | driver kick, white 56 pin plug, pin 19                   |
| Passenger Unlock<br>Motor | brown/black           | reverse  | dash fuse box, white 39 pin plug (B), pin 37             |





http://www.directechs.com

| Item                        | Wire Color                               | Polarity | Wire Location  |
|-----------------------------|--|----------|--|
| Factory Alarm Arm           | yellow/black (see Tech Doc 1300)         | -        | dash fuse box, white 24 pin plug (C), pin 23   |
| Factory Alarm Disarm        | orange (see Tech Doc 1300)               | double - | dash fuse box, white 24 pin plug (C), pin 16   |
| Lock Detection              | pink (see Tech Doc 1300)                 | open     | dash fuse box, white 24 pin plug (C), pin 6  |
| Unlock Detection            | (same as lock detection)                 | -        |  |
| Parking Lights              | green/black (LF/LR); brown/black (RF/RR) | +        | dash fuse box, white 39 pin plug (B), pin 9 (LF/LR); pin 10 (RF/RR)                  |
| Parking Lights -            | pink                                     | -        | headlight switch, white 16 pin plug, pin 14  |
| Hazards                     | red                                      | -        | dash fuse box, rear, white 24 pin plug (G), pin 14                                   |
| Turn Signal (Left)          | blue/orange (LF); blue/red (LR)          | +        | dash fuse box, white 34 pin plug (E), pin 25 (LF); white 39 pin plug (B), pin 7 (LR) |
| Turn Signal (Right)         | red (RF); red/black (RR)                 | +        | dash fuse box, white 34 pin plug (E), pin 16 (RF); white 39 pin plug (B), pin 8 (RR) |
| Headlight                   | blue                                     | -        | headlight switch, white 16 pin plug, pin 15  |
| AutoLights                  | green                                    | cut      | headlight switch, white 16 pin plug, pin 13  |
| Reverse Light               | blue                                     | +        | dash fuse box, white 39 pin plug (B), pin 22   |
| Left Front Door<br>Trigger  | brown                                    | -        | dash fuse box, white 24 pin plug (C), pin 7  |
| Right Front Door<br>Trigger | blue                                     | -        | dash fuse box, white 24 pin plug (C), pin 11   |
| Left Rear Door<br>Trigger   | gray                                     | -        | dash fuse box, white 24 pin plug (C), pin 12   |
| Right Rear Door<br>Trigger  | orange                                   | -        | dash fuse box, white 24 pin plug (C), pin 15   |
| Dome Light                  | yellow                                   | -        | left front pillar, white 24 pin plug, pin 5  |
| Trunk/Hatch Pin             | green                                    | -        | dash fuse box, white 24 pin plug (C), pin 21   |
| Hood Pin                    | green                                    | -        | dash fuse box, white 34 pin plug (E), pin 34   |
| Trunk/Hatch Release         | white (rear handle switch)               | -        | dash fuse box, white 24 pin plug (C), pin 5  |
| Trunk Release Motor         | red/orange                               | +        | dash fuse box, white 39 pin plug (B), pin 38   |





http://www.directechs.com

| Item                           | Wire Color   | Polarity  | Wire Location   |
|--------------------------------|--|-----------|---|
| Tachometer                     | blue, black, white, or red                               | ac        | fuel injector harness,<br>lower front of engine,<br>black 12 pin plug, pin 1, 3,<br>5, or 7   |
| Clutch Pedal                   | gray/black   | +         | clutch switch, black 2 pin plug, pin 2  |
| Fuel Pump                      | pink   | +         | driver kick, white 24 pin plug, pin 1   |
| Rear Defroster                 | blue/orange  | - latched | dash fuse box, white 34 pin plug (E), pin 12  |
| Mirror Defroster               | (same as rear defroster)                                 |           |   |
| Wiper Deicer                   | blue/orange  | - latched | dash fuse box, white 34 pin plug (E), pin 6   |
| Left Front Heated<br>Seat      | brown  | +         | left seat warmer switch, white 16 pin plug, pin 13  |
| Right Front Heated<br>Seat     | brown  | +         | right seat warmer switch, white 12 pin plug, pin 7  |
| Speed Sense                    | yellow   | 4-Pulse   | OBD-Data Link<br>Connector, black 16 pin<br>plug, pin 3or radio,<br>white 24 pin plug, pin 16 |
| Brake Wire                     | white  | +         | brake switch, white 4 pin plug, pin 1   |
| Parking Brake                  | orange (without electric parking brake)                  | -         | dash fuse box, white 24 pin plug (C), pin 22  |
| Horn Trigger                   | white  | -         | driver kick, white 58 pin plug, pin 17  |
| Wipers                         | yellow (LO); white (HI); pink (ignition)                 | +         | wiper switch, white 14 pin<br>plug, pin 5 (LO); pin 8<br>(HI); pin 7 (ignition)               |
| Left Front Window<br>(Up/Down) | yellow - green (without auto up/down only)               | A         | power window main<br>switch, white 18 pin plug,<br>pins 7 - 8                                 |
| Right Front Window (Up/Down)   | brown - white (without auto up/down only)                | A         | driver kick, door harness   |
| Left Rear Window (Up/Down)     | blue - gray (without auto up/down only)                  | A         | driver kick, door harness   |
| Right Rear Window (Up/Down)    | yellow/black - pink (without auto up/down only)          | А         | driver kick, door harness   |
| Sun Roof<br>(Open/Close)       | orange and gray (open) (functions with ignition on only) | both -    | sunroof switch, black 6<br>pin plug, pins 6, 2  |
| Sun Roof<br>(Limit/Close)      | green and gray (close) (functions with ignition on only) | both -    | sunroof switch, black 6 pin plug, pins 3, 2   |
| Radio 12V                      | red  | +         | radio, white 24 pin plug,<br>pin 12   |
| Radio Ground                   | black  | -         | radio, white 24 pin plug,<br>pin 24   |





http://www.directechs.com

| Item                              | Wire Color                                  | Polarity | Wire Location  |
|-----------------------------------|---|----------|--|
| Radio Ignition                    | blue  | +        | radio, white 24 pin plug, pin 11   |
| Radio Illumination                | blue (parking lights); gray (dimmer)        | +,-      | radio, white 18 pin plug,<br>pin 8 (parking lights); pin<br>17 (dimmer)                                  |
| Factory Amp Turn-on               | (M-CAN)                                     |          |  |
| Power Antenna                     | red   | +        | radio, white 18 pin plug, pin 18   |
| Left Front Speaker (+/-)          | orange - green                              | +,-      | radio, white 18 pin plug, pins 2 - 11  |
| Right Front Speaker (+/-)         | yellow - black                              | +,-      | radio, white 18 pin plug, pins 3 - 12  |
| Left Rear Speaker (+/-)           | red - blue                                  | +,-      | radio, white 18 pin plug, pins 1 - 10  |
| Right Rear Speaker (+/-)          | brown - white                               | +,-      | radio, white 18 pin plug, pins 4 - 13  |
| Left Front Speaker -<br>With Amp  | orange - green                              | +,-      | amplifier under passenger<br>seat, white 12 pin plug,<br>pins 6 - 12                                     |
| Right Front Speaker -<br>With Amp | yellow - black                              | +,-      | amplifier under passenger<br>seat, white 12 pin plug,<br>pins 5 - 11                                     |
| Left Front Tweeter -<br>With Amp  | orange - green                              | +,-      | amplifier under passenger<br>seat, white 12 pin plug,<br>pins 4 - 10                                     |
| Right Front Tweeter -<br>With Amp | white - black                               | +,-      | amplifier under passenger<br>seat, white 12 pin plug,<br>pins 3 - 9                                      |
| Left Rear Speaker -<br>With Amp   | red - blue                                  | +,-      | amplifier under passenger<br>seat, white 12 pin plug,<br>pins 2 - 8                                      |
| Right Rear Speaker -<br>With Amp  | brown - white                               | +,-      | amplifier under passenger<br>seat, white 12 pin plug,<br>pins 1 - 7                                      |
| Subwoofer - With<br>Amp           | brown - white (coil 1); blue - red (coil 2) | +,-      | amplifier under passenger<br>seat, white 26 pin plug,<br>pins 13 - 26 (coil 1); pins<br>12 - 25 (coil 2) |
| Aux. Audio Input Left (+/-)       | red - black/orange                          | +,-      | radio, white 24 pin plug, pins 21 - 9  |
| Aux. Audio Input<br>Right (+/-)   | black - black/orange                        | +,-      | radio, white 24 pin plug, pins 8 - 9   |
| Rearview Camera<br>Video          | green - white                               | +,-      | radio, white 24 pin plug,<br>pins 6 - 18 or white 18 pin<br>plug, pins 2 - 3                             |





### What Fits

| Item Size Depth Location |
|--------------------------|
|--------------------------|