



<http://www.directechs.com>

Wiring Information

Item	Wire Color	Polarity	Wire Location
12 Volts	red	+	ignition harness
Ground	(chassis ground)		
Starter	yellow	+	ignition harness
Ignition	pink	+	ignition harness
Second Ignition	blue/white	+	ignition harness
Accessory	orange	+	ignition harness
Second Accessory	violet/white	+	ignition harness
Power Lock	lt. blue	+	either kick
Power Unlock	black	+	either kick
Factory Alarm Arm	arms with lock		
Factory Alarm Disarm	lt. green	-	either kick or alarm
Parking Lights	brown or violet		light switch
Headlight	yellow	+	light switch
Left Front Door Trigger	white	-	at door jamb
Trunk/Hatch Release	black or black/org	+	release switch
Tachometer	violet/white	AC	ignition module
Brake Wire	lt. blue	+	brake switch
Horn Trigger	black	-	steering column
Wipers	violet, gray	+	wiper switch
Left Front Window (Up/Down)	blu - brown	A	switch in console
Right Front Window (Up/Down)	dk. blue - tan	A	switch in console

1988 Buick Reatta - Requested by: empire.de



<http://www.directechs.com>

What Fits

Item	Size	Depth	Location
------	------	-------	----------



<http://www.directechs.com>

Additional Wiring Notes

Item	Note
Left Front Door Trigger	Not interior illumination. Use lt. blue if equipped with factory alarm.
Factory Alarm Disarm	The factory alarm is located to the left of the steering column.
Tachometer	Located between engine and firewall on passenger side. Follow spark plug wires. 14 pin plug.