



<http://www.directechs.com>

### ***Wiring Information***

<b>Item</b>	<b>Wire Color</b>	<b>Polarity</b>	<b>Wire Location</b>
Starter	WHITE-RED		AT IGNITION SWITCH
Ignition	AT BARREL		FOR IMMOBILISATION USE IGNITION SWITCH WIRING
Second Ignition	WHITE-GREEN	SENSE	IN 26 WAY GREY CONNECTOR AT GREEN CONTROL UNIT BEHIND SPEAKER HOUSING
Power Lock	YELLOW-PINK	SINGLE	SINGLE WIRE 'MAKE AND BREAK' IN GREY 26 WAY CONNECTOR AT GREEN UNIT
Turn Signal (Left)	GREEN-WHITE		PIN 1 IN GREEN 12 WAY AT CONTROL UNIT BEHIND SPEAKER HOUSING
Turn Signal (Right)	GREEN-RED		PIN 6 IN GREEN 12 WAY AT CONTROL UNIT BEHIND SPEAKER HOUSING
Left Front Door Trigger	GREY-WHITE		AT GREY 26 WAY IN GREEN CONTROL UNIT
Right Front Door Trigger	VIOLET-BLUE		AT GREY 26 WAY IN GREEN CONTROL UNIT
Left Rear Door Trigger	REARS COVERED BY RH DOOR		
Trunk/Hatch Pin	FIT NEW		
Hood Pin	ORANGE-BLUE		AT GREY 26 WAY IN GREEN CONTROL UNIT



<http://www.directechs.com>

***What Fits***

Item	Size	Depth	Location
------	------	-------	----------