



http://www.directechs.com

Wiring Information

Item	Wire Color	Polarity	Wire Location
12 Volts	White (40A)	+	BCM in passenger kick, white 15 pin plug, pin 11
Ground	(chassis ground)		
Starter	Red (non-hybrid); Lt. Blue (hybrid)	-	BCM in passenger kick, black 40 pin plug, pin 22
Ignition	White/Black	+	BCM in passenger kick, black 40 pin plug, pin 27
Second Ignition	Black	-	BCM in passenger kick, black 40 pin plug, pin 30
Accessory	Black	+	BCM in passenger kick, black 40 pin plug, pin 26
Second Accessory	Lt. Blue	+	BCM in passenger kick, black 24 pin plug, pin 9
PTS 1	Red	-	BCM in passenger kick, green 40 pin plug, pin 1
CAN Bus High	Blue	Data	BCM in passenger kick, black 40 pin plug, pin 20
CAN Bus Low	N Bus Low Pink		BCM in passenger kick, black 40 pin plug, pin 19
CAN Bus High 2	Blue (DIAG CAN)	Data	OBD-Data Link Connector, white 16 pin plug, pin 6
CAN Bus Low 2	Lt. Green (DIAG CAN)	Data	OBD-Data Link Connector, white 16 pin plug, pin 14
OBD 12 Volts	BD 12 Volts White (5A)		OBD-Data Link Connector, white 16 pin plug, pin 16
OBD Ground	Black	-	OBD-Data Link Connector, white 16 pin plug, pin 4
OBD Ignition	White	+	OBD-Data Link Connector, white 16 pin plug, pin 8
IMMO Antenna	(NATS Antenna is on the push button ignition switch)		
Security Light	Blue	-	BCM in passenger kick, green 40 pin plug, pin 18
Power Lock	(use factory alarm arm)		
Power Unlock	(use factory alarm disarm)		
Lock Motor	Violet	Reverse	BCM in passenger kick, white 15 pin plug, pin 7
Driver Unlock Motor	Lt. Green	Reverse	BCM in passenger kick, white 15 pin plug, pin 9
Passenger Unlock Motor	Pink	Reverse	BCM in passenger kick, white 15 pin plug, pin 2





http://www.directechs.com

Item	Wire Color	Polarity	Wire Location
Factory Alarm Arm	Violet (key lock)	-	Power Window Main Switch, white 16 pin plug, pin 15
Factory Alarm Disarm	Yellow (key unlock)	Double -	Power Window Main Switch, white 16 pin plug, pin 16
Disarm No Unlock	(proximity Key and push button)		
Parking Lights	Red	+	Dash Fuse Box, white 40 pin plug, pin 16
Hazards	Green	-	BCM in passenger kick, green 40 pin plug, pin 36
Turn Signal (Left)			BCM in passenger kick, black 24 pin plug, pin 13 (LF); gray 24 pin plug, pin 23 (LR)
Furn Signal (Right) Violet (RF); White (RR)		+	BCM in passenger kick, black 24 pin plug, pin 1 (RF); gray 24 pin plug, pin 12 (RR)
Headlight	Violet (LO L); Red (LO R); Pink (HI L); Brown (HI R) (non-hybrid)	+	Underhood Fuse Box, white 8 pin plug, pin 3 (LO L); pin 2 (LO R); pin 8 (HI L); pin 7 (HI R)
Headlight 2	L); Tan (HI R) (hybrid)		Underhood Fuse Box, white 8 pin plug, pin 3 (LO L); pin 2 (LO R); pin 8 (HI L); pin 7 (HI R)
Reverse Light	Tan	+	Passenger Kick, harness to rear
Left Front Door Trigger	Violet	-	BCM in passenger kick, gray 24 pin plug, pin 16
Right Front Door Trigger	gger		BCM in passenger kick, gray 24 pin plug, pin 14
Left Rear Door Trigger	White	-	BCM in passenger kick, gray 24 pin plug, pin 2
Right Rear Door Trigger	ht Rear Door Green gger		BCM in passenger kick, gray 24 pin plug, pin 13
Dome Light	Violet	-	BCM in passenger kick, white 15 pin plug, pin 8
Trunk/Hatch Pin	Red	-	BCM in passenger kick, gray 24 pin plug, pin 17
Hood Pin	Pink	-	Underhood Fuse Box, white 16 pin plug, pin 15
Trunk/Hatch Release	Blue	-	BCM in passenger kick, black 40 pin plug, pin 40
Trunk Release Motor	runk Release Motor Gray		BCM in passenger kick, gray 24 pin plug, pin 11
Fuel Door Release	(locks/unlocks along with driver door)		





http://www.directechs.com

Item	Wire Color	Polarity	Wire Location
Tachometer	White AC		Passenger Kick, harness to rear
Fuel Pump	Brown	+	Above Driver Kick, white 6 pin plug, pin 2
Rear Defroster	Green	- Latched	BCM in passenger kick, black 40 pin plug, pin 21
Mirror Defroster	(same as rear defroster)		
Left Front Heated Seat	(CAN Bus)		
Right Front Heated Seat	(CAN Bus)		
Speed Sense	Red 8-Pulse		Display Control Unit, white 24 pin plug, pin 21
Brake Wire	Pink	+	BCM in passenger kick, green 40 pin plug, pin 27
Parking Brake	ing Brake Lt. Green -		Parking Brake Switch, white 1 pin plug, pin 1
Horn Trigger			Horn Switch-Clock Spring, yellow 6 pin plug, pin 1
Wipers	Violet (LO); Blue (HI)	+	Underhood Fuse Box, white 12 pin plug, pin 5 (LO); pin 12 (HI)
Left Front Window (Up/Down)	(use factory alarm arm/disarm)		
Right Front Window (Up/Down)	(see left front window)		
Left Rear Window (Up/Down)	(see left front window)		
Right Rear Window (Up/Down)	(see left front window)		
Sun Roof (Open/Close)			Sunroof Switch, white 12 pin plug, pins 4 - 9
Memory Seat 1			Driver Kick, harness to rear
Memory Seat 2	Violet	-	Driver Kick, harness to rear
Radio 12V	Yellow	+	Radio, white 20 pin plug, pin 19
Radio Ground	Black	-	Radio, white 20 pin plug, pin 20
Radio Ignition	Lt. Blue or Violet	+	Radio, white 20 pin plug, pin 7
Power Antenna	(no wire color listed in service manual)	+	Radio, 3 pin plug, pin 1
Left Front Speaker (+/-)	Front Speaker Blue - Red		Radio, white 20 pin plug, pins 2 - 3





http://www.directechs.com

Item	Wire Color	Polarity	Wire Location
Right Front Speaker (+/-)	Lt. Green - Pink	+,-	Radio, white 20 pin plug, pins 11 - 12
Left Rear Speaker (+/-)			Radio, white 20 pin plug, pins 4 - 5
Right Rear Speaker (+/-)	Blue - Pink	+,-	Radio, white 20 pin plug, pins 13 - 14
Left Front Speaker - With Amp	Pink - Violet (woofer); Pink - Violet (dash midrange)	+,-	Amplifier under rear deck, brown 14 pin plug, pins 4 - 13 (woofer); brown 23 pin plug, pins 12 - 2 (dash midrange)
Right Front Speaker - With Amp			Amplifier under rear deck, brown 14 pin plug, pins 8 - 9 (woofer); brown 23 pin plug, pins 4 - 3 (dash midrange)
Left Front Tweeter - With Amp	Green - Red (door midrange/tweeter)	+,-	Amplifier under rear deck, brown 23 pin plug, pins 20 - 8
Right Front Tweeter - With Amp	White - Black (door midrange/tweeter)	+,-	Amplifier under rear deck, brown 23 pin plug, pins 15 - 5
Left Rear Speaker - With Amp	Brown - Red	+,-	Amplifier under rear deck, brown 14 pin plug, pins 10 - 11
Right Rear Speaker - With Amp	Blue - Pink	+,-	Amplifier under rear deck, brown 14 pin plug, pins 5 - 14
Left Rear Surround - With Amp	ith Amp		Amplifier under rear deck, brown 23 pin plug, pins 18 - 6
Right Rear Surround - With Amp	Blue - Pink	+,-	Amplifier under rear deck, brown 23 pin plug, pins 19 - 7
Center Channel - With Amp	Brown - Gray	+,-	Amplifier under rear deck, brown 23 pin plug, pins 13 - 14
Subwoofer - With Amp			Amplifier under rear deck, brown 14 pin plug, pins 6 - 7
Aux. Audio Input Left (+/-)	udio Input Left White - Red		Radio, white 12 pin plug, pins 6 - 11
Aux. Audio Input Right (+/-)			Radio, white 12 pin plug, pins 12 - 11
RSE Video (+/-)			Radio, white 40 pin plug, pins 18 - 19 (front display); pins 16 - 36 (aux. video)
RSE Audio Left (+/-)	Violet - Blue (bluetooth audio)	+,-	Radio, white 12 pin plug, pins 1 - 7





		http:/	/ww	w.di	rect	ech	15.CO	m
--	--	--------	-----	------	------	-----	-------	---

Item	Wire Color	Polarity	Wire Location
RSE Audio Right (+/-)	Red - Green (bluetooth audio)	+,-	Radio, white 12 pin plug, pins 2 - 8





What Fits

Item	Size	Depth	Location
Headunit	Irregular		Center of Dash
Left Front Speaker	6.5 or 10		Left Front Door
Left Front Tweeter			Left Front Door; Left Front Door and Front Dash
Right Front Speaker	6.5 or 10		Right Front Door
Right Front Tweeter	ht Front Tweeter 1 (tweeter); 3.25 (midrange)		Right Front Door; Right Front Door and Front Dash
Left Rear Speaker	ft Rear Speaker 6.5 or 5.25		Left Rear Door
Left Rear Tweeter	ear Tweeter 3.25 (surround)		Left Rear Shelf
Right Rear Speaker	6.5 or 5.25		Right Rear Door
Right Rear Tweeter	3.25 (surround)		Right Rear Shelf
Center Channel	3.25		Top Center of Dash
Subwoofer	10		Top Center of Rear Shelf