



### Wiring Information

| Item                      | Wire Color                                       | Polarity | Wire Location  |
|---------------------------|--|----------|--|
| 12 Volts                  | White (40A)                                      | +        | BCM in passenger kick,<br>white 15 pin plug, pin 11      |
| Ground                    | (chassis ground)                                 |          |  |
| Starter                   | Red  | -        | BCM in passenger kick,<br>black 40 pin plug, pin 22      |
| Ignition                  | White/Black                                      | +        | BCM in passenger kick,<br>black 40 pin plug, pin 27      |
| Second Ignition           | Black  | -        | BCM in passenger kick,<br>black 40 pin plug, pin 30      |
| Accessory                 | Black  | +        | BCM in passenger kick,<br>black 40 pin plug, pin 26      |
| Second Accessory          | Lt. Blue   | +        | BCM in passenger kick,<br>black 24 pin plug, pin 9       |
| PTS 1                     | Red  | -        | BCM in passenger kick,<br>green 40 pin plug, pin 1       |
| CAN Bus High              | Blue   | Data     | BCM in passenger kick,<br>black 40 pin plug, pin 20      |
| CAN Bus Low               | Pink   | Data     | BCM in passenger kick,<br>black 40 pin plug, pin 19      |
| CAN Bus High 2            | Blue   | Data     | OBD-Data Link<br>Connector, white 16 pin<br>plug, pin 6  |
| CAN Bus Low 2             | Pink   | Data     | OBD-Data Link<br>Connector, white 16 pin<br>plug, pin 14 |
| OBD 12 Volts              | White (5A)                                       | +        | OBD-Data Link<br>Connector, white 16 pin<br>plug, pin 16 |
| OBD Ground                | Black  | -        | OBD-Data Link<br>Connector, white 16 pin<br>plug, pin 4  |
| OBD Ignition              | White  | +        | OBD-Data Link<br>Connector, white 16 pin<br>plug, pin 8  |
| IMMO Antenna              | (NATS antenna is on push button ignition switch) |          |  |
| Security Light            | Blue   | -        | BCM in passenger kick,<br>green 40 pin plug, pin 18      |
| Power Lock                | (use factory alarm arm)                          |          |  |
| Power Unlock              | (use factory alarm disarm)                       |          |  |
| Lock Motor                | Violet   | Reverse  | BCM in passenger kick,<br>white 15 pin plug, pin 7       |
| Driver Unlock Motor       | Lt. Green  | Reverse  | BCM in passenger kick,<br>white 15 pin plug, pin 9       |
| Passenger Unlock<br>Motor | Pink   | Reverse  | BCM in passenger kick,<br>white 15 pin plug, pin 2       |





| Item                        | Wire Color   | Polarity  | Wire Location   |
|-----------------------------|--|-----------|---|
| Factory Alarm Arm           | Violet (key lock)  | -         | Power Window Main<br>Switch, white 16 pin plug,<br>pin 15   |
| Factory Alarm Disarm        | Yellow (key unlock)  | Double -  | Power Window Main<br>Switch, white 16 pin plug,<br>pin 16   |
| Parking Lights              | Red  | +         | Dash Fuse Box, white 40 pin plug, pin 16  |
| Hazards                     | Green  | -         | BCM in passenger kick, green 40 pin plug, pin 36  |
| Turn Signal (Left)          | White/Black (LF); Yellow (LR)                                    | +         | BCM in passenger kick,<br>black 24 pin plug, pin 13<br>(LF); gray 24 pin plug, pin<br>23 (LR)         |
| Turn Signal (Right)         | Violet (RF); White (RR)  | +         | BCM in passenger kick,<br>black 24 pin plug, pin 1<br>(RF); gray 24 pin plug, pin<br>12 (RR)          |
| Headlight                   | Lt. Blue or Violet (LO L); Red (LO R); Pink (HI L); Brown (HI R) | +         | Underhood Fuse Box,<br>white 8 pin plug, pin 3 (LO<br>L); pin 2 (LO R); pin 8 (HI<br>L); pin 7 (HI R) |
| Reverse Light               | Tan  | +         | Passenger Kick, harness to rear   |
| Left Front Door<br>Trigger  | Violet   | -         | BCM in passenger kick, gray 24 pin plug, pin 16   |
| Right Front Door<br>Trigger | Gray   | -         | BCM in passenger kick, gray 24 pin plug, pin 14   |
| Dome Light                  | Violet   | -         | BCM in passenger kick, white 15 pin plug, pin 8   |
| Trunk/Hatch Pin             | Red  | -         | BCM in passenger kick, gray 24 pin plug, pin 17   |
| Hood Pin                    | Pink or Lt. Blue   | -         | Underhood Fuse Box, white 16 pin plug, pin 15   |
| Trunk/Hatch Release         | Blue   | -         | BCM in passenger kick,<br>black 40 pin plug, pin 40   |
| Trunk Release Motor         | Gray   | Reverse   | BCM in passenger kick, gray 24 pin plug, pin 11   |
| Fuel Door Release           | (locks/unlocks with driver door)                                 |           |   |
| Tachometer                  | Pink (w/o Bose); White (with Bose)                               | AC        | Passenger Kick, harness to rear   |
| Fuel Pump                   | Brown or Blue  | +         | Above Driver Kick, white 6 pin plug, pin 2 or 4   |
| Rear Defroster              | Green  | - Latched | BCM in passenger kick,<br>black 40 pin plug, pin 21   |
| Mirror Defroster            | (same as rear defroster)   |           |   |
| Left Front Heated<br>Seat   | (CAN)  |           |   |





http://www.directechs.com

| Item                              | Wire Color   | Polarity | Wire Location   |
|-----------------------------------|--|----------|---|
| Right Front Heated<br>Seat        | (CAN)  |          |   |
| Speed Sense                       | Red  | 8-Pulse  | Display Control Unit,<br>white 24 pin plug, pin 21  |
| Brake Wire                        | Pink   | +        | BCM in passenger kick,<br>green 40 pin plug, pin 27   |
| Parking Brake                     | Lt. Green  | -        | Parking Brake Switch, white 1 pin plug, pin 1   |
| Horn Trigger                      | Lt. Green  | -        | Horn Switch-Clock<br>Spring, yellow 6 pin plug,<br>pin 1 or white 24 pin plug,<br>pin 17      |
| Wipers                            | Violet (LO); Blue (HI)                                     | +        | Underhood Fuse Box,<br>white 12 pin plug, pin 5<br>(LO); pin 12 (HI)                          |
| All Windows Up-<br>Down           | (use factory alarm arm/disarm)                             |          |   |
| Sun Roof<br>(Open/Close)          | Pink - Lt. Blue (function with ignition on only)           | -        | Sunroof Switch, white 12 pin plug, pins 4 - 9   |
| Memory Seat 1                     | Brown  | -        | Driver Kick, harness to rear  |
| Memory Seat 2                     | Violet   | -        | Driver Kick, harness to rear  |
| Radio 12V                         | Yellow   | +        | Radio, white 20 pin plug, pin 19  |
| Radio Ground                      | Black  | -        | Radio, white 20 pin plug, pin 20  |
| Radio Ignition                    | Lt. Blue   | +        | Radio, white 20 pin plug, pin 7   |
| Power Antenna                     | (no wire color listed in service manual)                   | +        | Radio, 3 pin plug, pin 1  |
| Left Front Speaker (+/-)          | Blue - Red   | +,-      | Radio, white 20 pin plug, pins 2 - 3  |
| Right Front Speaker (+/-)         | Lt. Green - Pink   | +,-      | Radio, white 20 pin plug, pins 11 - 12  |
| Left Rear Speaker (+/-)           | Lt. Green - Lt. Blue                                       | +,-      | Radio, white 20 pin plug, pins 4 - 5  |
| Right Rear Speaker (+/-)          | Blue - Pink  | +,-      | Radio, white 20 pin plug, pins 13 - 14  |
| Left Front Speaker -<br>With Amp  | Pink - Violet (woofer-tweeter)                             | +,-      | Amplifier in right rear side panel, brown 14 pin plug, pins 4 - 13                            |
| Right Front Speaker -<br>With Amp | Blue - Yellow (woofer-tweeter)                             | +,-      | Amplifier in right rear side panel, brown 14 pin plug, pins 8 - 9                             |
| Left Front Tweeter -<br>With Amp  | Green - Red (door midrange); Pink - Violet (dash midrange) | +,-      | Amplifier in right rear side panel, brown 23 pin plug, pins 20 - 8 (door); pins 12 - 2 (dash) |





| Item                              | Wire Color   | Polarity | Wire Location  |
|-----------------------------------|--|----------|--|
| Right Front Tweeter -<br>With Amp | White - Black (door midrange); Pink - Blue (dash midrange)       | +,-      | Amplifier in right rear side panel, brown 23 pin plug, pins 15 - 5 (door); pins 4 - 3 (dash) |
| Left Rear Speaker -<br>With Amp   | Red - Blue (woofer)  | +,-      | Amplifier in right rear side panel, brown 14 pin plug, pins 6 - 7                            |
| Right Rear Speaker -<br>With Amp  | Brown - Red (woofer)   | +,-      | Amplifier in right rear side panel, brown 14 pin plug, pins 10 - 11                          |
| Left Rear Tweeter -<br>With Amp   | White - Black (midrange)   | +,-      | Amplifier in right rear side panel, brown 23 pin plug, pins 18 - 6                           |
| Right Rear Tweeter -<br>With Amp  | Blue - Pink (midrange)   | +,-      | Amplifier in right rear side panel, brown 23 pin plug, pins 19 - 7                           |
| Center Channel -<br>With Amp      | Brown - Gray   | +,-      | Amplifier in right rear side panel, brown 23 pin plug, pins 13 - 14                          |
| Aux. Audio Input Left (+/-)       | White - Red  | +,-      | Radio, white 12 pin plug, pins 6 - 11  |
| Aux. Audio Input<br>Right (+/-)   | Black - Red  | +,-      | Radio, white 12 pin plug, pins 12 - 11   |
| Rearview Camera<br>Video          | Black - (Shield)   | +,-      | Display Control Unit,<br>white 40 pin plug, pins 24<br>- 4                                   |
| RSE Video (+/-)                   | Blue - Violet (aux. video); Brown - Lt.<br>Green (display video) | +,-      | Radio, white 40 pin plug,<br>pins 16 - 36 (aux.); pins<br>18 - 19 (display)                  |





### What Fits

| Item                | Size                             | Depth | Location  |
|---------------------|----------------------------------|-------|---|
| Headunit            | Irregular                        |       | Center of Dash  |
| Left Front Speaker  | 6.5 or 10 (woofer); 3 (midrange) |       | Left Front Door (woofer);<br>Left Front Dash and Door<br>(midrange)   |
| Left Front Tweeter  | 1                                |       | Left Front Door   |
| Right Front Speaker | 6.5 or 10 (woofer); 3 (midrange) |       | Right Front Door (woofer);<br>Right Front Dash and<br>Door (midrange) |
| Right Front Tweeter | 1                                |       | Right Front Door  |
| Left Rear Speaker   | 6 x 9                            |       | Left Rear Shelf   |
| Left Rear Tweeter   | 3                                |       | Left Rear Side Panel  |
| Right Rear Speaker  | 6 x 9                            |       | Right Rear Shelf  |
| Right Rear Tweeter  | 3                                |       | Right Rear Side Panel   |
| Center Channel      | 3                                |       | Top Center of Dash  |