
2011 Audi A8





Wiring Information

Item	Wire Color	Polarity	Wire Location
12 Volts	red/gray (30A)	+	VESCM under driver dash, brown 17 pin plug, pin 16
Second 12 Volts	red/black (30A)	+	VESCM under driver dash, red 17 pin plug, pin 16
Starter	yellow/brown (for starter kill only)	+	Comfort System Module in R side of trunk, gray 32 pin plug, pin 5
Second Starter	blue/white (SS1), black/red (SS2), black/gry (SS3)	-	start/stop button, 6 pin plug, pins 3, 5, and 6
Ignition	blue/red (for ignition sense only)	+	VESCM under driver dash, black 32 pin plug, pin 16
Second Ignition	N/A		
Third Ignition	N/A		
Accessory	red/purple (for accessory sense only)	+	cigarette lighter, 3 pin plug, pin 2
Second Accessory	N/A		
Third Accessory	N/A		
Key Sense	N/A		
Data Bus	N/A		
Can Bus High	orange/green	data	driver kick or VESCM under driver dash, brown 16 pin plug, pin 15
Can Bus Low	orange/brown	data	driver kick or VESCM under driver dash, brown 16 pin plug, pin 14
Can Bus Sw	N/A		
Power Lock	purple/red	- resistor	Driver Door Module, blue 32 pin plug, pin 28
Power Unlock	same as power lock	- resistor	
Lock Motor	blue/brown	5 wire	Driver Door Module, black 20 pin plug, pin 13
Unlock Motor	brown/green	5 wire	Driver Door Module, black 20 pin plug, pin 11
Disarm Defeat	brown/green	5 wire	Passenger Door Module, black 20 pin plug, pin 11
Parking Lights (+)	gray/black (LF); gray/red (RF)	+	VESCM under dr dash, red 17 pin plg, pin 12; brn 17 pin plg, pin 2
Parking Lights (-)	(LIN bus)		
Hazards	red/blue	-	VESCM under driver dash, gray 32 pin plug, pin 8
Turn Signal (Left)	black/green (F); black/yellow (R)	+	VESCM, bn 17 pin plg, pin5; Cmft Sys Mod, brown 17 pin plg, pin 11
Turn Signal (Right)	black/white (F); black/red (R)	+	VESCM, rd17 pin plg, pin10; Cmft Sys Mod, black 17 pin plug, pin 10 rectWire and its vehicle information are fo



Wiring Information (Continued)

Item	Wire Color	Polarity	Wire Location	
Headlight	yellow/black (L); yellow/red (R)	+	VESCM under dr dash, brn 17 pin plg, pin 15; red 17 pin plg, pin 15	
AutoLights	(LIN bus)			
Reverse Light	white/green	+	Comfort System Module in R side of trunk, brown 17 pin plug, pin 14	
Left Front Door Trigger	brown/green	-	Driver Door Module, black 20 pin plug, pin 5	
Right Front Door Trigger	brown/gray	-	Passenger Door Module, black 20 pin plug, pin 5	
Left Rear Door Trigger	gray/purple	-	Left Rear Door Module, black 20 pin plug, pin 5	
Right Rear Door Trigger	gray/purple	-	Right Rear Door Module, black 20 pin plug, pin 5	
Dome Supervision	(LIN bus)			
Trunk/Hatch Pin	white/black	-	Comfort System Module in R side of trunk, gray 32 pin plug, pin 4	
Rear Glass Pin	N/A			
Hood Pin	yellow/black	-	VESCM under driver dash, black 32 pin plug, pin 3	
Trunk Hatch/Release	red/green	-	Driver Door Module, blue 32 pin plug, pin 23	
Trunk Release Motor	green/white	5 wire	Comfort System Module in R side of trunk, black 17 pir plug, pin 5	
Fuel Door Release	locks/unlocks along with doors			
Power Sliding Door (Left)	N/A			
Power Sliding Door (Right)	N/A			
Factory Alarm Arm	blue/white (driver door key cylinder)	-	Driver Door Module, black 20 pin plug, pin 1	
Factory Alarm Disarm	same as factory alarm arm	- 250 ohms		
Disarm No Unlock	see factory alarm disarm			
Trunk Alarm Shunt	N/A			
Tachometer	brown/stripe	ac	any fuel injector	
Wait to Start	N/A			
Neutral Safety	N/A			
Clutch Pedal	N/A			
Fuel Pump	red/gray	+	fuel pump relay in R side of trunk	
Rear Defroster	red/brown	+ latched	Comfort System Module in R side of trunk, black 32 pin plug, pin 4	
Mirror Defroster	(CAN bus)			
Left Front Heated Seat	(CAN bus)			
Right Front Heated Seat	(CAN bus)			

Wiring Information (Continued)

Item	Wire Color	Polarity	Wire Location
Speed Sense	(wheel speed sensor)	1 Olarity	Wife Education
Brake Wire	black/green	+	brake switch, 4 pin plug, pin 3
Parking Brake	green/purple	_	electric parking brake switch, 12 pin plug, pin 8
Horn Trigger	black/white	+	VESCM under driver dash, black 32 pin plug, pin 29
Wipers	(LIN bus)	•	VESCHI UNDER GITVET GGSTI, BIGGR 62 PIII PIGG, PIII 25
Left Front Window	use factory alarm		
(Up/Down)	arm/disarm		
Right Front Window (Up/Down)	see left front window		
Left Rear Window (Up/Down)	see left front window		
Right Rear Window (Up/Down)	see left front window		
Sun Roof (Open/Close)	use factory alarm arm/disarm		
Sun Roof (Limit/Close)	N/A		
Memory Seat 1	gray	- resistor	Driver Door Module, blue 32 pin plug, pin 19
Memory Seat 2	same as memory seat 1	- resistor	
Memory Seat 3	N/A		
Radio 12V	red/yellow	+	radio, 10 pin plug, pin 10
Radio Ground	brown	-	radio, 10 pin plug, pin 9
Radio Ignition	(CAN bus)		
Radio Illumination	(CAN bus)		
Factory Amp Turn-on	(CAN bus)		
Power Antenna	N/A		
Left Front Speaker (+/-)	wht-blu (t); red-brn/red (m); wht/blk-blu/blk (w)	+,-	amplifier in L side of trunk, 38 pin plug, pins 10 - 22; 19 - 7; 16 - 4
Right Front Speaker (+/-)	red-brn (t); blu-brn/blu (m); red/blk-brn/blk (w)	+,-	amplifier in L side of trunk, 38 pin plug, pins 21 - 9; 8 - 20; 12 - 11
Left Rear Speaker (+/-)	white/purple-blue/purple (t+m); blue-brown (surr)	+,-	amplifier in L side of trunk, 38 pin plug, pins 13 and 14; 34 and 33
Right Rear Speaker (+/-)	red/purple-brown/purple (t+M); red-brown (surr)	+,-	amplifier in L side of trunk, 38 pin plug, pins 3 and 15; 37 and 38
Center Channel (+/-)	white - brown	+,-	amplifier in L side of trunk, 38 pin plug, pins 31 and 32
Subwoofer (+/-)	red/gray - brown/gray	+,-	amplifier in L side of trunk, 38 pin plug, pins 17 and 5
Aux. Audio Input Left (+/-)	yellow - brown	+,-	radio, 12 pin plug, pins 2 and 1
Aux. Audio Input Right (+/-)	green - brown	+,-	radio, 12 pin plug, pins 7 and 1
RSE Video (+/-)	(coaxial cable)		
RSE Audio Left (+/-)	(MOST bus)		
RSE Audio Right (+/-)	(MOST bus)		
Satellite Radio 12 Volts	N/A		
Satellite Radio Ground	N/A		
Satellite Radio Ignition	N/A		
Satellite Radio Antenna	N/A		

Saterite Arcais chicle, Info	rmation - 6/A 4/2013 12	55:16 AM	
Satellite Audio Right (+/-)	N/A		

What Fits

Item	Size	Depth	Location
Headunit	irregular		center of dash
Left Front Speaker	6.5	3	left front door
Left Front Tweeter	1 (tweeter); 3 (midrange)	1; 1.5	left front dash (tweeter); front door (midrange)
Right Front Speaker	6.5	3	right front door
Right Front Tweeter	1 (tweeter); 3 (midrange)	1; 1.5	right front dash (tweeter); front door (midrange)
Left Rear Speaker	6.5	3	left rear door
Left Rear Tweeter	1 (tweeter); 3 (surround)	1; 1.5	left rear door (tweeter); rear deck (surround)
Right Rear Speaker	6.5	3	right rear door
Right Rear Tweeter	1 (tweeter); 3 (surround)	1; 1.5	right rear door (tweeter); rear deck (surround)
Center Channel	3	1.5	top center of dash
Subwoofer	10	3	center of rear deck
Left Front Headrest			
Right Front Headrest			
Left Right Headrest			
Right Rear Headrest			
Satellite Radio Tuner	(built into radio)		