2010 BMW X6 (E71/E72)






Wiring Information

Wire Color	Polarity	Wire Location
red/green (40A)	+	Footwell Module in driver kick, 51 pin plug (X14260), pin 2
red/purple (40A)	+	Footwell Module, 51 pin plug (X14261), pin 34
black (for starter kill only)	+ low curr	Car Access System under driver dash, 41 pin plug, pin 22
N/A		
green (for ignition sense only)	+ low curr	Car Access System under driver dash, 41 pin plug, pin 8
N/A		
IMMOBILIZER AND IGNITION INTERFACE REQUIRED FOR RS		
orange/green	data	Footwell Module in driver kick, 51 pin plug (X14260), pin 46
green	data	Footwell Module in driver kick, 51 pin plug (X14260), pin 45
N/A		
yellow/red (center dash switch)	-	Car Access System under driver dash, 41 pin plug, pin 29
same as power lock		
white or black	5 wire	driver kick or pass dash fuse box ECU, 47 pin plug, pin 36 or 14
blue	5 wire	driver kick or pass dash fuse box ECU, 47 pin plug, pin 18
blue	5 wire	passenger kick or pass dash fuse box ECU, 47 pin plug, pin 19
blue (LF); black/green (RF)	+	Footwell Mod, 51P plug (X14261), pin 50; 51P plug (X14260), pin 8
black	-	Footwell Module in driver kick, 26 pin plug, pin 1
brown/blue	-	Footwell Module in driver kick, 26 pin plug, pin 18
blue/green (F); blue/green (R)	+	Footwell Mod, 51P plug (X14260), pin 13; 51P plug (X14261), pin 45
	red/green (40A) red/purple (40A) black (for starter kill only) N/A N/A green (for ignition sense only) N/A N/A N/A N/A N/A N/A N/A IMMOBILIZER AND IGNITION INTERFACE REQUIRED FOR RS orange/green green N/A N/A yellow/red (center dash switch) same as power lock white or black blue blue blue blue blue blue blue black brown/blue	red/green (40A) + red/purple (40A) + black (for starter kill only) + low curr N/A green (for ignition sense only) + low curr N/A N/A N/A N/A N/A N/A IMMOBILIZER AND IGNITION INTERFACE REQUIRED FOR RS orange/green data green data N/A yellow/red (center dash switch) - same as power lock white or black 5 wire blue 5 wire blue (LF); black/green (RF) + black - brown/blue -

Piractivize Vehicle Information (F)/30/2013 nl(R)3:18 AM	+	Footwell Mod, 51P plug (X14261), pin 40; 51P
(Right)		plug (X14260), pin 12

Wiring Information (Continued)

Item	Wire Color	Polarity	Wire Location
Headlight	yellow/green (L); yellow/blue (R)	+	Footwell Mod, 51P plug (X14260), pin 6; 51P
lieaungiit	yellow/green (L), yellow/blue (IV)		plug (X14261), pin 38
AutoLights			
Reverse Light	yellow/brown	+	Footwell Module in driver kick, 51 pin plug (X14261), pin 47
Left Front Door Trigger	brown/gray/yellow - F		Footwell Module in driver kick, 51 pin plug (X14261), pin 24
Right Front Door Trigger	brown/gray/yellow	-	Footwell Module, 51 pin plug (X14261), pin 13
Left Rear Door Trigger	brown/gray	-	Footwell Module, 51 pin plug (X14261), pin 26
Right Rear Door Trigger	brown/white	-	Footwell Module, 51 pin plug (X14261), pin 15
Dome Supervision	red/blue (without Roof Function Cntrl Center only)	+	Footwell Module in driver kick, 51 pin plug (X14260), pin 35
Trunk/Hatch Pin	gray/brown	-	passenger dash fuse box ECU, 54 pin plug, pin 50
Rear Glass Pin	N/A		
Hood Pin	purple/green	-	Car Access System under driver dash, 41 pin plug, pin 38
Trunk Hatch/Release	gray/yellow	-	release switch or pass dash fuse box ECU, 54 pin plug, pin 44
Trunk Release Motor	gray/green	5 wire	passenger dash fuse box ECU, 47 pin plug, pin 39
Fuel Door Release	unlocks along with driver door		
Power Sliding Door (Left)	N/A		
Power Sliding Door (Right)	N/A		
Factory Alarm Arm	blue/red (driver door key lock)	-	Footwell Module in driver kick, 51 pin plug (X14261), pin 42
Factory Alarm Disarm	white/black (driver door key unlock)	-	Footwell Module in driver kick, 51 pin plug (X14261), pin 46
Disarm No Unlock			
Trunk Alarm Shunt	N/A		
Tachometer	black	ac	data link connector, 16 pin plug, pin 9
Wait to Start	N/A		
Neutral Safety	N/A		
Clutch Pedal	N/A		
Fuel Pump	red/white or white/blue	+	fuel pump under left rear seat
Rear Defroster	black	+ latched	passenger dash fuse box, plug (X11003), pin 1
Mirror Defroster	(LIN BUS)		
Left Front Heated Seat	(LIN BUS or CAN BUS)		
Right Front Heated Seat	(LIN BUS or CAN BUS)		



Wiring Information (Continued)

Item	Wire Color	Pol.	arit Wire Location	
Speed Sense	yellow/purple	ac	Car Access System under driver dash, 41 pin plug, pin 31	
Brake Wire	brown/gray (functions with ignition on only)	+	brake switch or Car Access System under dr dash, 41 pin plug, pin 32	
Parking Brake	(electric parking brake)			
Horn Trigger	purple/blue	+	passenger dash fuse box, plug (X11002), pin 9	
Wipers	black/blue (L), black/brown (H)	+	passenger dash fuse box, plug (X11006), pins 9, 10	
Left Front Window (Up/Down)	use factory alarm arm/disarm			
Right Front Window (Up/Down)	see left front window			
Left Rear Window (Up/Down)	see left front window			
Right Rear Window (Up/Down)	see left front window			
Sun Roof (Open/Close)	use factory alarm arm/disarm			
Sun Roof (Limit/Close)	N/A			
Memory Seat 1	(LIN BUS)			
Memory Seat 2	(LIN BUS)			
Memory Seat 3	N/A			
Radio 12V	red/green	+	radio, 16 pin plug, pin 15	
Radio Ground	brown	-	radio, 16 pin plug, pin 12	
Radio Ignition	(CAN BUS)			
Radio Illumination	gray/red (dimmer)	+	radio, 16 pin plug, pin 14	
Factory Amp Turn-on	(same as power ant - HiFi); (MOST BUS - Top HiFi)			
Power Antenna	black	+	radio, 16 pin plug, pin 13	
Left Front Speaker (+/-)	red/white - brown/yellow or yellow/red - brown/org	+,-	radio, 16 pin plug, pins 3 - 7	
Right Front Speaker (+/-)	red/blue - brown/white or blue/red - brown/orange	+,-	radio, 16 pin plug, pins 2 - 6	
Left Rear Speaker (+/-)	yellow/red - yellow/brown or yellow/blk - brn/org	+,-	radio, 16 pin plug, pins 4 - 8	
Right Rear Speaker (+/-)	blue/green - blue/brown or blue/black - brown/org	+,-	radio, 16 pin plug, pins 1 - 5	
Center Channel (+/-)	black/white - black/brown	+,-	amplifier, 42 pin plug, pins 39 - 40, or 20 pin plug, pins 5 - 15	
Subwoofer (+/-)	red/wht - brown/yel (L); red/blue - brown/wht (R)	+,-	amplifier, 42 pin plg, pins 4-3; 23-22, or 20 pin plug, pins 8-18; 6-16	
Aux. Audio Input Left (+/-)				
Aux. Audio Input Right (+/-)				
RSE Video (+/-)				

Rise at Wise exchiple	Information - 9/30/2013 1:13:18 AM		
RSE Audio Right (+/-)			
Satellite Radio 12 Volts	red/purple	+	Sat Radio in left side of trunk, 3 pin plug, pin 1
Satellite Radio Ground	brown	-	Sat Radio in left side of trunk, 3 pin plug, pin 3
Satellite Radio Ignition	(MOST BUS)		
Satellite Radio Antenna	(coaxial cable)		
Satellite Audio Left (+/-)	(MOST BUS)		
Satellite Audio Right (+/-)	(MOST BUS)		

What Fits

Item	Size	Depth	Location
Headunit	irregular		center of dash
Left Front Speaker	3.9		left front door
Left Front Tweeter	1		left front door
Right Front Speaker	3.9		right front door
Right Front Tweeter	1		right front door
Left Rear Speaker	3.9		left rear door; left rear pillar
Left Rear Tweeter	1		left rear door; left rear pillar
Right Rear Speaker	3.9		right rear door; right rear pillar
Right Rear Tweeter	1		right rear door; right rear pillar
Center Channel	3.9		top center of dash
Subwoofer	8.5		under front seats
Left Front Headrest			
Right Front Headrest			
Left Right Headrest			
Right Rear Headrest			
Satellite Radio Tuner			left side of trunk

DirectWire Vehicle Information - 9/30/2013 1:13:18 AM

Additional Wiring Notes

Item	Note
	On models with amplifier, the speaker wires are blue/white - blue/brown at the amplifier in left side of trunk, 42 pin plug, pins 33 - 34, or 20 pin plug, pins 19 - 9.
	On models with amplifier, the speaker wires are blue/black - blue/brown at the amplifier in left side of trunk, 42 pin plug, pins 11 - 12, or 20 pin plug, pins 17 - 7.
. , ,	On models with amplifier, the door speaker wires are yellow/red - yellow/brown at the amplifier in left side of trunk, 42 pin plug, pins 31 - 32, or 20 pin plug, pins 14 - 4. The rear pillar speaker wires are yellow/red - yellow/brown at the amplifier, 20 pin plug, pins 1 - 11.
	On models with amplifier, the door speaker wires are blue/green - blue/brown at the amplifier in left side of trunk, 42 pin plug, pins 13 - 21, or 20 pin plug, pins 13 - 3. The rear pillar speaker wires are blue/green - blue/brown at the amplifier, 20 pin plug, pins 12 - 2.
	The LR - RR are yellow/black - yellow/purple at the Footwell Module in driver kick, 51 pin plug (X14260), pins 16 - 18.