

2008 Honda Accord

Wiring Information

Item	Wire Color	Polarity	Wire Location
12 Volts	white (50A)	+	ignition switch, white 5 pin plug, pin 2
Second 12 Volts	N/A		
Starter	yellow	+	ignition switch, white 5 pin plug, pin 1
Second Starter	N/A		
Ignition	blue	+	ignition switch, white 5 pin plug, pin 5
Second Ignition	N/A		
Third Ignition	N/A		
Accessory	orange	+	ignition switch, white 5 pin plug, pin 3
Second Accessory	red	+	ignition switch, white 5 pin plug, pin 4
Third Accessory	N/A		
Key Sense	white	-	ignition key switch, green 6 pin plug, pin 1
Data Bus	lt. green (data), yellow (ignition), brown(ground)	data	Immobilizer Module, white 7 pin plug, pins 6, 2, and 7
Can Bus High	pink	data	Immobilizer Module, white 7 pin plug, pin 4
Can Bus Low	blue	data	Immobilizer Module, white 7 pin plug, pin 3
Can Bus Sw	N/A		
Power Lock	use factory alarm arm		
Power Unlock	use factory alarm disarm		
Lock Motor	orange	5 wire	driver kick, door harness
Unlock Motor	yellow	5 wire	driver kick, door harness
Disarm Defeat	lt. green	5 wire	passenger kick, door harness
Parking Lights (+)	red	+	driver fuse box, 16 pin plug, pin 11
Parking Lights (-)	gray	-	headlight switch, 12 pin plug, pin 11
Hazards	green	+	hazard switch, white 6 pin plug, pin 2
Turn Signal (Left)	blue	+	driver fuse box, 16 pin plug, pin 13
Turn Signal (Right)	green	+	driver fuse box, 16 pin plug, pin 7

Wiring Information (Continued)

Item	Wire Color	Polarity	Wire Location
Headlight	brown	-	headlight switch, 12 pin plug, pin 10
AutoLights	red	-	headlight switch, 12 pin plug, pin 9
Reverse Light	lt. blue	+	driver fuse box, 16 pin plug, pin 6
Left Front Door Trigger	brown	-	driver fuse box, 16 pin plug, pin 12
Right Front Door Trigger	green	-	passenger fuse box, bottom, 38 pin plug, pin 3
Left Rear Door Trigger	lt. green	-	driver fuse box, 16 pin plug, pin 4
Right Rear Door Trigger	lt. green	-	passenger fuse box, bottom, 38 pin plug, pin 25
Dome Supervision	pink	-	driver fuse box, rear, 20 pin plug, pin 4
Trunk/Hatch Pin	white	-	driver fuse box, 16 pin plug, pin 5
Rear Glass Pin	N/A		
Hood Pin	green/black	-	driver fuse box, 13 pin plug, pin 3
Trunk Hatch/Release	use trunk release motor		
Trunk Release Motor	orange	+	driver fuse box, 16 pin plug, pin 16
Fuel Door Release	N/A		
Power Sliding Door (Left)	N/A		
Power Sliding Door (Right)	N/A		
Factory Alarm Arm	orange	-	power window master switch, gray 37 pin plug, pin 28
Factory Alarm Disarm	brown and white (double pulse)	-	power window master switch, gray 37 pin plug, pins 29, 31
Disarm No Unlock	see factory alarm disarm		
Trunk Alarm Shunt	N/A		
Tachometer	NOT yellow/black	ac	any fuel injector
Wait to Start	N/A		
Neutral Safety	N/A		
Clutch Pedal	black (in), orange (out)	- N.O.	clutch pedal switch
Fuel Pump	pink	+	driver fuse box, 16 pin plug, pin 10
Rear Defroster	brown	- latched	driver fuse box, 33 pin plug, pin 6
Mirror Defroster	orange (L), orange (R)	+ latched	each front power window switch, gray 37 pin plug, pin 1
Left Front Heated Seat	red	+ latched	driver seat heater switch, blue 6 pin plug, pin 3
Right Front Heated Seat	green	+ latched	passenger seat heater switch, white 7 pin plug, pin 4

Wiring Information (Continued)

Item	Wire Color	Polarity	Wire Location
Speed Sense	blue (1 CD disc player only)	ac	radio, gray 24 pin plug, pin 15
Brake Wire	lt. green	+	switch or driver fuse box, 33 pin plug, pin 20
Parking Brake	lt. green	-	parking brake switch
Horn Trigger	orange	-	horn switch
Wipers	orange (L), white (H)	-	wiper switch, 8 pin plug, pins 2 (L) and 4 (H)
Left Front Window (Up/Down)	use factory alarm arm/disarm		
Right Front Window (Up/Down)	see left front window		
Left Rear Window (Up/Down)	see left front window		
Right Rear Window (Up/Down)	see left front window		
Sun Roof (Open/Close)	use factory alarm arm/disarm		
Sun Roof (Limit/Close)	N/A		
Memory Seat 1	N/A		
Memory Seat 2	N/A		
Memory Seat 3	N/A		
Radio 12V	white	+	radio, gray 24 pin plug, pin 24
Radio Ground	brown	-	radio, gray 24 pin plug, pin 12
Radio Ignition	purple	+	radio, gray 24 pin plug, pin 14
Radio Illumination	gray (parking lights), red (dimmer)	+,-	radio, gray 24 pin plug, pins 13 and 1
Factory Amp Turn-on	white	+	radio, gray 24 pin plug, pin 17
Power Antenna	black	+	radio, gray 3 pin plug, pin 3
Left Front Speaker (+/-)	lt. green - pink	+,-	radio, gray 24 pin plug, pins 23 and 22
Right Front Speaker (+/-)	gray - red	+,-	radio, gray 24 pin plug, pins 19 and 18
Left Rear Speaker (+/-)	yellow - brown	+,-	radio, gray 24 pin plug, pins 11 and 10 or amplifier
Right Rear Speaker (+/-)	blue - orange	+,-	radio, gray 24 pin plug, pins 7 and 6 or amplifier
Center Channel (+/-)	N/A		
Subwoofer (+/-)	gray - lt. blue	+,-	amplifier above the passenger kick
Aux. Audio Input Left (+/-)	red - black (common)	+,-	radio, gray 12 pin plug, pins 7 and 1
Aux. Audio Input Right (+/-)	white - black (common)	+,-	radio, gray 12 pin plug, pins 8 and 1
RSE Video (+/-)	N/A		
RSE Audio Left (+/-)	N/A		
RSE Audio Right (+/-)	N/A		
Satellite Radio 12 Volts	white	+	XM Receiver, white 14 pin plug, pin 1
Satellite Radio Ground	black	-	XM Receiver, white 14 pin plug, pin 11
Satellite Radio Ignition	lt. blue	+	XM Receiver, white 14 pin plug, pin 2
Satellite Radio Antenna	(coaxial cable)		
Satellite Audio Left (+/-)	black - red	+,-	XM Receiver, white 14 pin plug, pins 6 and 14
Satellite Audio Right (+/-)	green - white	+,-	XM Receiver, white 14 pin plug, pins 5 and 13

Copyright © 2007 Directed Electronics. All Rights Reserved. DirectWire and its vehicle information are for the sole use of authorized Directed Electronics personnel and its participating dealers and distributors. The information contained on these pages may contain confidential and privileged information. Any unauthorized review, use, disclosure or distribution is prohibited.

What Fits

Item	Size	Depth	Location
Headunit	irregular		center of dash
Left Front Speaker			left front door
Left Front Tweeter			left front door
Right Front Speaker			right front door
Right Front Tweeter			right front door
Left Rear Speaker			left rear deck
Left Rear Tweeter	N/A		
Right Rear Speaker			right rear deck
Right Rear Tweeter	N/A		
Center Channel	N/A		
Subwoofer			center of rear deck
Left Front Headrest			
Right Front Headrest			
Left Right Headrest			
Right Rear Headrest			
Satellite Radio Tuner			passenger side of the trunk

Smart Starter Kill Relay

Relay Type:	n/a
Part #:	n/a
OE Relay Part #:	
Location:	n/a

Notes:
n/a

Alternate Part Notes:
n/a

Immobilizer Bypass Module

Required:	Yes
Type:	Transponder
Part #:	XK05
Alternate Part #'s:	20402, 29402, 556UW, PKH34

Notes:
Standard on all models. When using the XK05, it needs to be programmed with the PKH4 firmware.

Additional Wiring Notes

Item	Note
Factory Alarm Arm	Meter this wire while turning the key in the driver door key cylinder.
Key Sense	Also found at the MICU, lt. green 20 pin plug, pin 18. The MICU (Multiplex Integrated Control Unit) is attached to the back of the driver fuse box, under the driver side dash.
Parking Lights (-)	Also found at the MICU, lt. green 24 pin plug, pin 7. The MICU (Multiplex Integrated Control Unit) is attached to the back of the driver fuse box, under the driver side dash.
Headlight	Also found at the MICU, lt. green 24 pin plug, pin 8. The MICU (Multiplex Integrated Control Unit) is attached to the back of the driver fuse box, under the driver side dash.
AutoLights	Also found at the MICU, lt. green 24 pin plug, pin 6. The MICU (Multiplex Integrated Control Unit) is attached to the back of the driver fuse box, under the driver side dash. Trigger a ground to this wire to turn off autolights.
Data Bus	The Immobilizer Module is around the ignition key switch.
Can Bus High	The Immobilizer Module is around the ignition key switch. Also found at the driver fuse box, rear, 20 pin plug, pin 6.
Can Bus Low	The Immobilizer Module is around the ignition key switch. Also found at the driver fuse box, rear, 20 pin plug, pin 5.
Factory Alarm Disarm	Meter these wires while turning the key in the driver door key cylinder. Brown is the driver door key cylinder unlock wire and white is the door unlock detection wire. Use both wires and diode isolate each.
Brake Wire	Also found in the driver kick, blue 8 pin plug, pin 1.
Hazards	Also found at the MICU, lt. green 20 pin plug, pin 17. The MICU (Multiplex Integrated Control Unit) is attached to the back of the driver fuse box, under the driver side dash.
Radio Illumination	These wires are only on vehicles with 1 CD disc player. On vehicles with 6 CD disc changer, the illumination is CAN data bus controlled.
Aux. Audio Input Left (+/-)	On vehicles with 6 CD disc changer, they are in a gray 20 pin plug, pins 13 and 3.
Aux. Audio Input Right (+/-)	On vehicles with 6 CD disc changer, they are in a gray 20 pin plug, pins 14 and 3.
Tachometer	On vehicles with active noise control, can also use yellow at the radio, gray 16 pin plug, pin 15.
Left Front Speaker (+/-)	On vehicles with amplifier, the speaker wires are green - purple at the amplifier above the passenger kick.
Right Front Speaker (+/-)	On vehicles with amplifier, the speaker wires are pink - white at the amplifier above the passenger kick.
Satellite Radio 12 Volts	The XM Receiver is in the passenger side of the trunk.
Dome Supervision	Also found in the driver kick, white 4 pin plug, pin 2 or white 20 pin plug, pin 12.
Horn Trigger	Also found at the MICU, lt. green 20 pin plug, pin 12. The MICU (Multiplex Integrated Control Unit) is attached to the back of the driver fuse box, under the driver side dash.
Wipers	Also found at the MICU, lt. green 24 pin plug, pins 15 (L) and 16 (H). The MICU (Multiplex Integrated Control Unit) is attached to the back of the driver fuse box, under the driver side dash.
Right Front Door Trigger	On some models, it is at the passenger fuse box, 16 pin plug, pin 15.
Right Rear Door Trigger	On some models, it is at the passenger fuse box, 16 pin plug, pin 14.