

## 2013 Hyundai Veloster



## Wiring Information

Item	Wire Color	Polarity	Wire Location
<b>12 Volts</b>	green (40A)	+	ignition switch, white 6 pin plug, pin 1
<b>Second 12 Volts</b>	red (40A)	+	ignition switch, white 6 pin plug, pin 5
<b>Starter</b>	white	+	ignition switch, white 6 pin plug, pin 3
<b>Second Starter</b>	N/A		
<b>Ignition</b>	black	+	ignition switch, white 6 pin plug, pin 4
<b>Second Ignition</b>	N/A		
<b>Third Ignition</b>	N/A		
<b>Accessory</b>	orange	+	ignition switch, white 6 pin plug, pin 2
<b>Second Accessory</b>	blue	+	ignition switch, white 6 pin plug, pin 6
<b>Third Accessory</b>	N/A		
<b>Key Sense</b>	white	-	ignition key switch, white 6 pin plug, pin 3
<b>Data Bus</b>	blue (EMS COM immobilizer data)	data	driver kick, white 55 pin plug, pin 10
<b>Can Bus High</b>	white (C-CAN)	data	data link connector, black 16 pin plug, pin 6
<b>Can Bus Low</b>	yellow (C-CAN)	data	data link connector, black 16 pin plug, pin 14
<b>Can Bus Sw</b>	N/A		
<b>Power Lock</b>	pink/black	-	dash fuse box, bottom, yellow 32 pin plug (B), pin 7
<b>Power Unlock</b>	yellow/black	-	dash fuse box, bottom, yellow 32 pin plug (B), pin 11
<b>Lock Motor</b>	brown/orange	5 wire	dash fuse box, white 38 pin plug (K), pin 36
<b>Unlock Motor</b>	green/white	5 wire	driver kick, door harness
<b>Disarm Defeat</b>	green	5 wire	dash fuse box, white 38 pin plug (K), pin 26
<b>Parking Lights (+)</b>	red (L), brown/black (R)	+	dash fuse box, white 38 pin plug (K), pins 34 and 24
<b>Parking Lights (-)</b>	pink	-	headlight switch, white 13 pin plug, pin 2
<b>Hazards</b>	red	-	dash fuse box, rear, white 24 pin plug (C), pin 9
<b>Turn Signal (Left)</b>	blue/orange (F); blue/orange (R)	+	dash fuse box, wht 16 pin plug (N), pin 3; wht 38 pin plug (K), pin 3
<b>Turn Signal (Right)</b>	red/orange (F); red/orange (R)	+	dash fuse box, wht 16 pin plug (N), pin 13; wht 38 pin plug (K), pin 6

*Wiring Information (Continued)*

Item	Wire Color	Polarity	Wire Location
<b>Headlight</b>	yellow	-	headlight switch, white 13 pin plug, pin 4
<b>AutoLights</b>	pink (interrupt to turn off autolights)	-	headlight switch, white 13 pin plug, pin 3
<b>Reverse Light</b>	blue	+	dash fuse box, white 38 pin plug (K), pin 7
<b>Left Front Door Trigger</b>	brown	-	dash fuse box, bottom, yellow 32 pin plug (B), pin 18
<b>Right Front Door Trigger</b>	blue	-	dash fuse box, bottom, yel 32 pin plug (B), pin 17
<b>Left Rear Door Trigger</b>	N/A		
<b>Right Rear Door Trigger</b>	orange	-	dash fuse box, bottom, yel 32 pin plug (B), pin 19
<b>Dome Supervision</b>	yellow	-	dash fuse box, rear, white 40 pin plug (D), pin 23
<b>Trunk/Hatch Pin</b>	green	-	dash fuse box, bottom, yellow 32 pin plug (B), pin 5
<b>Rear Glass Pin</b>	N/A		
<b>Hood Pin</b>	green	-	dash fuse box, bottom, blue or white 24 pin plug (A), pin 12
<b>Trunk Hatch/Release</b>	brown (rear handle switch)	-	driver kick, white 56 pin plug, pin 3
<b>Trunk Release Motor</b>	red	+	dash fuse box, white 38 pin plug (K), pin 17
<b>Fuel Door Release</b>	N/A		
<b>Power Sliding Door (Left)</b>	N/A		
<b>Power Sliding Door (Right)</b>	N/A		
<b>Factory Alarm Arm</b>	white (key lock), orange (lock/unlock detection)	- and open	dash fuse box, bottom, yellow 32 pin plug (B), pins 3 and 2
<b>Factory Alarm Disarm</b>	pink/blk (key unlock), orange (lock/unlock detect)	both -	dash fuse box, bottom, yellow 32 pin plug (B), pins 4 and 2
<b>Disarm No Unlock</b>	see factory alarm disarm		
<b>Trunk Alarm Shunt</b>	N/A		
<b>Tachometer</b>	blue, black, white, or red (except 1.6L Turbo A/T)	ac	top front of engine, black 12 pin plug, pin 1, 3, 5, or 7
<b>Wait to Start</b>	N/A		
<b>Neutral Safety</b>	N/A		
<b>Clutch Pedal</b>	gray/black	+	clutch switch, white 2 pin plug, pin 1
<b>Fuel Pump</b>	gray	+	driver kick, white 56 pin plug, pin 19
<b>Rear Defroster</b>	black	- latched	dash fuse box, bottom, blue or white 24 pin plug (A), pin 7
<b>Mirror Defroster</b>	same as rear defroster		
<b>Left Front Heated Seat</b>	yellow	+	driver seat warmer switch, black 12 pin plug, pin 2
<b>Right Front Heated Seat</b>	yellow	+	passenger seat warmer switch, white 12 pin plug, pin 2

*Wiring Information (Continued)*

Item	Wire Color	Polarity	Wire Location
<b>Speed Sense</b>	pink	4-Pulse	data link conn, blk 16 pin plug, pin 3 or radio, wht 18 pin plug, pin 18
<b>Brake Wire</b>	pink	+	driver kick, white 55 pin plug, pin 43
<b>Parking Brake</b>	blue	-	driver kick, white 56 pin plug, pin 17
<b>Horn Trigger</b>	white/orange	-	driver kick, white 55 pin plug, pin 44
<b>Wipers</b>	white (L), yellow (H), blue (ignition)	+	wiper switch, white 14 pin plug, pins 3, 9, and 10
<b>Left Front Window (Up/Down)</b>	yellow - orange/black (without safety pwr window)	A	power window main switch, white 16 pin plug, pins 8 and 7
<b>Right Front Window (Up/Down)</b>	brown - white	A	driver kick, door harness
<b>Left Rear Window (Up/Down)</b>	N/A		
<b>Right Rear Window (Up/Down)</b>	green - pink	A	driver kick, door harness
<b>Sun Roof (Open/Close)</b>	orange/black - gray (function with ign on only)	-	sunroof switch, black or white 6 pin plug, pins 2 and 3
<b>Sun Roof (Limit/Close)</b>	N/A		
<b>Memory Seat 1</b>	N/A		
<b>Memory Seat 2</b>	N/A		
<b>Memory Seat 3</b>	N/A		
<b>Radio 12V</b>	red	+	radio, white 24 pin plug, pin 12
<b>Radio Ground</b>	black	-	radio, white 24 pin plug, pin 24
<b>Radio Ignition</b>	blue	+	radio, white 24 pin plug, pin 11
<b>Radio Illumination</b>	blue (parking lights), gray (dimmer)	+,-	radio, white 24 pin plug, pins 7 and 6
<b>Factory Amp Turn-on</b>	(M-CAN)		
<b>Power Antenna</b>	N/A		
<b>Left Front Speaker (+/-)</b>	orange - blue/black	+,-	radio, white 18 pin plug, pins 1 and 4
<b>Right Front Speaker (+/-)</b>	blue/orange - yellow/black	+,-	radio, white 18 pin plug, pins 3 and 2
<b>Left Rear Speaker (+/-)</b>	pink - green	+,-	radio, white 18 pin plug, pins 12 and 13
<b>Right Rear Speaker (+/-)</b>	brown - white	+,-	radio, white 18 pin plug, pins 10 and 11
<b>Center Channel (+/-)</b>	blue/orange - green/black	+,-	amplifier under passenger seat, white 16 pin plug, pins 7 and 15
<b>Subwoofer (+/-)</b>	green/orange - blue (1); brown - white (2)	+,-	amplifier under passenger seat, wht 26 pin plug, pins 12-25; 13-26
<b>Aux. Audio Input Left (+/-)</b>	red - orange	+,-	radio, white 24 pin plug, pins 10 and 9
<b>Aux. Audio Input Right (+/-)</b>	blue - orange	+,-	radio, white 24 pin plug, pins 8 and 9
<b>RSE Video (+/-)</b>	orange - black/orange (rear view camera)	+,-	radio, white 24 pin plug, pins 12 and 24
<b>RSE Audio Left (+/-)</b>	N/A		
<b>RSE Audio Right (+/-)</b>	N/A		
<b>Satellite Radio 12 Volts</b>	N/A		
<b>Satellite Radio Ground</b>	N/A		
<b>Satellite Radio Ignition</b>	N/A		

Copyright © 2011 Directed Electronics. All Rights Reserved. DirectWire and its vehicle information are for the sole use of authorized Directed Electronics personnel and its participating dealers and distributors. The information contained on these pages may contain confidential and privileged information. Any unauthorized review, use, disclosure or distribution is prohibited.

DirectWire Vehicle Information - 2/3/2014 12:07:02 AM			
Satellite Radio Antenna	N/A		
Satellite Audio Left (+/-)	N/A		
Satellite Audio Right (+/-)	N/A		

Copyright © 2011 Directed Electronics. All Rights Reserved. DirectWire and its vehicle information are for the sole use of authorized Directed Electronics personnel and its participating dealers and distributors. The information contained on these pages may contain confidential and privileged information. Any unauthorized review, use, disclosure or distribution is prohibited.

*What Fits*

Item	Size	Depth	Location
<b>Headunit</b>	irregular		center of dash
<b>Left Front Speaker</b>	6.5	3.4	left front door
<b>Left Front Tweeter</b>	1	1	left front door
<b>Right Front Speaker</b>	6.5	3.4	right front door
<b>Right Front Tweeter</b>	1	1	right front door
<b>Left Rear Speaker</b>	6.5	3.8	left rear side panel
<b>Left Rear Tweeter</b>	N/A		
<b>Right Rear Speaker</b>	6.5	3.8	right rear door
<b>Right Rear Tweeter</b>	N/A		
<b>Center Channel</b>			top center of dash
<b>Subwoofer</b>	8		left rear quarter panel
<b>Left Front Headrest</b>			
<b>Right Front Headrest</b>			
<b>Left Right Headrest</b>			
<b>Right Rear Headrest</b>			
<b>Satellite Radio Tuner</b>	(built into radio)		

*Additional Wiring Notes*

Item	Note
<b>Left Front Speaker (+/-)</b>	On models with amplifier, the speaker wires are orange - blue/black (woofer); pink/black - orange/black (tweeter) at the amplifier under passenger seat, white 12 pin plug, pins 6 and 12; 4 and 10.
<b>Aux. Audio Input Right (+/-)</b>	The aux. video input wires are gray - black/orange at the radio, white 18 pin plug, pins 17 and 16.
<b>Factory Alarm Arm</b>	See Tech Doc 1300 for wiring information.
<b>Factory Alarm Disarm</b>	See Tech Doc 1300 for wiring information.
<b>Right Front Speaker (+/-)</b>	On models with amplifier, the speaker wires are blue/orange - yellow/black (woofer); white/orange - green/orange (tweeter) at the amplifier under passenger seat, white 12 pin plug, pins 5 and 11; 3 and 9.
<b>Left Rear Speaker (+/-)</b>	On models with amplifier, the speaker wires are pink - green at the amplifier under passenger seat, white 12 pin plug, pins 2 and 8.
<b>Right Rear Speaker (+/-)</b>	On models with amplifier, the speaker wires are brown - white at the amplifier under passenger seat, white 12 pin plug, pins 1 and 7.
<b>Left Front Window (Up/Down)</b>	On models with safety power window, the window motor is part of the window module, not allowing access to the motor wires.
<b>Data Bus</b>	The immobilizer light is orange (-) at the instrument cluster, white 40 pin plug, pin 8.
<b>Can Bus High</b>	The B-CAN high is white/orange at the dash fuse box, rear, white 24 pin plug (C), pin 5.
<b>Can Bus Low</b>	The B-CAN low is yellow/orange at the dash fuse box, rear, white 24 pin plug (C), pin 6.
<b>Power Unlock</b>	To unlock the driver door only, use yellow/orange (-) at the dash fuse box, rear, white 40 pin plug (D), pin 6.
<b>Tachometer</b>	On 1.6L Turbo A/T models, the fuel injectors are orange, red, blue, or yellow.