
# 2012 Porsche Cayenne





## Wiring Information

| Item                   | Wire Color                                                                  | Pol<br>V | arit Wire Location                                                    |
|------------------------|-----------------------------------------------------------------------------|----------|-----------------------------------------------------------------------|
| 12 Volts               | red/white (30A)                                                             | +        | Front BCM under driver dash, 4 pin plug (A), pin                      |
| Second 12 Volts        | red/yellow (30A)                                                            | +        | Front BCM under driver dash, 4 pin plug (A), pin                      |
| Starter                | black (for starter kill only)                                               | +        | Front BCM under driver dash, 42 pin plug (C), pin 38                  |
| Second Starter         | (electronic ign sw interface needed for rem start)                          |          |                                                                       |
| Ignition               | white or black (for ignition sense only)                                    | +        | Front BCM under driver dash, 42 pin plug (D), pin 14                  |
| Second Ignition        | N/A                                                                         |          |                                                                       |
| Third Ignition         | N/A                                                                         |          |                                                                       |
| Accessory              | N/A                                                                         |          |                                                                       |
| Second<br>Accessory    | N/A                                                                         |          |                                                                       |
| Third Accessory        | N/A                                                                         |          |                                                                       |
| Key Sense              | N/A                                                                         |          |                                                                       |
| Data Bus               | gray/brown (electronic ignition LIN)                                        | data     | Front BCM under driver dash, 42 pin plug (C), pin 31                  |
| Can Bus High           | orange/green (comfort CAN)                                                  | data     | Front BCM under driver dash, 42 pin plug (C), pin 42                  |
| Can Bus Low            | orange/brown (comfort CAN)                                                  | data     | Front BCM under driver dash, 42 pin plug (C), pin 34                  |
| Can Bus Sw             | N/A                                                                         |          |                                                                       |
| Power Lock             | (use factory alarm arm)                                                     |          |                                                                       |
| Power Unlock           | (use factory alarm disarm)                                                  |          |                                                                       |
| Lock Motor             | purple/green                                                                | 5 wire   | Driver Door Control Unit, 20 pin plug, pin 13                         |
| Unlock Motor           | blue/green                                                                  | 5 wire   | Driver Door Control Unit, 20 pin plug, pin 11                         |
| Disarm Defeat          | blue/green                                                                  | 5 wire   | Passenger Door Control Unit, 20 pin plug, pin 11                      |
| Parking Lights (+)     | blk/bu (LF), gry/rd (RF); gry/ye (LR), red/wh (RR)                          | +        | Frnt BCM, 42P plg (D), pins 26, 4; Rear BCM, 42P plg (B), pins 4, 26  |
| Parking Lights (-)     | (LIN bus)                                                                   |          |                                                                       |
| Hazards                | purple                                                                      | -        | Front BCM under driver dash, 42 pin plug (C), pin 16                  |
| Turn Signal<br>(Left)  | black/white (F); green/white or black/white (R)                             | +        | Frt BCM under dr dash, 42 pin plg (C), pin 24; 42 pin plg (D), pin 5  |
| Turn Signal<br>(Right) | black/green (F); black/green (R)  IT Directed Electronics. All Rights Reser | +        | Frt BCM under dr dash, 42 pin plg (C), pin 25; 42 pin plg (D), pin 25 |



### Wiring Information (Continued)

| Item                       | Wire Color                        | Polarity   | Wire Location                                                        |
|----------------------------|-----------------------------------|------------|----------------------------------------------------------------------|
| Headlight                  | yellow                            |            | headlight sw or Front BCM under driver dash, 42 pin plug (D), pin 18 |
| AutoLights                 | (LIN bus)                         |            |                                                                      |
| Reverse Light              | blue/black                        | +          | Rear BCM in right rear quarter panel, 42 pin plug (B), pin 2         |
| Left Front Door Trigger    | red/blue                          | -          | Driver Door Control Unit, 20 pin plug, pin 5                         |
| Right Front Door Trigger   | red/blue                          | -          | Passenger Door Control Unit, 20 pin plug, pin 5                      |
| Left Rear Door Trigger     | red/blue                          | -          | Left Rear Door Control Unit, 20 pin plug, pin 5                      |
| Right Rear Door Trigger    | red/blue                          | -          | Right Rear Door Control Unit, 20 pin plug, pin 5                     |
| Dome Supervision           | (LIN bus)                         |            |                                                                      |
| Trunk/Hatch Pin            | gray/blue                         | -          | Rear BCM in right rear quarter panel, 42 pin plug (B), pin 39        |
| Rear Glass Pin             | N/A                               |            |                                                                      |
| Hood Pin                   | yellow/black                      | -          | Front BCM under driver dash, 42 pin plug (D), pin 38                 |
| Trunk Hatch/Release        | yellow/blue (rear handle switch)  | -          | Rear BCM in right rear quarter panel, 42 pin plug (A), pin 17        |
| Trunk Release Motor        | brown/yellow                      | 5 wire     | Rear BCM in right rear quarter panel, 12 pin plug (C), pin 4         |
| Fuel Door Release          | red/brown (unlock)                | 5 wire     | Front BCM under driver dash, 12 pin plug (B), pin 3                  |
| Power Sliding Door (Left)  | N/A                               |            |                                                                      |
| Power Sliding Door (Right) | N/A                               |            |                                                                      |
| Factory Alarm Arm          | blue/white (driver door key lock) | -          | Driver Door Control Unit, 20 pin plug, pin 1                         |
| Factory Alarm Disarm       | (same as factory alarm arm)       | - 250 ohms |                                                                      |
| Disarm No Unlock           | (see factory alarm disarm)        |            |                                                                      |
| Trunk Alarm Shunt          | N/A                               |            |                                                                      |
| Tachometer                 | blue/stripe or brown/stripe       | ac         | any fuel injector, 2 pin plug, pin 1 (V6); pin 2 (V8)                |
| Wait to Start              | N/A                               |            |                                                                      |
| Neutral Safety             | N/A                               |            |                                                                      |
| Clutch Pedal               | yellow/purple                     |            | clutch switch, 5 pin plug, pin 4                                     |
| Fuel Pump                  | red/yellow                        | +          | driver kick, harness to rear                                         |
| Rear Defroster             | gray/white                        | + latched  | Rear BCM in right rear quarter panel, 42 pin plug (A), pin 36        |
| Mirror Defroster           | (comfort CAN)                     |            |                                                                      |
| Left Front Heated Seat     | blue/yellow                       | 5 wire     | A/C Control Unit, 3 pin plug, pin 2                                  |
| Right Front Heated Seat    | blue/white                        | 5 wire     | A/C Control Unit, 3 pin plug, pin 3                                  |

### Wiring Information (Continued)

| Item                            | Wire Color                                            | Pol<br>y | arit Wire Location                                                         |
|---------------------------------|-------------------------------------------------------|----------|----------------------------------------------------------------------------|
| Speed Sense                     | (wheel speed sensor)                                  |          |                                                                            |
| Brake Wire                      | black/red                                             | +        | pass kick or Rear BCM in right rear qrtr panel,<br>42 pin plug (B), pin 27 |
| Parking Brake                   | (electric parking brake)                              |          |                                                                            |
| Horn Trigger                    | white/purple                                          | +        | Front BCM under driver dash, 42 pin plug (C), pin 36                       |
| Wipers                          | (LIN bus)                                             |          |                                                                            |
| Left Front Window<br>(Up/Down)  | (use factory alarm arm/disarm)                        |          |                                                                            |
| Right Front Window<br>(Up/Down) | (see left front window)                               |          |                                                                            |
| Left Rear Window<br>(Up/Down)   | (see left front window)                               |          |                                                                            |
| Right Rear Window<br>(Up/Down)  | (see left front window)                               |          |                                                                            |
| Sun Roof<br>(Open/Close)        | (LIN bus)                                             |          |                                                                            |
| Sun Roof<br>(Limit/Close)       | N/A                                                   |          |                                                                            |
| Memory Seat 1                   |                                                       |          |                                                                            |
| Memory Seat 2                   |                                                       |          |                                                                            |
| Memory Seat 3                   |                                                       |          |                                                                            |
| Radio 12V                       | red/yellow                                            | +        | radio, 16 pin plug, pin 15                                                 |
| Radio Ground                    | brown                                                 | -        | radio, 16 pin plug, pin 12                                                 |
| Radio Ignition                  | (MMI CAN)                                             |          |                                                                            |
| Radio Illumination              | N/A                                                   |          |                                                                            |
| Factory Amp Turn-on             | black/red (without Bose); (MOST bus, with Bose)       | +        | radio, 12 pin plug (C), pin 4                                              |
| Power Antenna                   | white                                                 | +        | radio, 16 pin plug, pin 14                                                 |
| Left Front Speaker (+/-)        | white - white/black                                   | +,-      | radio, 8 pin plug, pins 3 - 7                                              |
| Right Front Speaker (+/-)       | gray - gray/black                                     | +,-      | radio, 8 pin plug, pins 2 - 6                                              |
| Left Rear Speaker<br>(+/-)      | green - green/black                                   | +,-      | radio, 8 pin plug, pins 4 - 8                                              |
| Right Rear Speaker (+/-)        | purple - purple/black                                 | +,-      | radio, 8 pin plug, pins 1 - 5                                              |
| Center Channel (+/-)            | blue - blue/black                                     | +,-      | amp in RR qrtr panel, 20 pin plug, pins 4-14, or 32 pin plg, pins 8-20     |
| Subwoofer (+/-)                 | yellow/red - yellow/brn (preamp);<br>red/wht(turn-on) | +,-; +   | amplifier in RR quarter panel, 32 pin plug, pins 10 - 22; pin 23           |
| Aux. Audio Input Left (+/-)     | yellow - gray or gray - yellow                        | +,-      | radio, 12 pin plug (D), pins 2 - 8                                         |
| Aux. Audio Input<br>Right (+/-) | green - gray or green - yellow                        | +,-      | radio, 12 pin plug (D), pins 7 - 8                                         |
| RSE Video (+/-)                 | white - black (television tuner)                      | +,-      | radio, 12 pin plug (C), pins 10 - 11                                       |
| RSE Audio Left (+/-)            | (MOST bus) (television tuner)                         |          |                                                                            |
| . , ,                           |                                                       | d Dina   | actWire and its vahicle information are f                                  |

| REEAWIREIZEHICHE            | Information busy tolevish ting, AM |  |
|-----------------------------|------------------------------------|--|
| Satellite Radio 12<br>Volts | (built into radio)                 |  |
| Satellite Radio<br>Ground   | N/A                                |  |
| Satellite Radio<br>Ignition | N/A                                |  |
| Satellite Radio<br>Antenna  | N/A                                |  |
| Satellite Audio Left (+/-)  | N/A                                |  |
| Satellite Audio Right (+/-) | N/A                                |  |

#### What Fits

| It a ma               | 0:                 | Danith | Landan                             |
|-----------------------|--------------------|--------|------------------------------------|
| Item                  | Size               | Depth  | Location                           |
| Headunit              | irregular          |        | center of dash                     |
| Left Front Speaker    |                    |        | left front door                    |
| Left Front Tweeter    |                    |        | left front door; left front dash   |
| Right Front Speaker   |                    |        | right front door                   |
| Right Front Tweeter   |                    |        | right front door; right front dash |
| Left Rear Speaker     |                    |        | left rear door                     |
| Left Rear Tweeter     |                    |        | left rear door; left rear pillar   |
| Right Rear Speaker    |                    |        | right rear door                    |
| Right Rear Tweeter    |                    |        | right rear door; right rear pillar |
| Center Channel        |                    |        | top center of dash                 |
| Subwoofer             |                    |        |                                    |
| Left Front Headrest   |                    |        |                                    |
| Right Front Headrest  |                    |        |                                    |
| Left Right Headrest   |                    |        |                                    |
| Right Rear Headrest   |                    |        |                                    |
| Satellite Radio Tuner | (built into radio) |        |                                    |

#### DirectWire Vehicle Information - 1/9/2014 6:16:37 AM

### Additional Wiring Notes

| Item                      | Note                                                                                                                                                                                                                                                                                                                        |
|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Left Front Speaker (+/-)  | The woofer wires are white/red - white/brown at the amplifier in RR quarter panel, 20 pin plug, pins 5 - 15 (without Bose), or 32 pin plug, pins 3 - 15 (with Bose). The midrange/tweeter wires are white - white/black at the amplifier, 20 pin plug, pins 12 - 2 (without Bose), or 32 pin plug, pins 7 - 19 (with Bose). |
| Right Front Speaker (+/-) | The woofer wires are gray/red - gray/brown at the amplifier in RR quarter panel, 20 pin plug, pins 10 - 20 (without Bose), or 32 pin plug, pins 5 - 17 (with Bose). The midrange/tweeter wires are gray - gray/black at the amplifier, 20 pin plug, pins 13 - 3 (without Bose), or 32 pin plug, pins 18 - 6 (with Bose).    |
| Left Rear Speaker (+/-)   | The woofer/tweeter wires are green - green/black at the amplifier in RR quarter panel, 20 pin plug, pins 6 - 16 (without Bose), or 32 pin plug, pins 12 - 11 (with Bose).                                                                                                                                                   |
| Right Rear Speaker (+/-)  | The woofer/tweeter wires are purple - purple/black at the amplifier in RR quarter panel, 20 pin plug, pins 17 - 7 (without Bose), or 32 pin plug, pins 13 - 14 (with Bose). The surround speakers are paralleled, and the wires are yellow - blue/yellow at the amplifier, 32 pin plug, pins 21 - 9 (with Bose).            |