

Wiring Information

Item	Wire Color	Polarity	Wire Location	
12 Volts				
Second 12 Volts				
Starter	brown	+	ignition switch wiring harness	
Second Starter				
Ignition	orange	+	ignition switch wiring harness	
Second Ignition				
Third Ignition				
Accessory				
Second Accessory				
Third Accessory				
Key Sense				
Data Bus				
Can Bus High				
Can Bus Low				
Can Bus Sw				
Power Lock	white/brown	-	fuse box, black-red 40 pin connector, pos. 34	
Power Unlock	It. blue/blue	-	fuse box, black-red 40 pin connector, pos. 24	
Lock Motor				
Unlock Motor				
Disarm Defeat				
Parking Lights (+)				
Parking Lights (-)				
Hazards				
Turn Signal (Left)	pink	+	fuse box, black-red 40 pin connector, pos. 3	
Turn Signal (Right)	green/red	+	fuse box, black-red 40 pin connector, pos. 12	

Wiring Information (Continued)

Item	Wire Color	Polarity	Wire Location	
Headlight				
AutoLights				
Reverse Light				
Left Front Door Trigger	lt. blue/yellow		fuse box, black-red 40 pin connector, pos. 21	
Right Front Door Trigger				
Left Rear Door Trigger				
Right Rear Door Trigger				
Dome Supervision				
Trunk/Hatch Pin	red/green		fuse box, black-red 40 pin connector, pos. 36	
Rear Glass Pin				
Hood Pin				
Trunk Hatch/Release				
Trunk Release Motor				
Fuel Door Release				
Power Sliding Door (Left)				
Power Sliding Door (Right)				
Factory Alarm Arm				
Factory Alarm Disarm				
Disarm No Unlock				
Trunk Alarm Shunt				
Tachometer				
Wait to Start				
Neutral Safety				
Clutch Pedal				
Fuel Pump	orange	+	ignition switch wiring harness	
Rear Defroster				
Mirror Defroster				
Left Front Heated Seat				
Right Front Heated Seat				

## Wiring Information (Continued)

Item	Wire Color	Polarity	Wire Location
Speed Sense			
Brake Wire			
Parking Brake			
Horn Trigger			
Wipers			
Left Front Window (Up/Down)	yellow/green		control switch on center console, under car radio predisposition
Right Front Window (Up/Down)	white/brown		control switch on center console, under car radio predisposition
Left Rear Window (Up/Down)			
Right Rear Window (Up/Down)			
Sun Roof (Open/Close)			
Sun Roof (Limit/Close)			
Memory Seat 1			
Memory Seat 2			
Memory Seat 3			
Radio 12V			
Radio Ground			
Radio Ignition			
Radio Illumination			
Factory Amp Turn-on			
Power Antenna			
Left Front Speaker (+/-)			
Right Front Speaker (+/-)			
Left Rear Speaker (+/-)			
Right Rear Speaker (+/-)			
Center Channel (+/-)			
Subwoofer (+/-)			
Aux. Audio Input Left (+/-)			
Aux. Audio Input Right (+/-)			
RSE Video (+/-)			
RSE Audio Left (+/-)			
RSE Audio Right (+/-)			
Satellite Radio 12 Volts			
Satellite Radio Ground			
Satellite Radio Ignition			
Satellite Radio Antenna			
Satellite Audio Left (+/-)			
Satellite Audio Right (+/-)			

## DirectWire Vehicle Information - 7/2/2012 2:53:21 AM

What Fits

Item	Size	Depth	Location
Headunit			
Left Front Speaker			
Left Front Tweeter			
Right Front Speaker			
Right Front Tweeter			
Left Rear Speaker			
Left Rear Tweeter			
Right Rear Speaker			
Right Rear Tweeter			
Center Channel			
Subwoofer			
Left Front Headrest			
Right Front Headrest			
Left Right Headrest			
Right Rear Headrest			
Satellite Radio Tuner			