

## 2012 Mercedes Benz E Class Sedan (W212)



## Wiring Information

Item	Wire Color	Polarity	Wire Location
<b>12 Volts</b>	red (100A)	+	trunk fuse box, 1 pin plug, pin 1
<b>Second 12 Volts</b>	N/A		
<b>Starter</b>	purple/white or red/green (for starter kill only)	+	underhood fuse box, 7 pin plug (3M), pin 4
<b>Second Starter</b>	N/A		
<b>Ignition</b>	black/blue (for ignition sense only)	+	trunk fuse box, 52 pin plug (9I), pin 18
<b>Second Ignition</b>	N/A		
<b>Third Ignition</b>	N/A		
<b>Accessory</b>	N/A		
<b>Second Accessory</b>	N/A		
<b>Third Accessory</b>	N/A		
<b>Key Sense</b>	N/A		
<b>Data Bus</b>	N/A		
<b>Can Bus High</b>	brown/red	data	driver kick or trunk fuse box, 52 pin plug (9I), pin 30
<b>Can Bus Low</b>	brown	data	driver kick or trunk fuse box, 52 pin plug (9I), pin 31
<b>Can Bus Sw</b>	N/A		
<b>Power Lock</b>	gray/blue	-	Left Front Door Module, plug (C5), pin 4
<b>Power Unlock</b>	(same as power lock)	- resistor	
<b>Lock Motor</b>	green/black	5 wire	Left Front Door Module, plug (C7), pin 7
<b>Unlock Motor</b>	green	5 wire	Left Front Door Module, plug (C7), pin 6
<b>Disarm Defeat</b>	green	5 wire	Right Front Door Module, plug (C7), pin 6
<b>Parking Lights (+)</b>	gry/bk (LF), gry/rd (RF); gry/bk (LR), gry/rd (RR)	+	undrhd FB, 18P plg(21M), pins 13, 14; trnk FB, 28P plg(5H),pins17,16
<b>Parking Lights (-)</b>	(LIN bus)		
<b>Hazards</b>	(LIN bus)		
<b>Turn Signal (Left)</b>	black/white (F); black/white (R)	+	underhood FB, 18P plg (20M), pin 18; trunk FB, 28P plg (5H), pin 25
<b>Turn Signal (Right)</b>	black/green (F); black/green (R)	+	underhood FB, 18P plg (18M), pin 11; trunk FB, 28P plg (5H), pin 15

*Wiring Information (Continued)*

Item	Wire Color	Polarity	Wire Location
<b>Headlight</b>	yellow/black (L); yellow (R) (low beams)	+	underhood FB, 10 pin plug (15M), pin 8; 10 pin plug (14M), pin 2
<b>AutoLights</b>	(LIN bus)		
<b>Reverse Light</b>	gray/blue	+	trunk fuse box, 32 pin plug (6HD), pin 5
<b>Left Front Door Trigger</b>	brown/pink	-	Left Front Door Module, plug (C7), pin 9
<b>Right Front Door Trigger</b>	brown/pink	-	Right Front Door Module, plug (C7), pin 9
<b>Left Rear Door Trigger</b>	purple	-	trunk fuse box, 52 pin plug (9I), pin 4
<b>Right Rear Door Trigger</b>	gray	-	trunk fuse box, 52 pin plug (9I), pin 3
<b>Dome Supervision</b>	(CAN bus, frnt dome lamp); blk/gry(rear dome lamp)	+	overhead control panel, 8 pin plug (C), pin 5
<b>Trunk/Hatch Pin</b>	brown/yellow	-	trunk fuse box, 32 pin plug (6HD), pin 29
<b>Rear Glass Pin</b>	N/A		
<b>Hood Pin</b>	brown/red	-	hood switch or trunk fuse box, 52 pin plug (9I), pin 5
<b>Trunk Hatch/Release</b>	gray (rear handle switch)	-	trunk fuse box, 32 pin plug (6HD), pin 31
<b>Trunk Release Motor</b>	black/white	5 wire	trunk fuse box, 32 pin plug (6HD), pin 3
<b>Fuel Door Release</b>	(unlocks along with doors)		
<b>Power Sliding Door (Left)</b>	N/A		
<b>Power Sliding Door (Right)</b>	N/A		
<b>Factory Alarm Arm</b>	(factory remote only)		
<b>Factory Alarm Disarm</b>	(factory remote only)		
<b>Disarm No Unlock</b>			
<b>Trunk Alarm Shunt</b>	N/A		
<b>Tachometer</b>	white/stripes (V6)	ac	any fuel injector, 2 pin plug, pin 2
<b>Wait to Start</b>	N/A		
<b>Neutral Safety</b>	N/A		
<b>Clutch Pedal</b>	N/A		
<b>Fuel Pump</b>	black/purple	+	underhood fuse box, 5 pin plug (9G), pin 5
<b>Rear Defroster</b>	black	+ latched	trunk fuse box, 1 pin plug (1H), pin 1
<b>Mirror Defroster</b>	(CAN bus)		
<b>Left Front Heated Seat</b>	(LIN bus)		
<b>Right Front Heated Seat</b>	(LIN bus)		

Wiring Information (Continued)

Item	Wire Color	Polarity	Wire Location
<b>Speed Sense</b>	(wheel speed sensor)		
<b>Brake Wire</b>	black/red	+	trunk fuse box, 32 pin plug (6HD), pin 1
<b>Parking Brake</b>	brown/black	-	parking brake switch, 2 pin plug, pin 2
<b>Horn Trigger</b>	black or black/white	+	underhood fuse box, 10 pin plug (15M), pin 9
<b>Wipers</b>	(CAN bus)		
<b>Left Front Window (Up/Down)</b>	(not recommended because of factory auto up/down)		
<b>Right Front Window (Up/Down)</b>	(not recommended because of factory auto up/down)		
<b>Left Rear Window (Up/Down)</b>	(not recommended because of factory auto up/down)		
<b>Right Rear Window (Up/Down)</b>	(not recommended because of factory auto up/down)		
<b>Sun Roof (Open/Close)</b>	(not recommended because of factory auto open/cls)		
<b>Sun Roof (Limit/Close)</b>	N/A		
<b>Memory Seat 1</b>	(LIN bus)		
<b>Memory Seat 2</b>	(LIN bus)		
<b>Memory Seat 3</b>	(LIN bus)		
<b>Radio 12V</b>	red/blue	+	radio, 16 pin plug, pin 15
<b>Radio Ground</b>	brown	-	radio, 16 pin plug, pin 12
<b>Radio Ignition</b>	(CAN bus)		
<b>Radio Illumination</b>	(CAN bus)		
<b>Factory Amp Turn-on</b>	blue/black (MOST wake up)		radio, 16 pin plug, pin 16
<b>Power Antenna</b>	blue (mobile phone on/off)		radio, 16 pin plug, pin 13
<b>Left Front Speaker (+/-)</b>	green - brown/green	+,-	radio, 16 pin plug, pins 3 - 7
<b>Right Front Speaker (+/-)</b>	orange - brown/orange	+,-	radio, 16 pin plug, pins 2 - 6
<b>Left Rear Speaker (+/-)</b>	purple - brown/purple	+,-	radio, 16 pin plug, pins 4 - 8
<b>Right Rear Speaker (+/-)</b>	white - brown/white	+,-	radio, 16 pin plug, pins 1 - 5
<b>Center Channel (+/-)</b>	gray - brown/gray	+,-	amplifier in trunk left side, 32 pin plug, pins 23 - 28
<b>Subwoofer (+/-)</b>	white - brown (preamp); black (amp turn-on)	+,-	amplifier in trunk left side, 32 pin plug, pins 24 - 29; pin 31
<b>Aux. Audio Input Left (+/-)</b>	black - brown	+,-	radio, 12 pin plug, pins 6 - 11, or 4 - 11
<b>Aux. Audio Input Right (+/-)</b>	yellow - brown	+,-	radio, 12 pin plug, pins 12 - 11, or 10 - 11
<b>RSE Video (+/-)</b>			
<b>RSE Audio Left (+/-)</b>	yellow - brown	+,-	radio, 10 pin plug, pins 5 - 10
<b>RSE Audio Right (+/-)</b>	black - brown	+,-	radio, 10 pin plug, pins 9 - 10
<b>Satellite Radio 12 Volts</b>	red/yellow	+	Sat Radio in trunk left side, 4 pin plug, pin 2

Copyright © 2011 Directed Electronics. All Rights Reserved. DirectWire and its vehicle information are for the sole use of authorized Directed Electronics personnel and it's participating dealers and distributors. The information contained on these pages may contain confidential and privileged information. Any unauthorized review, use, disclosure or distribution is prohibited.

DirectWire Vehicle Information - 11/19/2013 5:24:52 AM			
Satellite Radio Ground	brown	-	Sat Radio in trunk left side, 4 pin plug, pin 1
Satellite Radio Ignition	blue/black (MOST wake up)		Sat Radio in trunk left side, 4 pin plug, pin 3
Satellite Radio Antenna	(coaxial cable)		
Satellite Audio Left (+/-)	(MOST bus)		
Satellite Audio Right (+/-)	(MOST bus)		

Copyright © 2011 Directed Electronics. All Rights Reserved. DirectWire and its vehicle information are for the sole use of authorized Directed Electronics personnel and its participating dealers and distributors. The information contained on these pages may contain confidential and privileged information. Any unauthorized review, use, disclosure or distribution is prohibited.

*What Fits*

Item	Size	Depth	Location
<b>Headunit</b>	irregular		center of dash
<b>Left Front Speaker</b>			left front door
<b>Left Front Tweeter</b>			left front door
<b>Right Front Speaker</b>			right front door
<b>Right Front Tweeter</b>			right front door
<b>Left Rear Speaker</b>			left rear door
<b>Left Rear Tweeter</b>			left rear door (twtr); left rear deck (surr)
<b>Right Rear Speaker</b>			right rear door
<b>Right Rear Tweeter</b>			right rear door (twtr); right rear deck (surr)
<b>Center Channel</b>			top center of dash
<b>Subwoofer</b>			center of rear deck
<b>Left Front Headrest</b>			
<b>Right Front Headrest</b>			
<b>Left Right Headrest</b>			
<b>Right Rear Headrest</b>			
<b>Satellite Radio Tuner</b>			trunk left side

*Additional Wiring Notes*


---

Item	Note
<b>Left Front Speaker (+/-)</b>	On models with amplifier, the woofer wires are blue - brown/blue at the amplifier in trunk left side, 32 pin plug, pins 3 - 15. The midrange/tweeter wires are green - brown/green at the amplifier, 32 pin plug, pins 6 - 18.
<b>Right Front Speaker (+/-)</b>	On models with amplifier, the woofer wires are red - brown/red at the amplifier in trunk left side, 32 pin plug, pins 4 - 16. The midrange/tweeter wires are orange - brown/orange at the amplifier, 32 pin plug, pins 5 - 17.
<b>Left Rear Speaker (+/-)</b>	On models with amplifier, the midrange/tweeter wires are purple - brown/purple at the amplifier in trunk left side, 32 pin plug, pins 8 - 20. The surround wires are yellow - brown/yellow at the amplifier, 32 pin plug, pins 10 - 22.
<b>Right Rear Speaker (+/-)</b>	On models with amplifier, the midrange/tweeter wires are white - brown/white at the amplifier in trunk left side, 32 pin plug, pins 7 - 19. The surround wires are pink - brown/pink at the amplifier, 32 pin plug, pins 9 - 21.
<b>Tachometer</b>	On V8 models, they are black, blue, green, gray, pink, purple, white, or yellow at any fuel injector, 2 pin plug, pin 1.