

2009 Peugeot 308



Wiring Information

| Item | Wire Color | Polarity | Wire Location |
|---------------------|------------------------|----------|---|
| 12 Volts | WHITE | | AT 2 WAY CONNECTOR AT BSI UNDER DRIVERS SIDE DASH |
| Second 12 Volts | | | |
| Starter | YELLOW-RED | | AT BALCK 3 WAY AT IGN HARNESS |
| Second Starter | | | |
| Ignition | GREEN | | AT 10 WAY WHITE 'PB1' AT BSI |
| Second Ignition | LIGHT BLUE (IMMOB CUT) | | AT BLACK 3 WAY REAR OF IGN SWITCH |
| Third Ignition | | | |
| Accessory | | | |
| Second Accessory | | | |
| Third Accessory | | | |
| Key Sense | | | |
| Data Bus | | | |
| Can Bus High | | | |
| Can Bus Low | | | |
| Can Bus Sw | | | |
| Power Lock | YELLOW | | AT WHITE 40 WAY AT BSI PIN 4 |
| Power Unlock | RED | | WHITE 40 WAY 'EH1' AT BSI PIN 27 |
| Lock Motor | | | |
| Unlock Motor | | | |
| Disarm Defeat | | | |
| Parking Lights (+) | | | |
| Parking Lights (-) | | | |
| Hazards | | | |
| Turn Signal (Left) | SEE NOTES | | |
| Turn Signal (Right) | SEE NOTES | | |

Wiring Information (Continued)

| Item | Wire Color | Polarity | Wire Location |
|-----------------------------------|------------|----------|-------------------------------------|
| Headlight | | | |
| AutoLights | | | |
| Reverse Light | | | |
| Left Front Door Trigger | RED | | AT WHITE 40 WAY 'EH1' AT BSI PIN 27 |
| Right Front Door Trigger | GREY | | AT WHITE 40 WAY 'EH1' AT BSI PIN 5 |
| Left Rear Door Trigger | RED | | AT WHITE 40 WAY 'EH1' AT BSI PIN 34 |
| Right Rear Door Trigger | WHITE | | AT WHITE 40 WAY 'EH1' AT BSI PIN 33 |
| Dome Supervision | | | |
| Trunk/Hatch Pin | PURPLE | | AT WHITE 40 WAY 'EH1' AT BSI PIN 13 |
| Rear Glass Pin | | | |
| Hood Pin | | | |
| Trunk Hatch/Release | | | |
| Trunk Release Motor | | | |
| Fuel Door Release | | | |
| Power Sliding Door (Left) | | | |
| Power Sliding Door (Right) | | | |
| Factory Alarm Arm | | | |
| Factory Alarm Disarm | | | |
| Disarm No Unlock | | | |
| Trunk Alarm Shunt | | | |
| Tachometer | | | |
| Wait to Start | | | |
| Neutral Safety | | | |
| Clutch Pedal | | | |
| Fuel Pump | | | |
| Rear Defroster | | | |
| Mirror Defroster | | | |
| Left Front Heated Seat | | | |
| Right Front Heated Seat | | | |

Wiring Information (Continued)

| Item | Wire Color | Polarity | Wire Location |
|------------------------------|------------|----------|---------------|
| Speed Sense | | | |
| Brake Wire | | | |
| Parking Brake | | | |
| Horn Trigger | | | |
| Wipers | | | |
| Left Front Window (Up/Down) | | | |
| Right Front Window (Up/Down) | | | |
| Left Rear Window (Up/Down) | | | |
| Right Rear Window (Up/Down) | | | |
| Sun Roof (Open/Close) | | | |
| Sun Roof (Limit/Close) | | | |
| Memory Seat 1 | | | |
| Memory Seat 2 | | | |
| Memory Seat 3 | | | |
| Radio 12V | | | |
| Radio Ground | | | |
| Radio Ignition | | | |
| Radio Illumination | | | |
| Factory Amp Turn-on | | | |
| Power Antenna | | | |
| Left Front Speaker (+/-) | | | |
| Right Front Speaker (+/-) | | | |
| Left Rear Speaker (+/-) | | | |
| Right Rear Speaker (+/-) | | | |
| Center Channel (+/-) | | | |
| Subwoofer (+/-) | | | |
| Aux. Audio Input Left (+/-) | | | |
| Aux. Audio Input Right (+/-) | | | |
| RSE Video (+/-) | | | |
| RSE Audio Left (+/-) | | | |
| RSE Audio Right (+/-) | | | |
| Satellite Radio 12 Volts | | | |
| Satellite Radio Ground | | | |
| Satellite Radio Ignition | | | |
| Satellite Radio Antenna | | | |
| Satellite Audio Left (+/-) | | | |
| Satellite Audio Right (+/-) | | | |

What Fits

| Item | Size | Depth | Location |
|------------------------------|------|-------|----------|
| Headunit | | | |
| Left Front Speaker | | | |
| Left Front Tweeter | | | |
| Right Front Speaker | | | |
| Right Front Tweeter | | | |
| Left Rear Speaker | | | |
| Left Rear Tweeter | | | |
| Right Rear Speaker | | | |
| Right Rear Tweeter | | | |
| Center Channel | | | |
| Subwoofer | | | |
| Left Front Headrest | | | |
| Right Front Headrest | | | |
| Left Right Headrest | | | |
| Right Rear Headrest | | | |
| Satellite Radio Tuner | | | |

Additional Wiring Notes

| Item | Note |
|----------------------------|--|
| Turn Signal (Left) | FRONT LEFT WHITE WIRE AT BROWN 38 WAY AT ENGIGE FUSE BOX PIN 8. REAR LEFT YELLOW WIRE AT BLACK 16 WAY 'PH1' AT BSI PIN 14 |
| Turn Signal (Right) | FRONT RIGHT LIGHT GREEN, AT BROWN 38 WAY IN ENGINE FUSE BOX PIN 6. REAR RIGHT LIGHT BLUE AT BLACK 16 WAY 'PB1' AT BSI PIN 12 |