

2012 Mercedes Benz SLK Class (R172)



Wiring Information

| Item | Wire Color | Polarity | Wire Location |
|----------------------------|--|------------|---|
| 12 Volts | red (100A) | + | trunk fuse box, 1 pin plug, pin 1 |
| Second 12 Volts | N/A | | |
| Starter | purple/white (for starter kill only) | + | underhood fuse box, 7 pin plug (3M), pin 4 |
| Second Starter | N/A | | |
| Ignition | red/white (for ignition sense only) | + | trunk fuse box, 52 pin plug (9I), pin 18 |
| Second Ignition | N/A | | |
| Third Ignition | N/A | | |
| Accessory | N/A | | |
| Second Accessory | N/A | | |
| Third Accessory | N/A | | |
| Key Sense | N/A | | |
| Data Bus | N/A | | |
| Can Bus High | brown/red | data | driver kick or trunk fuse box, 28 pin plug (5H), pin 10 |
| Can Bus Low | brown | data | driver kick or trunk fuse box, 28 pin plug (5H), pin 9 |
| Can Bus Sw | N/A | | |
| Power Lock | green | - | Left Door Module, plug (C5), pin 4 |
| Power Unlock | (same as power lock) | - resistor | |
| Lock Motor | gray/black | 5 wire | Left Door Module, plug (C7), pin 7 |
| Unlock Motor | gray/blue | 5 wire | Left Door Module, plug (C7), pin 6 |
| Disarm Defeat | gray/blue | 5 wire | Right Door Module, plug (C7), pin 6 |
| Parking Lights (+) | gry/bk (LF), gry/rd (RF); grn/bk (LR), grn/rd (RR) | + | undrhd FB, 18P plg(21M), pins 13, 14; trnk FB, 28P plg(5H), pins 1, 2 |
| Parking Lights (-) | (LIN bus) | | |
| Hazards | (LIN bus) | | |
| Turn Signal (Left) | black/white (F); black/white (R) | + | underhood FB, 18P plg (20M), pin 18; trunk FB, 28P plg (5H), pin 25 |
| Turn Signal (Right) | black/green (F); black/green (R) | + | underhood FB, 18P plg (18M), pin 11; trunk FB, 28P plg (5H), pin 15 |

Wiring Information (Continued)

| Item | Wire Color | Polarity | Wire Location |
|-----------------------------------|---|--------------|---|
| Headlight | white/black (L); white/red (R) (high beams) | + | underhood FB, 10 pin plug (14M), pin 1; 10 pin plug (15M), pin 10 |
| AutoLights | (LIN bus) | | |
| Reverse Light | purple/black | + | trunk fuse box, 28 pin plug (5H), pin 22 |
| Left Front Door Trigger | brown/pink | - | Left Door Module, plug (C7), pin 9 |
| Right Front Door Trigger | brown/pink | - | Right Door Module, plug (C7), pin 9 |
| Left Rear Door Trigger | blue/yellow (center console alarm trigger) | - | trunk fuse box, 52 pin plug (9I), pin 14 |
| Right Rear Door Trigger | blue/black (glove box alarm trigger) | - | trunk fuse box, 52 pin plug (9I), pin 1 |
| Dome Supervision | (LIN bus) | | |
| Trunk/Hatch Pin | brown/white or gray | - | trunk fuse box, 32 pin plug (6HD), pin 29 or 31 |
| Rear Glass Pin | N/A | | |
| Hood Pin | brown/red or yellow/brown | - | trunk fuse box, 52 pin plug (9I), pin 5 |
| Trunk Hatch/Release | green (rear handle switch) | - | trunk fuse box, 32 pin plug (6HD), pin 30 |
| Trunk Release Motor | black/white | 5 wire | trunk fuse box, 32 pin plug (6HD), pin 3 |
| Fuel Door Release | (unlocks along with doors) | | |
| Power Sliding Door (Left) | N/A | | |
| Power Sliding Door (Right) | N/A | | |
| Factory Alarm Arm | (factory remote only) | | |
| Factory Alarm Disarm | (factory remote only) | | |
| Disarm No Unlock | | | |
| Trunk Alarm Shunt | N/A | | |
| Tachometer | bk/wh, bu/gn, ye/wh or bu/bk (I4); wht/strip (V6) | ac | any fuel injector, 2 pin plug, pin 1 or 2 |
| Wait to Start | N/A | | |
| Neutral Safety | N/A | | |
| Clutch Pedal | N/A | | |
| Fuel Pump | purple/blue | + | underhood fuse box, 5 pin plug (9G), pin 5 |
| Rear Defroster | black | + latched | trunk fuse box, 1 pin plug (1H), pin 1 |
| Mirror Defroster | (CAN bus) | | |
| Left Front Heated Seat | black/green | 5 wire | trunk fuse box, 8 pin plug (7I), pin 7 |
| Right Front Heated Seat | black | 5 wire | trunk fuse box, 8 pin plug (7I), pin 8 |

Wiring Information (Continued)

| Item | Wire Color | Polarity | Wire Location |
|-------------------------------------|------------------------------|----------|--|
| Speed Sense | (wheel speed sensor) | | |
| Brake Wire | black/red | + | trunk fuse box, 32 pin plug (6HD), pin 1 |
| Parking Brake | (electric parking brake) | | |
| Horn Trigger | black | + | underhood fuse box, 10 pin plug (15M), pin 9 |
| Wipers | (CAN bus) | | |
| Left Front Window (Up/Down) | | | |
| Right Front Window (Up/Down) | | | |
| Left Rear Window (Up/Down) | | | |
| Right Rear Window (Up/Down) | | | |
| Sun Roof (Open/Close) | | | |
| Sun Roof (Limit/Close) | | | |
| Memory Seat 1 | (LIN bus) | | |
| Memory Seat 2 | (LIN bus) | | |
| Memory Seat 3 | (LIN bus) | | |
| Radio 12V | red | + | radio, 16 pin plug, pin 15 |
| Radio Ground | brown | - | radio, 16 pin plug, pin 12 |
| Radio Ignition | (CAN bus) | | |
| Radio Illumination | N/A | | |
| Factory Amp Turn-on | blue (MOST wake up) | | radio, 16 pin plug, pin 16 |
| Power Antenna | purple (mobile phone on/off) | | radio, 16 pin plug, pin 13 |
| Left Front Speaker (+/-) | pink/black - pink | +,- | radio, 16 pin plug, pins 3 - 7 |
| Right Front Speaker (+/-) | yellow/black - yellow | +,- | radio, 16 pin plug, pins 2 - 6 |
| Left Rear Speaker (+/-) | green/black - green | +,- | radio, 16 pin plug, pins 4 - 8 |
| Right Rear Speaker (+/-) | orange/black - orange | +,- | radio, 16 pin plug, pins 1 - 5 |
| Center Channel (+/-) | white/black - white | +,- | amplifier, 32 pin plug, pins 23 - 28 |
| Subwoofer (+/-) | purple/black - purple | +,- | amplifier, 32 pin plug, pins 24 - 29 |
| Aux. Audio Input Left (+/-) | brown - black | +,- | radio, 12 pin plug, pins 4 - 11 |
| Aux. Audio Input Right (+/-) | yellow - black | +,- | radio, 12 pin plug, pins 10 - 11 |
| RSE Video (+/-) | N/A | | |
| RSE Audio Left (+/-) | N/A | | |
| RSE Audio Right (+/-) | N/A | | |
| Satellite Radio 12 Volts | red/purple | + | Sat Radio in left front of trunk, 4 pin plg, pin 2 |
| Satellite Radio Ground | brown | - | Sat Radio in left front of trunk, 4 pin plg, pin 1 |
| Satellite Radio Ignition | blue (MOST wake up) | | Sat Radio in left front of trunk, 4 pin plg, pin 3 |
| Satellite Radio Antenna | (coaxial cable) | | |
| Satellite Audio Left (+/-) | (MOST bus) | | |
| Satellite Audio Right (+/-) | (MOST bus) | | |

What Fits

| Item | Size | Depth | Location |
|------------------------------|-----------|-------|----------------------|
| Headunit | irregular | | center of dash |
| Left Front Speaker | | | left front door |
| Left Front Tweeter | | | left front door |
| Right Front Speaker | | | right front door |
| Right Front Tweeter | | | right front door |
| Left Rear Speaker | | | left rear panel |
| Left Rear Tweeter | | | N/A |
| Right Rear Speaker | | | right rear panel |
| Right Rear Tweeter | | | N/A |
| Center Channel | | | top center of dash |
| Subwoofer | | | center of rear panel |
| Left Front Headrest | | | |
| Right Front Headrest | | | |
| Left Right Headrest | | | |
| Right Rear Headrest | | | |
| Satellite Radio Tuner | | | left front of trunk |

Additional Wiring Notes

| Item | Notes |
|--|---|
| <p>Left Front Speaker (+/-)</p> | <p>On models with a multiplexed speaker wire, the speaker wire is blue - blue / black (</p> |