# 2011 Renault Master



## Wiring Information

Item	Wire Color	Polarity	Wire Location	
12 Volts	RED		PIN 1 AT BCM CONNECTOR BLACK-RED 16 WAY	
Second 12 Volts				
Starter	BEIGE		AT 4 WAY CONNECTOR IGNITION SWITCH	
Second Starter				
Ignition	YELLOW		BCM CONNECTOR BLACK 24 WAY PIN 6	
Second Ignition				
Third Ignition				
Accessory				
Second Accessory				
Third Accessory				
Key Sense				
Data Bus				
Can Bus High				
Can Bus Low				
Can Bus Sw				
Power Lock	BEIGE-WHITE	neg	AT BCM BLACK 40 WAY PIN 32	
Power Unlock	SAME AS LOCK WIRE			
Lock Motor				
Unlock Motor				
Disarm Defeat				
Parking Lights (+)				
Parking Lights (-)				
Hazards				
Turn Signal (Left)	BROWN-BLACK		BCM 16 PIN CONNECTOR PIN 3	
Turn Signal (Right)	PINK-BLACK`		PIN 2	

### DirectWire Vehicle Information - 3/2/2015 7:15:36 AM

## Wiring Information (Continued)

Item	Wire Color	Polarity	Wire Location		
Headlight					
AutoLights					
Reverse Light					
Left Front Door Trigger	GREY		BCM PIN 11 IN 16 WAY BLACK-RED CONNECTOR		
Right Front Door Trigger					
Left Rear Door Trigger					
Right Rear Door Trigger					
Dome Supervision					
Trunk/Hatch Pin					
Rear Glass Pin					
Hood Pin	FIT NEW				
Trunk Hatch/Release					
Trunk Release Motor					
Fuel Door Release					
Power Sliding Door (Left)					
Power Sliding Door (Right)					
Factory Alarm Arm					
Factory Alarm Disarm					
Disarm No Unlock					
Trunk Alarm Shunt					
Tachometer					
Wait to Start					
Neutral Safety					
Clutch Pedal					
Fuel Pump					
Rear Defroster					
Mirror Defroster					
Left Front Heated Seat					
Right Front Heated Seat					

### DirectWire Vehicle Information - 3/2/2015 7:15:36 AM

## Wiring Information (Continued)

Item	Wire Color	Polarity	Wire Location
Speed Sense			
Brake Wire			
Parking Brake			
Horn Trigger			
Wipers			
Left Front Window (Up/Down)			
Right Front Window (Up/Down)			
Left Rear Window (Up/Down)			
Right Rear Window (Up/Down)			
Sun Roof (Open/Close)			
Sun Roof (Limit/Close)			
Memory Seat 1			
Memory Seat 2			
Memory Seat 3			
Radio 12V			
Radio Ground			
Radio Ignition			
Radio Illumination			
Factory Amp Turn-on			
Power Antenna			
Left Front Speaker (+/-)			
Right Front Speaker (+/-)			
Left Rear Speaker (+/-)			
Right Rear Speaker (+/-)			
Center Channel (+/-)			
Subwoofer (+/-)			
Aux. Audio Input Left (+/-)			
Aux. Audio Input Right (+/-)			
RSE Video (+/-)			
RSE Audio Left (+/-)			
RSE Audio Right (+/-)			
Satellite Radio 12 Volts			
Satellite Radio Ground			
Satellite Radio Ignition			
Satellite Radio Antenna			
Satellite Audio Left (+/-)			
Satellite Audio Right (+/-)			

### DirectWire Vehicle Information - 3/2/2015 7:15:36 AM

#### What Fits

Item	Size	Depth	Location
Headunit			
Left Front Speaker			
Left Front Tweeter			
Right Front Speaker			
Right Front Tweeter			
Left Rear Speaker			
Left Rear Tweeter			
Right Rear Speaker			
Right Rear Tweeter			
Center Channel			
Subwoofer			
Left Front Headrest			
Right Front Headrest			
Left Right Headrest			
Right Rear Headrest			
Satellite Radio Tuner			