1997 Dodge Dakota



Wiring Information

Trining innomination			
Item	Wire Color	Polarity	Wire Location
12 Volts	red or pink/black	+	ignition harness
Second 12 Volts			
Starter	blue/yellow	+	ignition harness
Second Starter			
Ignition	dark blue	+	ignition harness
Second Ignition			
Third Ignition			
Accessory	black/orange	+	ignition harness
Second Accessory	black/white	+	ignition harness
Third Accessory			
Key Sense	lt. blue	-	ignition harness
Data Bus			
Can Bus High			
Can Bus Low			
Can Bus Sw			
Power Lock	org/pur or grn/blk	+	drivers kick panel
Power Unlock	pink/purple	+ or 5wire	drivers kick panel
Lock Motor			
Unlock Motor			
Disarm Defeat			
Parking Lights (+)	black/yellow		behind fuse box
Parking Lights (-)			
Hazards			
Turn Signal (Left)			
Turn Signal (Right)			

DirectWire Vehicle Information - 10/1/2015 2:17:07 AM

Wiring Information (Continued)

Item	Wire Color	Polarity	Wire Location
Headlight	light green	+	steering column
AutoLights			
Reverse Light			
Left Front Door Trigger	yellow	-	behind fuse box
Right Front Door Trigger			
Left Rear Door Trigger			
Right Rear Door Trigger			
Dome Supervision			
Trunk/Hatch Pin			
Rear Glass Pin			
Hood Pin			
Trunk Hatch/Release			
Trunk Release Motor			
Fuel Door Release			
Power Sliding Door (Left)			
Power Sliding Door (Right)			
Factory Alarm Arm			
Factory Alarm Disarm	black/orange	-	drivers door harness
Disarm No Unlock			
Trunk Alarm Shunt			
Tachometer	blk/gry or gry/blk	AC	coil pass. sid of eng.
Wait to Start			
Neutral Safety			
Clutch Pedal			
Fuel Pump			
Rear Defroster			
Mirror Defroster			
Left Front Heated Seat			
Right Front Heated Seat			

DirectWire Vehicle Information - 10/1/2015 2:17:07 AM

Wiring Information (Continued)

Speed Sense white/tan + at brake switch Parking Brake - steering column Horn Trigger black/red - steering column Wipers red/yellow + wiper switch Left Front Window (Up/Down) It. blue - white A drivers door switch Right Front Window (Up/Down) brn/wht - ppl/wht A drivers kick panel Left Rear Window (Up/Down) William W	Transport (Community)	14/1 0 . 1	D.1.26	AAP I d'
Brake Wire white/tan + at brake switch Parking Brake black/red - steering column wipers red/yellow + wiper switch Left Front Window (Up/Down) btrn/wht - ppl/wht A drivers door switch drivers kick panel Left Rear Window (Up/Down) btrn/wht - ppl/wht A drivers kick panel Left Rear Window (Up/Down) with the windo	Item	Wire Color	Polarity	Wire Location
Parking Brake Black/red - Steering column Horn Trigger black/red - steering column Wijpers red/yellow + wijper switch Left Front Window (Up/Down) bt. blue - white A drivers kick panel Left Rear Window (Up/Down) Fred Window (Up/Down) A drivers kick panel Left Rear Window (Up/Down) Fred Window (Up/Down) B Fred Window (Up/Down) Sun Roof (Open/Close) Sun Roof (Open/Close) Fred Window (Up/Down) Fred Window (Up/Down) Sun Roof (Open/Close) Sun Roof (Imit/Close) Fred Window (Up/Down) Fred Window (Up/Down) Sun Roof (Open/Close) Sun Roof (Imit/Close) Fred Window (Up/Down) Fred Window (Up/Down) Sun Roof (Open/Close) Sun Roof (Imit/Close) Fred Window (Up/Down) Fred Window (Up/Down) Memory Seat 2 Wemory Seat 2 Fred Window (Up/Down) Fred Window (Up/Down)<	•			
Horn Trigger Black/red - Steering column		white/tan	+	at brake switch
Vipers				
Left Front Window (Up/Down) It. blue - white A drivers door switch Right Front Window (Up/Down) bm/wht - ppl/wht A drivers kick panel Left Rear Window (Up/Down) Stranger Window (Up/Down) Stranger Window (Up/Down) Stranger Window (Up/Down) Sun Roof (Open/Close) Stranger Window (Up/Down) Stranger Window (Up/Down) Stranger Window (Up/Down) Sun Roof (Open/Close) Stranger Window (Up/Down) Stranger Window (Up/Down) Stranger Window (Up/Down) Sun Roof (Open/Close) Stranger Window (Up/Down) Stranger Window (Up/Down) Stranger Window (Up/Down) Sun Roof (Open/Close) Stranger Window (Up/Down) Stranger Window (Up/Down) Stranger Window (Up/Down) Sun Roof (Open/Close) Stranger Window (Up/Down) Stranger Window (Up/Down) Stranger Window (Up/Down) Sun Roof (Up/Down) Stranger Window (Up/Down) Stranger Window (Up/Down) Stranger Window (Up/Down) Radio (Up/Down) Stranger Window (Up/Down) Stranger Window (Up/Down) Stranger Window (Up/Down) Radio (Up/Down) Stranger Window (Up/Down) Stranger Window (Up/Down) Stranger Window (Up/Down) Radio (Up/Down) Stranger			-	•
Right Front Window (Up/Down) bm/wht - ppl/wht A drivers kick panel Left Rear Window (Up/Down) Image: Common of the pillow of th	Wipers	red/yellow	+	wiper switch
Left Rear Window (Up/Down) Right Rear Window (Up/Down) Sun Roof (Open/Close) Sun Roof (Limit/Close) Memory Seat 1 Memory Seat 2 Memory Seat 3 Memory Seat 3 Radio 12V Radio Ground Radio Ignition Radio Illumination Factory Amp Turn-on Power Antena Left Front Speaker (+/-) Right Front Speaker (+/-) Right Rear Speaker (+/-) Right Rear Speaker (+/-) Subwoofer (+/-) Subwoofer (+/-) Aux. Audio Input Left (+/-) Aux. Audio Input Right (+/-) RSE Video (+/-) RSE Audio Left (+/-) RSE Audio Right (+/-) Satellite Radio 12 Volts Satellite Radio Ground Satellite Radio Gnothena Satellite Radio Antenna Satellite Radio Antenna Satellite Radio Antenna Satellite Radio Left (+/-)	Left Front Window (Up/Down)	It. blue - white	A	drivers door switch
Right Rear Window (Up/Down) (Dept/Close) Sun Roof (Limit/Close) (Dept/Close) Memory Seat 1 (Dept/Close) Memory Seat 2 (Dept/Close) Memory Seat 3 (Dept/Close) Radio 12V (Dept/Close) Radio Ground (Dept/Close) Radio Illumination (Dept/Close) Radio Illumination (Dept/Close) Factory Amp Turn-on (Dept/Close) Power Antenna (Dept/Close) Right Front Speaker (+/-) (Dept/Close) Right Front Speaker (+/-) (Dept/Close) Right Rear Spea	Right Front Window (Up/Down)	brn/wht - ppl/wht	A	drivers kick panel
Sun Roof (Open/Close) Sun Roof (Limit/Close) Memory Seat 1 Sun Roof (Limit/Close) Memory Seat 2 Sun Roof (Sun Roof Roof Roof Roof Roof Roof Roof Roo	Left Rear Window (Up/Down)			
Sun Roof (Limit/Close) (memory Seat 1) Memory Seat 2 (memory Seat 3) Radio 12V (memory Seat 3) Radio Ground (memory Seat 3) Radio Ignition (memory Seat 4) Radio Ignition (memory Seat 4) Radio Ignition (memory Seat 4) Radio Illumination (memory Seat 4) Factory Amp Turn-on (memory Amp Turn-on) Power Antenna (memory Seater 4) Left Front Speaker (+/-) (memory Seater 4) Right Front Speaker (+/-) (memory Seater 4) Right Rear Speaker (+/-) (memory Seater 4) Right Rear Speaker (+/-) (memory Seater 4) Subwoofer (+/-) (memory Seater 4) Subwoofer (+/-) (memory Seater 4) Aux. Audio Input Left (+/-) (memory Seater 4) SE Audio Left (Right Rear Window (Up/Down)			
Memory Seat 1 Memory Seat 2 Memory Seat 3 Memory Seat 3 Radio 12V Memory Seat 3 Radio Ground Memory Seat 3 Radio Ground Memory Seat 3 Radio Ground Memory Seat 4 Radio Illumination Memory Seat 4 Factory Amp Turn-on Memory Seat 4 Power Antenna Memory Seater (*/-) Left Front Speaker (*/-) Memory Seater (*/-) Right Front Speaker (*/-) Memory Seater (*/-) Right Rear Speaker (*/-) Memory Seater (*/-) Right Rear Speaker (*/-) Memory Seater (*/-) Subwoofer (*/-) Memory Seater (*/-) Subwoofer (*/-) Memory Seater (*/-) Aux. Audio Input Left (*/-) Memory Seater (*/-) RSE Video (*/-) Memory Seater (*/-) RSE Audio Left (*/-) Memory Seater (*/-) Satellite Radio 12 Votts Memory Seater (*/-) Satellite Radio Ground Memory Seater (*/-) Satellite Radio Ignition Memory Seater (*/-) Satellite Radio Ignition Memory Seater (*/-) Satellite Radio Ignition <	Sun Roof (Open/Close)			
Memory Seat 2 Memory Seat 3 Radio 12V Sadio Ground Radio Ignition Memory Seat 3 Radio Ignition Memory Seat 3 Radio Ignition Memory Seat 3 Radio Illumination Memory Seat 3 Factory Amp Turn-on Memory Seat 4 Power Antenna Memory Seat 4 Left Front Speaker (+/-) Memory Seat 4 Right Front Speaker (+/-) Memory Seat 2 Right Front Speaker (+/-) Memory Seat 2 Right Front Speaker (+/-) Memory Seat 2 Right Front Speaker (+/-) Memory Seat 3	Sun Roof (Limit/Close)			
Memory Seat 3 Radio 12V Radio Ground Control of the property of t	Memory Seat 1			
Radio 12V Radio Ground Radio Ignition Image: Common and analysis of the common and analy	Memory Seat 2			
Radio Ground <t< td=""><td>Memory Seat 3</td><td></td><td></td><td></td></t<>	Memory Seat 3			
Radio Ignition	Radio 12V			
Radio Illumination	Radio Ground			
Factory Amp Turn-on Power Antenna Left Front Speaker (+/-) Right Front Speaker (+/-) Right Rear Speaker (+/-) Right Rear Speaker (+/-) Center Channel (+/-) Subwoofer (+/-) Aux. Audio Input Left (+/-) Aux. Audio Input Right (+/-) RSE Video (+/-) RSE Audio Left (+/-) RSE Audio Right (+/-) Satellite Radio 12 Volts Satellite Radio Ignition Satellite Radio Antenna Satellite Audio Left (+/-) Satellite Radio Left (+/-) Satellite Radio Antenna Satellite Audio Left (+/-)	Radio Ignition			
Power Antenna	Radio Illumination			
Left Front Speaker (+/-) Right Front Speaker (+/-) Left Rear Speaker (+/-) State of the stat	Factory Amp Turn-on			
Right Front Speaker (+/-) Left Rear Speaker (+/-) Right Rear Speaker (+/-) Subwoofer (+/-) Center Channel (+/-) Subwoofer (+/-) Subwoofer (+/-) Aux. Audio Input Left (+/-) Aux. Audio Input Right (+/-) Subwoofer (+/-) RSE Video (+/-) Subwoofer (+/-) RSE Audio Left (+/-) Subwoofer (+/-) RSE Audio Right (+/-) Subwoofer (+/-) Satellite Radio 12 Volts Subwoofer (+/-) Satellite Radio Ground Subwoofer (+/-) Satellite Radio Antenna Satellite Radio Antenna Satellite Audio Left (+/-) Satellite Audio Left (+/-)	Power Antenna			
Left Rear Speaker (+/-) Right Rear Speaker (+/-) Center Channel (+/-) Subwoofer (+/-) Subwoofer (+/-) Subwoofer (+/-) Aux. Audio Input Left (+/-) Subwoofer (+/-) RSE Video (+/-) Subwoofer (+/-) RSE Audio Left (+/-) Subwoofer (+/-) RSE Audio Right (+/-) Subwoofer (+/-) Satellite Radio 12 Volts Subwoofer (+/-) Satellite Radio Ignition Subwoofer (+/-) Satellite Radio Antenna Subwoofer (+/-) Satellite Audio Left (+/-) Subwoofer (+/-)	Left Front Speaker (+/-)			
Right Rear Speaker (+/-) Center Channel (+/-) Subwoofer (+/-) Aux. Audio Input Left (+/-) Aux. Audio Input Right (+/-) RSE Video (+/-) RSE Audio Left (+/-) RSE Audio Right (+/-) Satellite Radio 12 Volts Satellite Radio Ignition Satellite Radio Antenna Satellite Audio Left (+/-) Satellite Audio Left (+/-)	Right Front Speaker (+/-)			
Center Channel (+/-) Subwoofer (+/-) Aux. Audio Input Left (+/-) Aux. Audio Input Right (+/-) RSE Video (+/-) RSE Audio Left (+/-) RSE Audio Right (+/-) Satellite Radio 12 Volts Satellite Radio Ground Satellite Radio Ignition Satellite Radio Antenna Satellite Audio Left (+/-)	Left Rear Speaker (+/-)			
Subwoofer (+/-) Aux. Audio Input Left (+/-) Aux. Audio Input Right (+/-) RSE Video (+/-) RSE Audio Left (+/-) RSE Audio Right (+/-) Satellite Radio 12 Volts Satellite Radio Ground Satellite Radio Ignition Satellite Radio Antenna Satellite Audio Left (+/-)	Right Rear Speaker (+/-)			
Aux. Audio Input Left (+/-) Aux. Audio Input Right (+/-) RSE Video (+/-) RSE Audio Left (+/-) RSE Audio Right (+/-) Satellite Radio 12 Volts Satellite Radio Ground Satellite Radio Ignition Satellite Radio Antenna Satellite Audio Left (+/-)	Center Channel (+/-)			
Aux. Audio Input Right (+/-) RSE Video (+/-) RSE Audio Left (+/-) RSE Audio Right (+/-) Satellite Radio 12 Volts Satellite Radio Ground Satellite Radio Ignition Satellite Radio Antenna Satellite Audio Left (+/-)	Subwoofer (+/-)			
RSE Video (+/-) RSE Audio Left (+/-) RSE Audio Right (+/-) Satellite Radio 12 Volts Satellite Radio Ground Satellite Radio Ignition Satellite Radio Antenna Satellite Audio Left (+/-)	Aux. Audio Input Left (+/-)			
RSE Audio Left (+/-) RSE Audio Right (+/-) Satellite Radio 12 Volts Satellite Radio Ground Satellite Radio Ignition Satellite Radio Antenna Satellite Audio Left (+/-)	Aux. Audio Input Right (+/-)			
RSE Audio Right (+/-) Satellite Radio 12 Volts Satellite Radio Ground Satellite Radio Ignition Satellite Radio Antenna Satellite Audio Left (+/-)	RSE Video (+/-)			
Satellite Radio 12 Volts Satellite Radio Ground Satellite Radio Ignition Satellite Radio Antenna Satellite Audio Left (+/-)	RSE Audio Left (+/-)			
Satellite Radio Ground Satellite Radio Ignition Satellite Radio Antenna Satellite Audio Left (+/-)	RSE Audio Right (+/-)			
Satellite Radio Ignition Satellite Radio Antenna Satellite Audio Left (+/-)	Satellite Radio 12 Volts			
Satellite Radio Antenna Satellite Audio Left (+/-)	Satellite Radio Ground			
Satellite Audio Left (+/-)	Satellite Radio Ignition			
	Satellite Radio Antenna			
Satellite Audio Right (+/-)	Satellite Audio Left (+/-)			
	Satellite Audio Right (+/-)			

DirectWire Vehicle Information - 10/1/2015 2:17:07 AM

What Fits

Item	Size	Depth	Location
Headunit			
Left Front Speaker			
Left Front Tweeter			
Right Front Speaker			
Right Front Tweeter			
Left Rear Speaker			
Left Rear Tweeter			
Right Rear Speaker			
Right Rear Tweeter			
Center Channel			
Subwoofer			
Left Front Headrest			
Right Front Headrest			
Left Right Headrest			
Right Rear Headrest			
Satellite Radio Tuner			