2014 BMW 2 Series (F22)



Wiring Information

vviiling innomitat			•	
Item	Wire Color	Polarity	Wire Location	
12 Volts	red/blue (40A)	+	Front Electronic Module in pass kick, black 54 pin plug (3B), pin 33	
Second 12 Volts	N/A			
Starter	black (for starter kill only)	+ low curr	Front Electronic Module in pass kick, black 42 pin plug (2B), pin 1	
Second Starter	grn/blu or blu/wht (SS1); wht/blu or blu/wht (SS2)	- resistor	start/stop button or Front Electronic Mod, wh 54 pin plg(7B), pins 45,49	
Ignition	green/gray (for ignition sense only)	+ low curr	Front Electronic Module in pass kick, black 54 pin plug (3B), pin 20	
Second Ignition	N/A			
Third Ignition	N/A			
Accessory	N/A			
Second Accessory	N/A			
Third Accessory	N/A			
Key Sense	N/A			
Data Bus	(immobilizer antenna ring is in steering column)			
Can Bus High	yellow/red (K CAN)	data	Front Electronic Module in pass kick, black 54 pin plug (8B), pin 50	
Can Bus Low	yellow/brown (K CAN)	data	Front Electronic Module in pass kick, black 54 pin plug (8B), pin 49	
Can Bus Sw	white/blue (keyless LIN bus)	data	Front Electronic Module in pass kick, white 54 pin plug (4B), pin 15	
Power Lock	yellow/brown (center dash switch)	-	Front Electronic Module in pass kick, white 54 pin plug (7B), pin 27	
Power Unlock	(same as power lock)			
Lock Motor	white or black	5 wire	Front Electronic Mod in pass kick, wht 54 pin plug (4B), pin 30 or 20	
Unlock Motor	yellow/green	5 wire	Front Electronic Module in pass kick, white 54 pin plug (4B), pin 29	
Disarm Defeat	blue	5 wire	Front Electronic Module in pass kick, white 54 pin plug (4B), pin 28	
Parking Lights (+)	black/green (LF); black/blue (RF)	+	Front Electronic Mod in pass kick, black 54 pin plug (3B), pins 51, 39	
Parking Lights (-)	(LIN bus)			
Hazards	brown/blue	-	Front Electronic Module in pass kick, white 54 pin plug (7B), pin 31	
Turn Signal (Left)	blue/green (F); black/white (R)	+	Frt Elct Mod, 54P plg (3B), pin 48; Rr Elct Mod, 26P plg (12B), pin 17	
Turn Signal (Right)	blue/brown (F); black/gray (R)	+	Frt Elct Mod, 54P plg (3B), pin 36; Rr Elct Mod, 54P plg (14B), pin 12	

Wiring Information (Continued)

,		
Wire Color	Polarity	Wire Location
yellow/green (L); yellow/blue (R)	+	Front Electronic Mod, 54 pin plug (3B), pin 35; 42 pin plg(2B), pin 25
(LIN bus)		
gray/blue	+	Rear Electronic Module in trunk R side, blk 54 pin plug (14B), pin 13
gray/white	-	Front Electronic Module in pass kick, black 42 pin plug (2B), pin 30
brown/yellow	-	Front Electronic Mod, blk 42 pin plug (2B), pin 31
N/A		
N/A		
gray/purple	-	Front Electronic Module in pass kick, black 54 pin plug (3B), pin 21
brown/green or brown/orange	-	Rear Electronic Module in trunk R side, wht 26 pin plug (13B), pin 26
N/A		
purple/green or purple/red	-	Front Electronic Module in pass kick, black 42 pin plug (2B), pin 40
green/black	-	release switch or Front Electronic Mod, blk 42 pin plug (2B), pin 37
gray/green	5 wire	Rear Electronic Module in trunk R side, wht 26 pin plug (13B), pin 19
purple/red (unlock only)	5 wire	Front Electronic Module in pass kick, white 54 pin plug (4B), pin 45
N/A		
N/A		
(factory remote only)		
(see disarm no unlock)		
(transponder and push-button start)		
N/A		
black/red	ac	data link connector, 16 pin plug, pin 9
N/A		
N/A		
blue/brown		Front Electronic Mod, blk 54 pin plug (3B), pin 23
red/green	+	rear fuse holder in trunk R side, plg (11B), pin 2
red	+ latched	Rear Electronic Module in trunk R side, blk 26 pin plug (12B), pin 26
(LIN bus)		
(LIN bus or K CAN)		
(LIN bus or K CAN)		
	yellow/green (L); yellow/blue (R) (LIN bus) gray/blue gray/white brown/yellow N/A N/A gray/purple brown/green or brown/orange N/A purple/green or purple/red green/black gray/green purple/red (unlock only) N/A N/A (factory remote only) (see disarm no unlock) (transponder and push-button start) N/A black/red N/A N/A blue/brown red/green red (LIN bus) (LIN bus or K CAN)	yellow/green (L); yellow/blue (R) (LIN bus) gray/blue + gray/white - brown/yellow - N/A N/A N/A gray/purple - brown/green or brown/orange - N/A purple/green or purple/red - gray/green 5 wire purple/red (unlock only) 5 wire N/A N/A (factory remote only) (see disarm no unlock) (transponder and push-button start) N/A N/A black/red ac N/A N/A N/A blue/brown red/green + red + latched (LIN bus) (LIN bus or K CAN)

Wiring Information (Continued)

Wire Color	Pola	arit Wire Location		
	y	WIIE LOCATION		
(wheel speed sensor)	,			
blue/red	-	brake switch or Front Electronic Mod, blk 54 pin pl (3B), pin 22		
yellow/blue	-	park brake sw or Front Electronic Mod, blk 54 pin plug (3B), pin 10		
purple/blue or purple/white (LO); purple/blue (HI)	+	Front Electronic Mod in pass kick, black 42 pin plug (2B), pins 2, 3		
red/green (LO); red/yellow (HI)	+	Front Electronic Mod in pass kick, black 42 pin plug (2B), pins 22, 23		
(not recommended because of factory auto up/down)				
(not recommended because of factory auto up/down)				
N/A				
N/A				
green - blue	reverse	overhead console, plug (3B), pins 3 - 4		
N/A				
red/yellow	+	radio, 40 pin plug, pin 15		
brown	-	radio, 40 pin plug, pin 12		
(K CAN)				
gray/red (dimmer)	+	radio, 40 pin plug, pin 14		
(same as power antenna)				
black	+	radio, 40 pin plug, pin 13		
black/red - black/brown or yellow/red - yellow/brn	+,-	radio, 40 pin plug, pins 3 - 7		
blue/red - blue/brown or purple/red - purple/brown	+,-	radio, 40 pin plug, pins 2 - 6		
+/-) white/red - white/brown or brown/blue - brown/red		radio, 40 pin plug, pins 4 - 8		
yellow/red - yellow/brown or green/brn - green/red	+,-	radio, 40 pin plug, pins 1 - 5		
enter Channel (+/-) black/white - black/purple		amplifier in trunk L side, 42 pin plug, pins 39 - 40		
N/A				
white/red - purple or gray - brown	+,-	+,- radio, 40 pin plug, pins 30 - 36		
white/green - purple or blue - brown	+,-	radio, 40 pin plug, pins 35 - 36		
white - (shield) (DVD changer)	+,-	radio, 40 pin plug, pins 24 - 23		
(MOST bus)				
(MOST bus)				
(built into radio)				
N/A				
	purple/blue or purple/white (LO); purple/blue (HI) red/green (LO); red/yellow (HI) not recommended because of factory auto up/down) not recommended because of factory auto up/down) N/A N/A N/A green - blue N/A red/yellow brown (K CAN) gray/red (dimmer) (same as power antenna) black black/red - black/brown or yellow/red - yellow/brn blue/red - blue/brown or brown/blue - brown/red yellow/red - yellow/brown or green/brn - green/red black/white - black/purple N/A white/red - purple or gray - brown white/green - purple or blue - brown white - (shield) (DVD changer) (MOST bus) (built into radio) N/A N/A N/A N/A N/A N/A N/A N/	blue/red yellow/blue purple/blue or purple/white (LO); purple/blue (HI) red/green (LO); red/yellow (HI) not recommended because of factory auto up/down) N/A N/A N/A green - blue red/yellow horown (K CAN) gray/red (dimmer) (same as power antenna) black black/red - black/brown or yellow/red - yellow/brn blue/red - white/brown or brown/blue - brown/red yellow/red - yellow/brown or green/brn - green/red holack/white - black/purple N/A white/red - purple or gray - brown white/green - purple or blue - brown white - (shield) (DVD changer) (MOST bus) (MOST bus) (built into radio) N/A N/A N/A N/A N/A N/A N/A N/		

What Fits

Item	Size	Depth	Location
Headunit			
Left Front Speaker			
Left Front Tweeter			
Right Front Speaker			
Right Front Tweeter			
Left Rear Speaker			
Left Rear Tweeter			
Right Rear Speaker			
Right Rear Tweeter			
Center Channel			
Subwoofer			
Left Front Headrest			
Right Front Headrest			
Left Right Headrest			
Right Rear Headrest			
Satellite Radio Tuner			

Additional Wiring Notes

Item	Note		
Parking Lights (+)	The LR - RR are gray/purple - gray/black at the Rear Electronic Module in trunk R side, black 26 pin plug (12B), pin 12; black 54 pin plug (14B), pin 24.		
Left Front Speaker (+/-)	On models with amplifier, the speaker wire are black/red - black/brown (woofer); black/red - black/brown (tweeter/midrange) at the amplifier in trunk L side, 42 pin plug, pins 4 - 3; 33 - 34.		
Right Front Speaker (+/-)	On models with amplifier, the speaker wire are blue/red - blue/brown (woofer); blue/red - blue/brown (tweeter/midrange) at the amplifier in trunk L side, 42 pin plug, pins 23 - 22; 11 - 12.		
Left Rear Speaker (+/-)	On models with amplifier, the speaker wire are white/red - white/brown at the amplifier in trunk L side, 42 pin plug, pins 32 - 31.		
Right Rear Speaker (+/-)	On models with amplifier, the speaker wire are yellow/red - yellow/brown at the amplifier in trunk L side, 42 pin plug, pins 13 - 21.		