



<http://www.directechs.com>

Wiring Information

Item	Wire Color	Polarity	Wire Location
12 Volts	yellow	+	ignition harness
Ground	(chassis ground)		
Starter	red/lt. blue	+	ignition harness
Ignition	red/lt. green	+	ignition harness
Accessory	gray/yellow	+	ignition harness
Power Lock	pink/yellow	5wi	pass kick panel
Power Unlock	pink/green	5wi	pass kick panel
Parking Lights	brown		lt switch or dr kick
Headlight	red/yellow	+	at switch
Left Front Door Trigger	black/blue	+	driver kick panel
Tachometer	tan/yellow	AC	at coil
Wait to Start	black/pink	-	warning light on the dash
Brake Wire	lt. green	+	brake pedal switch
Horn Trigger	dk. blue	-	steering column
Left Front Window (Up/Down)	yellow - red	A	in drivers door
Right Front Window (Up/Down)	yel/blk - red/blk	A	in drivers door or pkp

1992 Ford FSeries - Requested by: [ampire.de](#)



<http://www.directechs.com>

What Fits

Item	Size	Depth	Location
------	------	-------	----------



<http://www.directechs.com>

Additional Wiring Notes

Item	Note
Power Lock	ESSENTIAL to use drivers switch when testing for switch and motor sides. E-brake bracket blocks easy access from drivers side.
Power Unlock	ESSENTIAL to use drivers switch when testing for switch and motor sides. E-brake bracket blocks easy access from drivers side.
Tachometer	On diesel trucks use white/black at the alternator for tach.
Wait to Start	Also found at the glow plug controller on the center rear of the engine.