



Wiring Information

| Item | Wire Color | Polarity | Wire Location |
|----------------------|------------------|----------|---|
| 12 Volts | White (50A) | + | Driver Kick Fuse Box, rear, white 1 pin plug, pin 1 |
| Ground | (chassis ground) | | |
| Starter | Brown | + | Start Stop Unit in steering column, white 24 pin plug, pin 23 |
| Ignition | Pink | + | Start Stop Unit in steering column, white 24 pin plug, pin 10 |
| Accessory | Yellow | + | Start Stop Unit in steering column, white 24 pin plug, pin 2 |
| Second Accessory | Pink | + | Start Stop Unit in steering column, white 24 pin plug, pin 14 |
| Ignition Interrupt | Brown | Cut | Start Stop Unit in steering column, white 32 pin plug, pin 3 |
| Ignition Interrupt 2 | Violet | Cut | Start Stop Unit in steering column, white 32 pin plug, pin 17 |
| PTS 1 | Lt. Green | - | Start Stop Unit in steering column, white 32 pin plug, pin 20 |
| PTS 2 | Red | - | Start Stop Unit in steering column, white 24 pin plug, pin 17 |
| CAN Bus High | White (HS CAN) | Data | Start Stop Unit in steering column, white 24 pin plug, pin 7 |
| CAN Bus Low | Red (HS CAN) | Data | Start Stop Unit in steering column, white 24 pin plug, pin 8 |
| CAN Bus High 2 | White (HS CAN) | Data | OBD-Data Link Connector, white 16 pin plug, pin 6 |
| CAN Bus Low 2 | Red (HS CAN) | Data | OBD-Data Link Connector, white 16 pin plug, pin 14 |
| CAN Bus High 3 | Pink (MS CAN) | Data | OBD-Data Link Connector, white 16 pin plug, pin 3 |
| CAN Bus Low 3 | Blue (MS CAN) | Data | OBD-Data Link Connector, white 16 pin plug, pin 11 |





| Item | Wire Color | Polarity | Wire Location |
|-----------------------------|---|-------------|---|
| OBD 12 Volts | Brown (7.5A) | + | OBD-Data Link Connector, white 16 pin plug, pin 16 |
| OBD Ground | Black | - | OBD-Data Link Connector, white 16 pin plug, pin 4 |
| IMMO Antenna | (immobilizer antenna is in the push button start) | | |
| Keyless Data | Green | Data | Start Stop Unit in steering column, white 32 pin plug, pin 9 |
| Power Lock | Blue | - 1000 Ohms | Driver Kick, harness to rearor Rear BCM in left rear quarter panel, white 24 pin plug, pin 15 |
| Power Unlock | (same as power lock) | - | |
| Lock Motor | Pink | Reverse | Driver Kick, harness to rearor Rear BCM in left rear quarter panel, white 16 pin plug, pin 2 |
| Driver Unlock Motor | Lt. Blue | Reverse | Driver Kick, harness to rearor Rear BCM in left rear quarter panel, white 16 pin plug, pin 3 |
| Passenger Unlock Motor | Blue | Reverse | Rear BCM in left rear quarter panel, white 16 pin plug, pin 4 |
| Factory Alarm Arm | White (driver door key lock) | - 1000 Ohms | Driver Kick, harness to rearor Rear BCM in left rear quarter panel, white 24 pin plug, pin 16 |
| Factory Alarm Disarm | (same as factory alarm arm) | Double - | |
| Disarm No Unlock | (proximity key and push button) | | |
| Parking Lights | Pink | + | Driver Kick, harness to rear |
| Parking Lights - | Yellow | - | Parking Light Switch Assembly inside steering column, white 6 pin plug, pin 3 |
| Parking Lights Interrupt | Green | Cut | Parking Light Switch Assembly inside steering column, white 6 pin plug, pin 4 |
| Hazards | White | - | Start Stop Unit in steering column, white 32 pin plug, pin 4 |
| Turn Signal (Left) | White (F); Lt. Blue (R) | + | Front BCM in underhood fuse box, white 28 pin plug, pin 15 (F); Driver Kick, harness to rear (R) |





| Item | Wire Color | Polarity | Wire Location |
|-----------------------------|--|-----------------------|---|
| Turn Signal (Right) | White (F); Blue (R) | + | Front BCM in underhood fuse box, blue 18 pin plug, pin 4 (F); Driver Kick, harness to rear (R) |
| Headlight | Green | - | Start Stop Unit in steering column, white 32 pin plug, pin 28 |
| AutoLights | (switch is plugged into Start Stop Unit; no wires) | | |
| Reverse Light | Brown | + | Rear BCM in left rear quarter panel, blue 18 pin plug, pin 10 |
| Left Front Door Trigger | Lt. Blue | - | Driver Kick, harness to rearor Rear BCM in left rear quarter panel, white 24 pin plug, pin 12 |
| Right Front Door Trigger | Brown | - | Rear BCM in left rear quarter panel, white 24 pin plug, pin 11 |
| Left Rear Door Trigger | Brown | - | Rear BCM in left rear quarter panel, white 24 pin plug, pin 10 |
| Right Rear Door Trigger | Brown | - | Rear BCM in left rear quarter panel, white 24 pin plug, pin 9 |
| Dome Light | Violet | - | Rear BCM in left rear quarter panel, white 8 pin plug, pin 3 |
| Trunk/Hatch Pin | Brown | - | Rear BCM in left rear quarter panel, blue 18 pin plug, pin 6 |
| Hood Pin | Blue | - N.C. | Driver Kick, harness to rearor Rear BCM in left rear quarter panel, white 24 pin plug, pin 18 |
| Power Liftgate | Green and Red | Connect With Relay | Power Liftgate Front Switch, white 10 pin plug, pins 7, 8 |
| Trunk/Hatch Release | White (rear handle switch) | - | Rear BCM in left rear quarter panel, blue 18 pin plug, pin 7 |
| Trunk Release Motor | Green (without power liftgate) | Reverse | Rear BCM in left rear quarter panel, blue 18 pin plug, pin 2 |
| Tachometer | Green | ac | Camshaft Position Sensor, engine driver side, gray 3 pin plug, pin 1 |
| Neutral Safety | Violet (M/T) | - | PCM next to underhood fuse box, black 140 pin plug, pin 33 |





| Item | Wire Color | Polarity | Wire Location |
|--------------------------------|--|-----------|--|
| Clutch Pedal | Yellow | - | Start Stop Unit in steering column, white 32 pin plug, pin 19 |
| Clutch Pedal 2 | White | - | Start Stop Unit in steering column, white 24 pin plug, pin 3 |
| Fuel Pump | Gray | + | Above Driver Kick, black 18 pin plug, pin 1 |
| Rear Defroster | Blue | + Latched | Driver Kick, harness to rear |
| Mirror Defroster | (same as rear defroster) | | |
| Wiper Deicer | (same as rear defroster) | | |
| Left Front Heated Seat | (serial data) | | |
| Right Front Heated Seat | (serial data) | | |
| Speed Sense | Lt. Blue (without Bose only) | ac | Radio in dash or Tuner above passenger kick, white 24 pin plug, pin 19 |
| Brake Wire | Red | + | Start Stop Unit in steering column, white 32 pin plug, pin 2 |
| Parking Brake | Blue (electric parking brake indicator) | - | Electric Parking Brake Switch, white 12 pin plug, pin 12 |
| Horn Trigger | Blue | - | Horn Switch-Clock Spring, white 14 pin plug, pin 1 |
| Wipers | Yellow | - | Start Stop Unit in steering column, white 32 pin plug, pin 27 |
| Left Front Window (Up/Down) | Brown - Gray | A | Power Window Main Switch, white 12 pin plug, pins 11 - 10 |
| Right Front Window (Up/Down) | Green - White | A | Driver Kick, door harness |
| Left Rear Window (Up/Down) | Blue - Red | A | Driver Kick, door harness |
| Right Rear Window (Up/Down) | Blue - Red | A | Driver Kick, door harness |
| Sun Roof (Open/Close) | Red - White (function with ignition on only) | - | Sunroof Switch, white 4 pin plug, pins 1 - 2 |
| Sun Roof (Limit/Close) | Blue (tilt up) (functions with ignition on only) | - | Sunroof Switch, white 4 pin plug, pin 3 |
| Memory Seat 1 | (no wire color listed in service manual) | - | Memory Switch, white 4 pin plug, pin 3 |
| Memory Seat 2 | (no wire color listed in service manual) | - | Memory Switch, white 4 pin plug, pin 4 |





| Item | Wire Color | Polarity | Wire Location |
|---------------------------------|---|----------|---|
| Radio 12V | Yellow | + | Radio in dash or Tuner above passenger kick, white 24 pin plug, pin 9 |
| Radio Ground | Black | - | Radio in dash or Tuner above passenger kick, white 24 pin plug, pin 16 |
| Radio Ignition | Violet | + | Radio in dash or Tuner above passenger kick, white 24 pin plug, pin 24 |
| Radio Illumination | Lt. Green (parking lights); Pink (dimmer) | +,- | Radio in dash, white 24 pin plug, pins 17, 18 |
| Factory Amp Turn-on | White | + | Tuner above passenger kick, white 24 pin plug, pin 10 |
| Power Antenna | (no wire color listed in service manual) | + | Radio in dash or Tuner above passenger kick, white 2 pin plug, pin 1 |
| Left Front Speaker (+/-) | Brown - Green or Black - White | +,- | Radio in dash or Tuner above passenger kick, white 24 pin plug, pins 1 - 2 |
| Right Front Speaker (+/-) | Yellow - Lt. Green or Red - Green | +,- | Radio in dash or Tuner above passenger kick, white 24 pin plug, pins 3 - 4 |
| Left Rear Speaker (+/-) | Brown - Green or Pink - Lt. Green | +,- | Radio in dash or Tuner above passenger kick, white 24 pin plug, pins 5 - 6 |
| Right Rear Speaker (+/-) | Yellow - Lt. Green or Gray - Blue | +,- | Radio in dash or Tuner above passenger kick, white 24 pin plug, pins 7 - 8 |
| Center Channel (+/-) | Gray - Blue | +,- | Amplifier under passenger seat, green 16 pin plug, pins 4 - 5 |
| Subwoofer (+/-) | Violet - Pink | +,- | Amplifier under passenger seat, black 8 pin plug, pins 3 - 7 |
| Aux. Audio Input Left (+/-) | White - Black or Green - Black | +,- | Radio in dash, white 24 pin plug (B), pins 5 - 17 or Tuner above passenger kick, white 32 pin plug, pins 5 - 21 |
| Aux. Audio Input Right (+/-) | Red - Black | +,- | Radio in dash, white 24 pin plug (B), pins 6 - 17 or Tuner above passenger kick, white 32 pin plug, pins 6 - 21 |





| Item | Wire Color | Polarity | Wire Location |
|-----------------------------|---|----------|---|
| Rearview Camera Video | Black - White | +,- | Connectivity Master Unit- Display, white 28 pin plug, pins 1 - 15 |
| Satellite Radio 12 Volts | (built into tuner above passenger kick) | | |





What Fits

| Item | Size | Depth | Location |
|---------------------|--------------|-------|--------------------|
| Headunit | double DIN | | center of dash |
| Left Front Speaker | 6.5 or 8.86 | | left front door |
| Left Front Tweeter | 1 | | left front pillar |
| Right Front Speaker | 6.5 or 8.86 | | right front door |
| Right Front Tweeter | 1 | | right front pillar |
| Left Rear Speaker | 6.5 or 5.25 | | left rear door |
| Left Rear Tweeter | 3 (surround) | | left rear pillar |
| Right Rear Speaker | 6.5 or 5.25 | | right rear door |
| Right Rear Tweeter | 3 (surround) | | right rear pillar |
| Center Channel | 3 | | top center of dash |





Additional Wiring Notes

| Item | Note |
|------------------------------|---|
| Ignition Interrupt | Do this to enable OEM remote during remote start runtime. |
| Ignition Interrupt 2 | Do this to enable OEM remote during remote start runtime. |
| Left Front Speaker (+/-) | On models with amplifier, the speaker wires are brown - green at the amplifier under passenger seat, black 8 pin plug, pins 2 - 6. |
| Left Rear Speaker (+/-) | On models with amplifier, the speaker wires are brown - green (door); pink - violet (pillar) at the amplifier under passenger seat, green 16 pin plug, pins 3 - 2; 8 - 16. |
| Right Front Speaker (+/-) | On models with amplifier, the speaker wires are yellow - It. green at the amplifier under passenger seat, black 8 pin plug, pins 8 - 4. |
| Right Rear Speaker (+/-) | On models with amplifier, the speaker wires are yellow - It. green (door); pink - violet (pillar) at the amplifier under passenger seat, green 16 pin plug, pins 7 - 6; 8 - 16. |