

# DirectWire

1998 Ford Windstar - North America - Requested by ampire.de

## Wiring Information

Item	Wire Color	Polarity	Wire Location
12 Volts	yellow	+	ignition harness
Starter	white/pink	+	ignition harness
Ignition	red/green	+	ignition harness
Second Ignition	black/green	+	ignition harness
Accessory	gray/yellow	+	ignition harness
Second Accessory	black/pink	+	ignition harness
Power Lock	pink/yellow	-	drivers kick panel
Power Unlock	pink/green	-	drivers kick panel
Factory Alarm Disarm	green/violet	-	either kick panel
Headlight	red/yellow	+	at light switch
Left Front Door Trigger	black/blue	+	kick panel
Hood Pin	black	-	at sw under hood
Tachometer	yellow/black (3.0L); dk. blue/lt. green (3.8L)	ac	coil assembly
Brake Wire	red/lt. green	+	brake pedal switch
Horn Trigger	yellow/green	-	ignition harness
Left Front Window (Up/Down)	wht/yel - yel/blu	A	driver kick panel
Right Front Window (Up/Down)	wht/yel - yel/blu	A	driver kick panel

# DirectWire

1998 Ford Windstar - North America - Requested by ampire.de



## Additional Wiring Notes

Item	Note
Accessory	May be more than one - test to verify which one powers blower and A/C controls.
Power Lock	The keyless module is behind center storage compartment.
Power Unlock	The keyless module is behind center storage compartment.