Wiring Information

| Item | Wire Color | Polarity | Wire Location |
|---------------------------------|---------------------------------------|----------|---|
| 12 Volts | pink/black | + | ignition harness |
| Second 12 Volts | red | + | ignition harness |
| Ground | (chassis ground) | | |
| Starter | yellow | + | ignition harness |
| Ignition | blue | + | ignition harness |
| Accessory | black/orange | + | ignition harness |
| Second Accessory | black/white | + | ignition harness |
| Power Lock | white/green | + | EEM on driver side of transmission tunnel, lt. blue plug, pin D14 |
| Power Unlock | same wire | | |
| Factory Alarm Arm | arms on lock with driver door open | | |
| Factory Alarm Disarm | It. green/orange | + | EEM on driver side of transmission tunnel, lt. blue plug, pin C11 |
| Parking Lights | tan or black/yellow | + | headlight switch or EEM on driver side of transmission tunnel, green plug, pin B |
| Headlight | It. green/red | + | headlight switch |
| Left Front Door Trigger | black/lt. blue | - | EEM on driver side of transmission tunnel, lt. blue plug, pin C15 |
| Right Front Door Trigger | tan/red | - | EEM on driver side of transmission tunnel, lt. blue plug, pin C16 |
| Dome Light | yellow | - | green plug, pin 6, under fuse box |
| Trunk/Hatch Pin | gray/black (GTS only) | - | EEM on driver side of transmission tunnel, lt. blue plug, pin C14 |
| Hood Pin | brown/tan | - | EEM on driver side of transmission tunnel, lt. blue plug, pin C12 |
| Tachometer | gray/lt. blue | ac | PCM on driver fender, under power distribution center, gray plug, pin 31 or behind instrument cluster |
| Speed Sense | white/tan | ac | radio |
| Brake Wire | white | + | brake pedal switch |
| Horn Trigger | black/red | - | EEM on driver side of transmission tunnel, lt. blue plug, pin C3 |
| Wipers | brown/white (L), red/yellow (H) | - | steering column |
| Left Front Window (Up/Down) | It. blue - white | А | switch on center console |
| Right Front Window (Up/Down) | brown - violet | А | switch on center console |
| Radio 12V | pink | + | radio |
| Radio Ground | black | - | radio |
| Radio Ignition | red/white | + | radio |
| Radio Illumination | black/yellow | + | radio |
| Power Antenna | green/red | + | radio |
| Left Front Speaker (+/-) | It. green/violet - It. green/green | +,- | power amplifier on driver side of trunk |
| Right Front Speaker (+/-) | lt. blue/violet - lt. blue/green | +,- | power amplifier on driver side of trunk |
| Left Rear Speaker (+/-) | white/violet - white/green | +,- | power amplifier on driver side of trunk |
| Right Rear Speaker (+/-) | tan/violet - tan/green | +,- | power amplifier on driver side of trunk |

DirectWire 1999 Dodge/Ram Viper RT/10-GTS - North America

Additional Wiring Notes

| Item | Note |
|---------------|---|
| Power Lock | Pulse the wire once will lock the doors and pulsing it again will unlock the doors. To OPEN the driver door pulse positive to pink/white in pin D11, in the lt. blue plug of the EEM. To OPEN the passenger door pulse positive to orange/white in pin D12. |