Wiring Information

Item	Wire Color	Polarity	Wire Location
12 Volts	pink/black	+	ignition harness
Second 12 Volts	red	+	ignition harness
Ground	(chassis ground)		
Starter	yellow	+	ignition harness
Ignition	blue	+	ignition harness
Accessory	black/orange	+	ignition harness
Second Accessory	black/white	+	ignition harness
Power Lock	white/green	+	EEM on driver side of transmission tunnel, lt. blue plug, pin D14
Power Unlock	same wire		
Factory Alarm Arm	arms on lock with driver door open		
Factory Alarm Disarm	It. green/orange	+	EEM on driver side of transmission tunnel, lt. blue plug, pin C11
Parking Lights	tan or black/yellow	+	headlight switch or EEM on driver side of transmission tunnel, green plug, pin B
Headlight	It. green/red	+	headlight switch
Left Front Door Trigger	black/lt. blue	-	EEM on driver side of transmission tunnel, lt. blue plug, pin C15
Right Front Door Trigger	tan/red	-	EEM on driver side of transmission tunnel, lt. blue plug, pin C16
Dome Light	yellow	-	green plug, pin 6, under fuse box
Trunk/Hatch Pin	gray/black (GTS only)	-	EEM on driver side of transmission tunnel, lt. blue plug, pin C14
Hood Pin	brown/tan	-	EEM on driver side of transmission tunnel, lt. blue plug, pin C12
Tachometer	gray/lt. blue	ac	PCM on driver fender, under power distribution center, gray plug, pin 31 or behind instrument cluster
Speed Sense	white/tan	ac	radio
Brake Wire	white	+	brake pedal switch
Horn Trigger	black/red	-	EEM on driver side of transmission tunnel, lt. blue plug, pin C3
Wipers	brown/white (L), red/yellow (H)	-	steering column
Left Front Window (Up/Down)	It. blue - white	А	switch on center console
Right Front Window (Up/Down)	brown - violet	А	switch on center console
Radio 12V	pink	+	radio
Radio Ground	black	-	radio
Radio Ignition	red/white	+	radio
Radio Illumination	black/yellow	+	radio
Power Antenna	green/red	+	radio
Left Front Speaker (+/-)	It. green/violet - It. green/green	+,-	power amplifier on driver side of trunk
Right Front Speaker (+/-)	lt. blue/violet - lt. blue/green	+,-	power amplifier on driver side of trunk
Left Rear Speaker (+/-)	white/violet - white/green	+,-	power amplifier on driver side of trunk
Right Rear Speaker (+/-)	tan/violet - tan/green	+,-	power amplifier on driver side of trunk

DirectWire2002 Dodge/Ram Viper RT/10-GTS - North America

Additional Wiring Notes

Item	Note	
Powe Lock		the wire once will lock the doors and pulsing it again will unlock the doors. To OPEN the driver door pulse positive to /hite in pin D11, in the lt. blue plug of the EEM. To OPEN the passenger door pulse positive to orange/white in pin D12.