

DirectWire

1986 Audi 4000 - North America

Wiring Information

Item	Wire Color	Polarity	Wire Location
12 Volts	red	+	ignition harness
Ground	(chassis ground)		
Starter	red/black	+	ignition harness
Ignition	black	+	ignition harness
Accessory	yellow	+	ignition harness
Power Lock	add actuator		in driver door
Power Unlock	add actuator		in driver door
Parking Lights	gry/red & gry/blk		bottom of fuse box
Headlight	white	+	headlight switch
Left Front Door Trigger	brown/white	-	any pin
Trunk/Hatch Pin	brown/blue	-	light or switch in trunk
Tachometer	green	AC	ignition coil
Brake Wire	red/black	+	brake pedal switch
Horn Trigger	black/yellow	+	at horn or horn relay
Wipers	grn/yel and grn/blk	+	wiper switch
Left Front Window (Up/Down)	blk/red - wht/yel		center console switch
Right Front Window (Up/Down)	blk/grn - white		center console switch
Left Rear Window (Up/Down)	grn/yel - wht/blk		center console switch
Right Rear Window (Up/Down)	yel/blk - yellow		center console switch