

Wiring Information

| Item | Wire Color | Polarity | Wire Location |
|---------------------------|------------------------|----------|--|
| 12 Volts | Green/Red (15A) | + | Ignition Switch, black 7 pin plug, pin 4 |
| Second 12 Volts | Red (30A) | + | BCM in driver kick, black 32 pin plug (D), pin 6 |
| Ground | (chassis ground) | | |
| Starter | Blue/White | + | Ignition Switch, black 7 pin plug, pin 7 |
| Ignition | White/Orange | + | Ignition Switch, black 7 pin plug, pin 1 |
| Accessory | Violet/Green | + | Ignition Switch, black 7 pin plug, pin 6 |
| Keysense | Blue/Gray | + | Ignition Switch, black 7 pin plug, pin 5 |
| CAN Bus High | White/Blue (HS CAN) | Data | OBD-Data Link Connector, black 16 pin plug, pin 6 |
| CAN Bus Low | White (HS CAN) | Data | OBD-Data Link Connector, black 16 pin plug, pin 14 |
| CAN Bus High 2 | Gray/Orange (MS CAN) | Data | OBD-Data Link Connector, black 16 pin plug, pin 3 |
| CAN Bus Low 2 | Violet/Orange (MS CAN) | Data | OBD-Data Link Connector, black 16 pin plug, pin 11 |
| OBD 12 Volts | Violet/Red (15A) | + | OBD-Data Link Connector, black 16 pin plug, pin 16 |
| OBD Ground | Black/Gray | - | OBD-Data Link Connector, black 16 pin plug, pin 4 |
| RX DATA | Violet/Gray | Data | PATS Transceiver on ignition switch, black 4 pin plug, pin 4 |
| TX DATA | Yellow/Orange | Data | PATS Transceiver on ignition switch, black 4 pin plug, pin 3 |
| Power Lock | blue/green | - | BCM in driver kick, black 26 pin plug (C), pin 6 |
| Power Unlock | yellow/violet | - | BCM in driver kick, black 26 pin plug (C), pin 8 |
| Lock Motor | gray/brown | reverse | driver kick, door harness |
| Driver Unlock Motor | blue/green | reverse | driver kick, door harness |
| Passenger Unlock Motor | violet/gray | reverse | driver kick, harness to rear |



| Item | Wire Color | Polarity | Wire Location |
|-----------------------------|--|----------|--|
| Factory Alarm Arm | violet/green and yellow/green (driver door keypad) | both - | driver kick, door harness |
| Factory Alarm Disarm | (transponder and ignition) | | |
| Parking Lights | yellow/blue | + | BCM in driver kick, gray 10 pin plug (E), pin 6 |
| Parking Lights - | (HS CAN) | | |
| Hazards | brown/yellow | - | BCM in driver kick, black 52 pin plug (B), pin 32 |
| Turn Signal (Left) | blue/green (F); gray/orange (R) | + | BCM in driver kick, brown 26 pin plug (F), pin 8; black 26 pin plug (C), pin 14 |
| Turn Signal (Right) | yellow/violet (F); green/orange (R) | + | BCM in driver kick, brown 26 pin plug (F), pin 7; black 26 pin plug (C), pin 15 |
| Headlight | brown/blue (L); blue/green (R) | + | BCM in driver kick, gray 10 pin plug (E), pins 2, 1 |
| AutoLights | (HS CAN) | | |
| Reverse Light | blue/white | + | BCM in driver kick, black 32 pin plug (D), pin 13 |
| Left Front Door Trigger | green/violet | - N.C. | BCM in driver kick, black 26 pin plug (C), pin 9or- - driver kick, door harness |
| Right Front Door Trigger | white | - N.C. | BCM in driver kick, black 26 pin plug (C), pin 5 |
| Left Rear Door Trigger | green | - N.C. | BCM in driver kick, black 26 pin plug (C), pin 20 |
| Right Rear Door Trigger | yellow | - N.C. | BCM in driver kick, black 26 pin plug (C), pin 21 |
| Dome Light | gray/violet | + | BCM in driver kick, gray 12 pin plug (A), pin 1 |
| Trunk/Hatch Pin | gray/orange | - N.C. | BCM in driver kick, black 26 pin plug (C), pin 19 |
| Hood Pin | blue/orange | - N.C. | BCM in driver kick, brown 26 pin plug (F), pin 2 |
| Power Liftgate | gray/yellow | - | power liftgate switch, black 6 pin plug, pin 6 |
| Trunk/Hatch Release | brown (rear handle switch) | - | BCM in driver kick, black 26 pin plug (C), pin 23 |
| Trunk Release Motor | green/brown | reverse | BCM in driver kick, black 32 pin plug (D), pin 29 |
| Tachometer | green/blue, gray/yellow, violet/gray, yellow/orange, brown, or green/white | ac | any fuel injector, black 2 pin plug, pin 1 |
| Fuel Pump | yellow/violet | - | BCM in driver kick, brown 26 pin plug (F), pin 6 |



| Item | Wire Color | Polarity | Wire Location |
|--------------------------------|---|-----------|---|
| Rear Defroster | white/orange | - latched | junction connector near steering column, black 30 pin plug, pin 5 |
| Mirror Defroster | (same as rear defroster) | | |
| Left Front Heated Seat | (MS CAN) | | |
| Right Front Heated Seat | (MS CAN) | | |
| Speed Sense | brown/green | ac | PCM on passenger firewall, black 50 pin plug, pin 25 (3.5L/3.7L); TCM next to battery, 60 pin plug, pin 51 (2.0L) |
| Brake Wire | violet/white | + | BCM in driver kick, black 52 pin plug (B), pin 28 or brake switch |
| Parking Brake | white/violet | - | BCM in driver kick, black 26 pin plug (C), pin 7or- - parking brake switch |
| Horn Trigger | violet/green | - | BCM in driver kick, black 52 pin plug (B), pin 33 or horn switch |
| Wipers | (LIN Bus) | | |
| Left Front Window (Up/Down) | (motor is part of module) | | |
| Right Front Window (Up/Down) | brown/yellow - green/orange | A | driver kick, door harness |
| Left Rear Window (Up/Down) | blue/orange - yellow | А | driver kick, door harness |
| Right Rear Window (Up/Down) | gray/violet - brown/green | A | driver kick, door harness |
| Sun Roof (Open/Close) | violet/brown - yellow/orange (function with ignition on only) | - | sunroof switch, 8 pin plug, pins 4 - 3 |
| Memory Seat 1 | violet/white | - | memory set switch, 8 pin plug, pin 2 |
| Memory Seat 2 | yellow | - | memory set switch, 8 pin plug, pin 6 |
| Radio 12V | gray/red | + | radio, 24 pin plug, pin 1 |
| Radio Ground | black/blue | - | radio, 24 pin plug, pin 13 |
| Radio Ignition | (Infotainment CAN) | | |
| Radio Illumination | (Infotainment CAN) | | |
| Factory Amp Turn-on | violet/red | + | radio, 26 pin plug, pin 18 |
| Power Antenna | black | + | radio, 24 pin plug, pin 2 |
| Left Front Speaker (+/-) | white - white/brown or yellow/violet - brown/blue | +,- | radio, 24 pin plug, pins 22 - 10 |
| Right Front Speaker (+/-) | white/violet - white/orange or violet - yellow | +,- | radio, 24 pin plug, pins 23 - 11 |



| Item | Wire Color | Polarity | Wire Location |
|---------------------------------|--|----------|--|
| Left Rear Speaker (+/-) | white/green - brown/yellow | +,- | radio, 24 pin plug, pins 21 - 9 |
| Right Rear Speaker (+/-) | brown/white - brown/blue | +,- | radio, 24 pin plug, pins 24 - 12 |
| Center Channel (+/-) | green - gray/yellow | +,- | amplifier in right rear quarter panel, 16 pin plug, pins 1 - 9 |
| Subwoofer (+/-) | violet - yellow (1); green/violet - gray (2) | +,- | amplifier in right rear quarter panel, 16 pin plug, pins 1 - 9; 2 - 10 |
| Aux. Audio Input Left (+/-) | blue - yellow/green (without SYNC) | +,- | radio, 24 pin plug, pins 17 - 6 |
| Aux. Audio Input Right (+/-) | blue/green - yellow/green (without SYNC) | +,- | radio, 24 pin plug, pins 18 - 6 |
| Rearview Camera Video | white/green - brown/violet | +,- | SYNC Module above radio, 54 pin plug, pins 14 - 15 |
| RSE Video (+/-) | blue/white - green/blue (aux. video) | +,- | SYNC Module above radio, 54 pin plug, pins 34 - 35 |
| RSE Audio Left (+/-) | blue - gray/orange (SYNC audio) | +,- | radio, 26 pin plug, pins 12 - 25 |
| RSE Audio Right (+/-) | violet/green - brown/white (SYNC audio) | +,- | radio, 26 pin plug, pins 13 - 26 |
| Satellite Radio 12 Volts | (built into radio) | | |



What Fits

| Item | Size | Depth | Location |
|---------------------|-----------|-------|--------------------------|
| Headunit | irregular | | center of dash |
| Left Front Speaker | 6 x 8 | 4 | left front door |
| Left Front Tweeter | | | left front pillar |
| Right Front Speaker | 6 x 8 | 4 | right front door |
| Right Front Tweeter | | | right front pillar |
| Left Rear Speaker | 6 x 8 | 3.8 | left rear door |
| Left Rear Tweeter | | | left rear pillar |
| Right Rear Speaker | 6 x 8 | 3.8 | right rear door |
| Right Rear Tweeter | | | right rear pillar |
| Center Channel | | | top center of dash |
| Subwoofer | 8 | | right rear quarter panel |



Additional Wiring Notes

| Item | Note |
|------------------------------|---|
| Left Front Speaker (+/-) | On models with amplifier, the speaker wires are white - white/brown at the amplifier in right rear quarter panel, 16 pin plug, pins 2 - 10. The tweeter wires are green/orange - gray/orange at the amplifier, 16 pin plug, pins 3 - 11. |
| Left Rear Speaker (+/-) | On models with amplifier, the speaker wires are white/green - brown/yellow at the amplifier in right rear quarter panel, 16 pin plug, pins 4 - 12. The tweeter wires are green/brown - gray/brown at the amplifier, 16 pin plug, pins 5 - 13. |
| Right Front Speaker (+/-) | On models with amplifier, the speaker wires are white/purple - white/orange at the amplifier in right rear quarter panel, 16 pin plug, pins 6 - 14. The tweeter wires are purple/orange - yellow/orange at the amplifier, 16 pin plug, pins 7 - 15. |
| Right Rear Speaker (+/-) | On models with amplifier, the speaker wires are brown/white - brown/blue at the amplifier in right rear quarter panel, 16 pin plug, pins 8 - 16. The tweeter wires are green/brown - gray/brown at the amplifier, 16 pin plug, pins 5 - 13. |