

Wiring Information

Item	Wire Color	Polarity	Wire Location
12 Volts	Red (60A)	+	Passenger Dash Fuse Box, green 41 pin plug, pin 22
Ground	(chassis ground)		
Starter	Blue/White	+	Passenger Dash Fuse Box, rear, green 32 pin plug, pin 18
Ignition	Yellow (for ignition sense only)	+	Passenger Dash Fuse Box, green 41 pin plug, pin 10
Accessory	Green/White (for accessory sense only)	+	Passenger Dash Fuse Box, blue 46 pin plug, pin 30
PTS 1	Brown/Violet	- 250 Ohms	Passenger Dash Fuse Box, bottom, gray 28 pin plug, pin 18
PTS 2	Yellow/Orange	- 250 Ohms	Passenger Dash Fuse Box, bottom, gray 28 pin plug, pin 17
CAN Bus High	Green/Orange (HS CAN)	Data	Passenger Dash Fuse Box, rear, green 32 pin plug, pin 10
CAN Bus Low	Gray/Blue (HS CAN)	Data	Passenger Dash Fuse Box, rear, green 32 pin plug, pin 9
CAN Bus High 2	Yellow/Orange (MS CAN)	Data	Passenger Dash Fuse Box, bottom, gray 28 pin plug, pin 5
CAN Bus Low 2	Yellow/Violet (MS CAN)	Data	Passenger Dash Fuse Box, bottom, gray 28 pin plug, pin 4
IMMO Data	Violet/White (LIN Bus)	Data	Passenger Dash Fuse Box, bottom, gray 28 pin plug, pin 10
Security Light	White/Violet	-	Passenger Dash Fuse Box, botton, gray 32 pin plug, pin 7
Power Lock	Gray/Brown	-	Passenger Dash Fuse Box, bottom, gray 28 pin plug, pin 9
Power Unlock	Brown/Green	-	Passenger Dash Fuse Box, bottom, gray 28 pin plug, pin 8
Lock Motor	Black	Reverse	Driver Door Module, black 22 pin plug, pin 10
Driver Unlock Motor	Black	Reverse	Driver Door Module, black 22 pin plug, pin 7



Item	Wire Color	Polarity	Wire Location
Passenger Unlock Motor	Black	Reverse	Passenger Door Module, gray 22 pin plug, pin 7
Factory Alarm Arm	Black (driver door key lock)	-	Driver Door Module, black 22 pin plug, pin 21
Factory Alarm Disarm	Black (driver door key unlock)	Double -	Driver Door Module, black 24 pin plug, pin 22
Disarm No Unlock	(proximity key and push button)		
Parking Lights	Green/Orange (LF); Brown/Yellow (RF); Green/Orange (LR); Brown/Yellow (RR)	+	Passenger Dash Fuse Box, green 41 pin plug, pins 35, 33; brown 46 pin plug, pins 2, 38
Parking Lights -	(LIN Bus)		
Hazards	Yellow/Green	-	Passenger Dash Fuse Box, bottom, gray 28 pin plug, pin 19
Turn Signal (Left)	Blue/Green (F); Gray/Orange (R)	+	Passenger Dash Fuse box, green 41 pin plug, pin 32; brown 46 pin plug, pin 9
Turn Signal (Right)	Yellow/Violet (F); Green/Orange (R)	+	Passenger Dash Fuse Box, green 41 pin plug, pin 37; brown 46 pin plug, pin 10
Headlight	Brown/Blue (L); Blue/Gray (R)	+	Passenger Dash Fuse Box, green 41 pin plug, pins 38, 29
AutoLights	(LIN Bus)		
Reverse Light	Green/White	+	Passenger Dash Fuse Box, brown 46 pin plug, pin 40
Left Front Door Trigger	Green/Violet	-	Passenger Dash Fuse Box, rear, brown 32 pin plug, pin 11
Right Front Door Trigger	White	-	Passenger Dash Fuse Box, rear, brown 32 pin plug, pin 12
Left Rear Door Trigger	Green	-	Passenger Dash Fuse box, rear, brown 32 pin plug, pin 25
Right Rear Door Trigger	Yellow	-	Passenger Dash Fuse Box, rear, brown 32 pin plug, pin 26
Dome Light	Gray/Violet	+	Passenger Dash Fuse Box, blue 46 pin plug, pin 2
Trunk/Hatch Pin	Violet/Orange	-	Passenger Dash Fuse Box, rear, brown 32 pin plug, pin 23



Item	Wire Color	Polarity	Wire Location
Hood Pin	Black	-	Passenger Dash Fuse box, rear, green 32 pin plug, pin 5
Power Liftgate	Brown	-	Passenger Dash Fuse Box, rear, gray 32 pin plug, pin 8
Trunk/Hatch Release	Brown (rear handle switch)	-	Passenger Dash Fuse Box, bottom, gray 32 pin plug, pin 15
Trunk Release Motor	White/Orange	Reverse	Passenger Dash Fuse Box, brown 46 pin plug, pin 6
Fuel Door Release	Black (unlock only)	Reverse	Passenger Dash Fuse box, brown 46 pin plug, pin 32
Tachometer	Yellow/Blue, Blue/Orange, Green/Violet, or Blue	ac	Fuel Injector Harness, engine driver side rear, black 16 pin plug, pin 9, 12, 13, or 14
Fuel Pump	Violet/Green	-	Passenger Dash Fuse Box, rear, green 32 pin plug, pin 13
Rear Defroster	Brown/Blue	+ Latched	Passenger Dash Fuse Box, brown 46 pin plug, pin 23
Mirror Defroster	(MS CAN)		
Wiper Deicer	Gray/Orange	- Latched	Passenger Dash Fuse Box, rear, green 32 pin plug, pin 29
Left Front Heated Seat	(LIN Bus)		
Right Front Heated Seat	(LIN Bus)		
Speed Sense	(wheel speed sensor)		
Brake Wire	Green/Blue	+	Passenger Dash Fuse Box, rear, brown 32 pin plug, pin 6
Parking Brake	(electric parking brake)		
Horn Trigger	Black	-	Passenger Dash Fuse Box, rear, green 32 pin plug, pin 28
Wipers	White	-	Passenger Dash Fuse Box, rear, green 32 pin plug, pin 25
Left Front Window (Up/Down)	(not recommended because of factory auto up/down)		
Right Front Window (Up/Down)	(not recommended because of factory auto up/down)		



Item	Wire Color	Polarity	Wire Location
Left Rear Window (Up/Down)	(not recommended because of factory auto up/down)		
Right Rear Window (Up/Down)	(not recommended because of factory auto up/down)		
Sun Roof (Open/Close)	Gray/Brown - Green/White (sunroof blind) (function with ignition on only)	-	Overhead Console, gray 20 pin plug, pins 16 - 17
Memory Seat 1	Black	- Resistor	Memory Switch, green 6 pin plug, pin 3
Memory Seat 2	(same as memory seat 1)	- Resistor	
Memory Seat 3	(same as memory seat 1)	- Resistor	
Radio 12V	Yellow	+	Radio, black 16 pin plug, pin 13 or gray 14 pin plug, pin 1
Radio Ground	Black/Yellow	-	Radio, black 16 pin plug, pin 11 or gray 14 pin plug, pin 8
Radio Ignition	(MS CAN or MOST)		
Power Antenna	Yellow/Orange	+	Radio, blue 12 pin plug, pin 4 or gray 14 pin plug, pin 2
Left Front Speaker (+/-)	Green/Orange - Gray/Orange	+,-	Radio, black 16 pin plug, pins 3 - 7
Right Front Speaker (+/-)	Violet/Orange - Yellow/Orange	+,-	Radio, black 16 pin plug, pins 2 - 6
Left Rear Speaker (+/-)	White/Green - Brown/Yellow	+,-	Radio, black 16 pin plug, pins 4 - 8
Right Rear Speaker (+/-)	Brown/White - Brown/Blue	+,-	Radio, black 16 pin plug, pins 1 - 5
Subwoofer (+/-)	Green/Violet - Gray (1); Violet - Yellow (2)	+,-	Amplifier under driver seat, brown 8 pin plug, pins 1 - 5; black 16 pin plug, pins 8 - 16 or gray 16 pin plug, pins 6 - 14; 8 - 16
Aux. Audio Input Left (+/-)	Blue - White/Green or Blue - Black	+,-	Radio, green 12 pin plug, pins 10 - 4 or gray 14 pin plug, pins 5 - 7
Aux. Audio Input Right (+/-)	Blue/Green - White/Green or Green - Black	+,-	Radio, green 12 pin plug, pins 3 - 4 or gray 14 pin plug, pins 6 - 7



What Fits

Item Size Depth Location



Additional Wiring Notes

Item	Note
Left Front Speaker (+/-)	On models with amplifier, the speaker wires are white - white/brown (woofer); green/blue - gray/blue (midrange/tweeter) at the amplifier under driver seat, black 16 pin plug, pins 3 - 11; 2 - 10 or gray 16 pin plug, pins 2 - 10; 1 - 9.
Left Rear Speaker (+/-)	On models with amplifier, the speaker wires are white/green - brown/yellow at the amplifier under driver seat, black 16 pin plug, pins 4 - 12 or gray 16 pin plug, pins 5 - 13.
Right Front Speaker (+/-)	On models with amplifier, the speaker wires are white/violet - white/orange (woofer); violet/gray - yellow/gray (midrange/tweeter) at the amplifier under driver seat, black 16 pin plug, pins 6 - 14; 5 - 13 or gray 16 pin plug, pins 4 - 12; 3 - 11.
Right Rear Speaker (+/-)	On models with amplifier, the speaker wires are brown/white - brown/blue at the amplifier under driver seat, black 16 pin plug, pins 7 - 15 or gray 16 pin plug, pins 7 - 15.