



545T Nite-Lite®

OWNER'S GUIDE

The Nite-Lite automated vehicle lighting system offers unprecedented convenience and safety.

Nite-Lite® Mode: The system automatically turns on your headlights and parking lights during hours of darkness and turns them off in daylight. The 545T can distinguish night from day with the Nite-Lite photocell. The photocell requires 5 seconds of darkness to turn on, and 30 seconds of continuous light to turn off, eliminating any possibility of "flutter" from the system.

When the ignition is on, the system will continuously monitor the photocell. The parking lights and headlights will be energized automatically any time the photocell does not receive enough light.

NOTE: With some vehicles, the factory high/low-beam dimmer switch will not work on the high beams while Nite-Lite is activated.

Turn-off delay (adjustable): This allows between 1 and 150 seconds to elapse before the system deactivates the vehicle's lights. The delay period governs how long the lights will stay on if:

- the security system is armed or disarmed
- the security system's auxiliary channel is pressed (if installed)

The turn-off delay is provided so the headlights can light your path as you leave or approach your vehicle. Simply have your dealer set the delay to the required time.

NOTE: When the 545T is activating the lights while the key is out of the ignition switch, the parking lights will flash to indicate that **Nite-Lite** is operating the vehicle's lights.

Legi-Lite® Mode (optional): This function automatically turns on the headlights and parking lights as soon as the windshield wipers are activated. This ensures you are never in violation of state or local ordinances requiring headlights be turned on whenever wipers are used. The lights will automatically turn off 30 seconds after the wipers are turned off.

Safe-Lite® Mode (optional): This feature makes it possible to have the headlights and parking lights on at all times while operating the vehicle. This feature is useful for foggy or cloudy days when the photocell may not sense enough darkness to activate. In addition, Safe-Lite Mode can prevent battery drain by automatically turning off the lights when the ignition is turned off. An optional toggle switch is required to install this feature.

NOTE: If the factory light switch is used to turn on the headlights, Safe-Lite cannot turn them off.

Remote Control Interface (optional): The Nite-Lite system is designed to interface with most security systems so you can activate the 545T by remote control. The Nite-Lite system can be activated when the security system is armed or disarmed, or with an auxiliary channel. Activating the auxiliary channel after arming or disarming the security system will cancel Nite-Lite operation. If Nite-Lite is operating with the ignition on, triggering the auxiliary channel will turn the lights off for 30 seconds.

NOTE: The auxiliary channel will not cancel Legi-Lite operation.