

Wiring Information

Item	Wire Color	Polarity	Wire Location
12 Volts	BLACK		1 WAY CONNECTOR AT REAR OF FUSE BOX DRIVERS SIDE
Starter	RED-ORANGE (2)		AT 68 WAY BLACK REAR OF FUSE BOX
Ignition	ORANGE		AT 68 WAY REAR OF FUSE BOX
Power Lock	YELLOW-ORANGE	NEG	AT GREEN 16 WAY AT FRONT OF FUSE BOX PIN 10
Power Unlock	YELLOW-WHITE	NEG	AT GREEN 16 WAY AT FRONT OF FUSE BOX PIN 9
Turn Signal (Left)	WHITE-BLACK		AT GREY 16 WAY AT FRONT OF FUSE BOX PIN 15
Turn Signal (Right)	BROWN-ORANGE		AT GREY 16 WAY AT FRONT OF FUSE BOX PIN 16
Left Front Door Trigger	GREY	NEG	AT GREY 16 WAY FRONT OF FUSE BOX PIN 13
Trunk/Hatch Pin	GREEN	NEG	AT 16 WAY GREEN PIN 6
Hood Pin	GREEN-BLACK	NEG	(IF FITTED) GREEN 16 WAY AT FRONT OF FUSE BOX PIN 15