

Standard 12V automotive relay diagram

- 85 - (-) orange connect to orange "gwa"
- 86 - (+) yellow connect to 87A
- 87 - NO not used
- 87A - NC connect to black PIN 22 CAS
- 30 - COM connect to black starter side

