

Wiring Information

| Item | Wire Color | Polarity | Wire Location |
|------------------|---------------------|----------|---|
| 12 Volts | white or gray (40A) | + | BCM in passenger kick, black 3 pin plug, pin 1 |
| Second 12 Volts | red (80A) | + | dash fuse box, rear, white 1 pin plug, pin 1 |
| Ground | (chassis ground) | | |
| Starter | It. blue | - | BCM in passenger kick, gray 40 pin plug, pin 21 |
| Ignition | red | + | BCM in passenger kick, black 40 pin plug, pin 11 |
| Second Ignition | yellow | - | BCM in passenger kick, gray 40 pin plug, pin 16 |
| Accessory | orange | + | BCM in passenger kick, black 40 pin plug, pin 31 |
| Second Accessory | orange | + | BCM in passenger kick, black 40 pin plug, pin 24 |
| PTS 1 | brown | - | Push-Button Ignition Switch, brown 8 pin plug, pin 4OR BCM in passenger kick, black 40 pin plug, pin 18 |
| Keysense | red | + | Key Slot, white 12 pin plug, pin 11OR BCM in passenger kick, green 40 pin plug, pin 10 |
| CAN Bus High | blue | data | OBD-data link connector, white 16 pin plug, pin 6 |
| CAN Bus Low | pink | data | OBD-data link connector, white 16 pin plug, pin 14 |
| CAN Bus High 2 | blue | data | BCM in passenger kick, black 40 pin plug, pin 20 |
| CAN Bus Low 2 | pink | data | BCM in passenger kick, black 40 pin plug, pin 19 |
| IMMO Data | blue | data | Key Slot, white 12 pin plug, pin 3OR BCM in passenger kick, black 40 pin plug, pin 10 |
| IMMO Clock | gray | data | Key Slot, white 12 pin plug, pin 2OR BCM in passenger kick, black 40 pin plug, pin 9 |
| Security Light | green | - | BCM in passenger kick, green 40 pin plug, pin 30 |
| Power Lock | pink | - | BCM in passenger kick, green 40 pin plug, pin 17 |
| Power Unlock | brown | - | BCM in passenger kick, green 40 pin plug, pin 20 |



| ltem | Wire Color | Polarity | Wire Location |
|-----------------------------|--------------------------------|----------|---|
| Lock Motor | violet | 5 wire | BCM in passenger kick, white 16 pin plug, pin 5 |
| Driver Unlock Motor | green | 5 wire | BCM in passenger kick, white 16 pin plug, pin 6 |
| Passenger Unlock Motor | green | 5 wire | BCM in passenger kick, white 16 pin plug, pin 2 |
| Factory Alarm Arm | arms on lock with door open | | |
| Factory Alarm Disarm | see disarm no unlock | | |
| Disarm No Unlock | proximity key and push-button | | |
| Parking Lights | red | + | dash fuse box, white 10 pin plug, pin 8 or driver kick, harness to rear |
| Hazards | green | - | BCM in passenger kick, black 40 pin plug, pin 39 |
| Turn Signal (Left) | orange (F); violet (R) | + | BCM in passenger kick, wht 16 pin plug, pin 15; wht 12 pin plg, pin 6 |
| Turn Signal (Right) | white (F); It. blue (R) | + | BCM in passenger kick, wht 16 pin plug, pin 14; wht 12 pin plg, pin 1 |
| Headlight | pink (L), red (R) | + | headlights or underhood fuse box, white 8 pin plug, pins 2 and 1 |
| Reverse Light | orange | + | radio, white 32 pin plug, pin 21 |
| Left Front Door Trigger | gray | - | BCM in passenger kick, green 40 pin plug, pin 39 |
| Right Front Door Trigger | lt. green | - | BCM in passenger kick, green 40 pin plug, pin 13 |
| Dome Light | violet | - | BCM in passenger kick, white 16 pin plug, pin 16 |
| Trunk/Hatch Pin | red | - | BCM in passenger kick, gray 40 pin plug, pin 19 |
| Hood Pin | lt. green | - | hood switch or underhood fuse box, white 16 pin plug, pin 14 |
| Trunk/Hatch Release | green | - | BCM in passenger kick, gray 40 pin plug, pin 36 |
| Trunk Release Motor | green | 5 wire | BCM in passenger kick, white 12 pin plug, pin 4 |
| Fuel Door Release | unlocks along with driver door | | |
| Tachometer | It. blue | ac | Power Steering Ctrl Unit behind glove box, wht 12 pin plug, pin 10 |
| Fuel Pump | yellow | + | passenger kick, harness to rear |



| ltem | Wire Color | Polarity | Wire Location |
|---------------------------------|---|-----------|--|
| Rear Defroster | green | - latched | BCM in passenger kick, green 40 pin plug, pin 40 |
| Mirror Defroster | same as rear defroster | | |
| Left Front Heated Seat | blue/red | 5 wire | driver heated seat switch, brown 6 pin plug, pin 5 |
| Right Front Heated Seat | blue/red | 5 wire | passenger heated seat switch, brown 6 pin plug, pin 5 |
| Speed Sense | violet | 8-Pulse | radio, white 32 pin plug, pin 22 |
| Brake Wire | pink | + | BCM in passenger kick, green 40 pin plug, pin 7 |
| Parking Brake | violet or red | - | parking brake switch or radio, white 32 pin plug, pin 5 |
| Horn Trigger | white | - | horn switch, gray 8 pin plug, pin 8 |
| Wipers | violet (L), blue (H) | + | wiper motor or underhood fuse box, wht 36 pin plug, pins 2 and 3 |
| Left Front Window (Up/Down) | motor part of module | | |
| Right Front Window (Up/Down) | motor part of module | | |
| Radio 12V | yellow | + | radio, white 20 pin plug, pin 19 |
| Radio Ground | black | - | radio, white 20 pin plug, pin 20 |
| Radio Ignition | violet | + | radio, white 20 pin plug, pin 7 |
| Radio Illumination | red | + | radio, white 32 pin plug, pin 19 |
| Factory Amp Turn-on | violet | + | radio, white 20 pin plug, pin 1 |
| Power Antenna | | + | radio, 3 pin plug, pin 1 |
| Left Front Speaker (+/-) | red - green or blue - pink | +,- | radio, white 20 pin plug, pins 2 - 3 |
| Right Front Speaker (+/-) | orange/blue - white/blue or red - green | +,- | radio, white 20 pin plug, pins 11 - 12 |
| Left Rear Speaker (+/-) | black - white | +,- | radio, white 20 pin plug, pins 4 - 5 |
| Right Rear Speaker (+/-) | blue/green - blue/yellow | +,- | radio, white 20 pin plug, pins 13 - 14 |
| Center Channel (+/-) | violet - white (BOSE audio) | +,- | amplifier under driver seat, brown 23 pin plug, pins 13 - 14 |



| ltem | Wire Color | Polarity | Wire Location |
|---------------------------------|---|----------|---|
| Subwoofer (+/-) | pink - It. blue (preamp); white (turn-on) (BOSE) | +,- | amplifier under driver seat, brown 14 pin plug, pins 20 - 8; 11 |
| Aux. Audio Input Left (+/-) | white - black | +,- | radio, white 28 pin plug, pins 4 - 19 |
| Aux. Audio Input Right (+/-) | red - black | +,- | radio, white 28 pin plug, pins 18 - 19 |
| RSE Video (+/-) | red - white (front display video) | +,- | radio, white 32 pin plug, pins 8 - 7 |
| Satellite Radio 12 Volts | (built into radio) | | |



What Fits

| Item | Size | Depth | Location |
|-----------------------|------------------------------|----------|--|
| Headunit | irregular | | center of dash |
| Left Front Speaker | 6.5 | 4 | left front door |
| Left Front Tweeter | 1 (tweeter); 3.25 (midrange) | 1; 2.85 | left front door |
| Right Front Speaker | 6.5 | 4 | right front door |
| Right Front Tweeter | 1 (tweeter); 3.25 (midrange) | 1; 2.85 | right front door |
| Left Rear Speaker | 6.5 or 3.25 | 3.5 or 3 | between rear seats or left rear deck |
| Right Rear Speaker | 6.5 or 3.25 | 3.5 or 3 | between rear seats or right rear deck |
| Center Channel | 3.25 | 3 | top center of dash |
| Subwoofer | 9 (x2) | 3.5 | between rear seats |
| Satellite Radio Tuner | (built into radio) | | |



Additional Wiring Notes

| ltem | Note |
|-------------------------------------|---|
| Aux. Audio Input Right (+/-) | The auxiliary video input wires are green - red at the radio, white 40 pin plug, pins 6 - 26. |
| Left Front Speaker (+/-) | The speaker wires are red - green at the amplifier under driver seat, white 10 pin plug, pins 8 - 7 (base audio) or brown 14 pin plug, pins 10 - 11 (BOSE audio). The tweeter wires are orange - gray at the amplifier, brown 14 pin plug, pins 4 - 13 (BOSE audio). |
| Left Rear Speaker (+/-) | The speaker wires are blue - white at the amplifier under driver seat, white 10 pin plug, pins 4 - 3 (base audio) or purple - It. green in the brown 23 pin plug, pins 12 - 2 (BOSE audio). |
| Right Front Speaker (+/-) | The speaker wires are yellow - It. green at the amplifier under driver seat, white 10 pin plug, pins 8 - 7 (base audio) or brown 14 pin plug, pins 6 - 7 (BOSE audio). The tweeter wires are It. blue - brown at the amplifier, brown 14 pin plug, pins 8 - 9 (BOSE audio). |
| Right Rear Speaker (+/-) | The speaker wires are It. green - orange at the amplifier under driver seat, white 10 pin plug, pins 4 - 3 (base audio) or brown 23 pin plug, pins 4 - 3 (BOSE audio). |