

Wiring Information

Item	Wire Color	Polarity	Wire Location
12 Volts	red/white (30A)	+	Front BCM under driver dash, 4 pin plug (A), pin 1
Ground	(chassis ground)		
Starter	red/yellow	-	electronic ignition switch, 16 pin plug, pin 10
Second Starter	black (for starter kill only)	+	Front BCM under driver dash, blue 42 pin plug (C), pin 38
Ignition	blue/green	-	electronic ignition switch, 16 pin plug, pin 9
Second Ignition	white or black (for ignition sense only)	+	Front BCM under driver dash, 42 pin plug (D), pin 14
Accessory	black/red and black/blue	-	electronic ignition switch, 16 pin plug, pins 6, 12
Keysense	blue/yellow and violet	-	electronic ignition switch, 16 pin plug, pins 5, 11
Key Release	yellow/red	+	electronic ignition switch, 16 pin plug, pin 14
Data Bus	(ELECTRONIC IGNITION SWITCH INTERFACE NEEDED FOR REMOTE START)		
CAN Bus High	orange/green (comfort CAN)	data	driver kick or Front BCM under driver dash, blue 42 pin plug (C), pin 42
CAN Bus Low	orange/brown (comfort CAN)	data	driver kick or Front BCM under driver dash, blue 42 pin plug (C), pin 34
IMMO Data	gray/brown (electronic ignition LIN)	data	electronic ignition switch, 16 pin plug, pin 1
Power Lock	(use factory alarm arm)		
Power Unlock	(use factory alarm disarm)		
Lock Motor	violet/green	5 wire	Driver Door Control Unit, 20 pin plug, pin 13
Driver Unlock Motor	blue/green or blue	5 wire	Driver Door Control Unit, 20 pin plug, pin 11
Passenger Unlock Motor	blue/green or blue	5 wire	Passenger Door Control Unit, 20 pin plug, pin 11
Factory Alarm Arm	blue/yellow (driver door key lock)	-	Driver Door Control Unit, 20 pin plug, pin 1
Factory Alarm Disarm	(same as factory alarm arm)	- 250 ohms	
Disarm No Unlock	(see factory alarm disarm)		



Item	Wire Color	Polarity	Wire Location
Parking Lights (+)	black/blue (LF), gray/red (RF); gray/yellow (LR), red/white (RR)	+	Front BCM under driver dash, 42 pin plug (D), pins 26, 4; Rear BCM in right rear quarter panel, 42 pin plug (B), pins 4, 26
Parking Lights (-)	(LIN bus)		
Hazards	violet	-	Front BCM under driver dash, blue 42 pin plug (C), pin 16
Turn Signal (Left)	black/white (F); green/white or black/white (R)	+	Front BCM under driver dash, blue 42 pin plug (C), pin 24; 42 pin plug (D), pin 5
Turn Signal (Right)	black/green (F); black/green (R)	+	Front BCM under driver dash, blue 42 pin plug (C), pin 25; 42 pin plug (D), pin 25
Headlight	yellow		headlight switch or Front BCM under driver dash, 42 pin plug (D), pin 18
AutoLights	(LIN bus)		
Reverse Light	blue/black	+	Rear BCM in right rear quarter panel, 42 pin plug (B), pin 2
Left Front Door Trigger	red/blue	-	Driver Door Control Unit, 20 pin plug, pin 5
Right Front Door Trigger	red/blue	-	Passenger Door Control Unit, 20 pin plug, pin 5
Left Rear Door Trigger	red/blue	-	Left Rear Door Control Unit, 20 pin plug, pin 5
Right Rear Door Trigger	red/blue	-	Right Rear Door Control Unit, 20 pin plug, pin 5
Dome Light	(LIN bus)		
Trunk/Hatch Pin	gray/blue	-	Rear BCM in right rear quarter panel, 42 pin plug (B), pin 39
Hood Pin	yellow/black	-	Front BCM under driver dash, 42 pin plug (D), pin 38
Trunk/Hatch Release	yellow/blue (rear handle switch)	-	Rear BCM in right rear quarter panel, 42 pin plug (A), pin 17
Trunk Release Motor	white/red or brown/yellow	5 wire	Rear BCM in right rear quarter panel, 12 pin plug (C), pin 4
Fuel Door Release	yellow/white or red/brown (fuel door lock/unlock)	5 wire	Front BCM under driver dash, 12 pin plug (B), pins 5, 3



Item	Wire Color	Polarity	Wire Location
Tachometer	brown/stripe or blue/stripe	ac	any fuel injector, 2 pin plug, pin 2
Clutch Pedal	yellow/violet		clutch switch, 5 pin plug, pin 4
Fuel Pump	red/yellow	+	driver kick, harness to rear
Rear Defroster	gray/white	+ latched	Rear BCM in right rear quarter panel, 42 pin plug (A), pin 36
Mirror Defroster	(comfort CAN)		
Wiper Deicer	violet/green (L); violet/yellow (R)	- latched	Front BCM under driver dash, blue 42 pin plug (C), pins 9, 10
Left Front Heated Seat	blue/yellow	5 wire	A/C Control Unit, 3 pin plug, pin 2
Right Front Heated Seat	blue/white	5 wire	A/C Control Unit, 3 pin plug, pin 3
Speed Sense	(wheel speed sensor)		
Brake Wire	black/red	+	passenger kick or Rear BCM in right rear quarter panel, 42 pin plug (B), pin 27
Parking Brake	(electric parking brake)		
Horn Trigger	white/violet	+	Front BCM under driver dash, blue 42 pin plug (C), pin 36
Wipers	(LIN bus)		
Left Front Window (Up/Down)	(use factory alarm arm/disarm)		
Right Front Window (Up/Down)	(see left front window)		
Left Rear Window (Up/Down)	(see left front window)		
Right Rear Window (Up/Down)	(see left front window)		
Sun Roof (Open/Close)	(LIN bus)		
Memory Seat 1	blue	- resistor	Driver Door Control Unit, 32 pin plug, pin 19
Memory Seat 2	(same as memory seat 1)	- resistor	
Memory Seat 3	(same as memory seat 1)	- resistor	
Radio 12V	red/yellow	+	radio, 16 pin plug, pin 15
Radio Ground	brown	-	radio, 16 pin plug, pin 12
Radio Ignition	(MMI CAN)		
Factory Amp Turn-on	black/red (without Bose); (MOST bus, with Bose)	+	radio, 12 pin plug (C), pin 4



Item	Wire Color	Polarity	Wire Location
Power Antenna	white	+	radio, 16 pin plug, pin 14
Left Front Speaker (+/-)	white - white/black	+,-	radio, 8 pin plug, pins 3 - 7
Right Front Speaker (+/-)	gray - gray/black	+,-	radio, 8 pin plug, pins 2 - 6
Left Rear Speaker (+/-)	green - green/black	+,-	radio, 8 pin plug, pins 4 - 8
Right Rear Speaker (+/-)	violet - violet/black	+,-	radio, 8 pin plug, pins 1 - 5
Center Channel (+/-)	blue - blue/black	+,-	amplifier in right rear quarter panel, 20 pin plug, pins 4 - 14 or 32 pin plug, pins 8 - 20
Subwoofer (+/-)	yellow/red - yellow/brown (preamp); red/white (turn-on)	+,-; +	amplifier in right rear quarter panel, 32 pin plug, pins 10 - 22; pin 23
Aux. Audio Input Left (+/-)	blue - brown	+,-	radio, 12 pin plug (D), pins 2 - 8
Aux. Audio Input Right (+/-)	green - brown	+,-	radio, 12 pin plug (D), pins 7 - 8
RSE Video (+/-)	black - black (television tuner)	+,-	radio, 12 pin plug (C), pins 10 - 11
RSE Audio Left (+/-)	(MOST bus) (television tuner)		
RSE Audio Right (+/-)	(MOST bus) (television tuner)		
Satellite Radio 12 Volts	(built into radio)		



What Fits

Item	Size	Depth	Location
Headunit	irregular		center of dash
Left Front Speaker			left front door
Left Front Tweeter			left front door; left front dash
Right Front Speaker			right front door
Right Front Tweeter			right front door; right front dash
Left Rear Speaker			left rear door
Left Rear Tweeter			left rear door; left rear pillar
Right Rear Speaker			right rear door
Right Rear Tweeter			right rear door; right rear pillar
Center Channel		_	top center of dash
Satellite Radio Tuner	(built into radio)		



Additional Wiring Notes

Item	Note
Left Front Speaker (+/-)	The woofer wires are white/red - white/brown at the amplifier in right rear quarter panel, 20 pin plug, pins 5 - 15 (without Bose) or 32 pin plug, pins 3 - 15 (with Bose). The midrange/tweeter wires are white - white/black at the amplifier, 20 pin plug, pins 12 - 2 (without Bose) or 32 pin plug, pins 7 - 19 (with Bose).
Left Rear Speaker (+/-)	The woofer/tweeter wires are green - green/black at the amplifier in right rear quarter panel, 20 pin plug, pins 6 - 16 (without Bose) or 32 pin plug, pins 12 - 11 (with Bose).
Right Front Speaker (+/-)	The woofer wires are gray/red - gray/brown at the amplifier in right rear quarter panel, 20 pin plug, pins 10 - 20 (without Bose) or 32 pin plug, pins 5 - 17 (with Bose). The midrange/tweeter wires are gray - gray/black at the amplifier, 20 pin plug, pins 13 - 3 (without Bose) or 32 pin plug, pins 18 - 6 (with Bose).
Right Rear Speaker (+/-)	The woofer/tweeter wires are purple - purple/black at the amplifier in right rear quarter panel, 20 pin plug, pins 17 - 7 (without Bose) or 32 pin plug, pins 13 - 14 (with Bose). The surround speakers are paralleled, and the wires are yellow - blue/yellow at the amplifier, 32 pin plug, pins 21 - 9 (with Bose).