



http://www.directechs.com

Wiring Information

Item	Wire Color	Polarity	Wire Location
12 Volts	Red (60A)	+	Passenger Dash Fuse Box, green 41 pin plug, pin 22
Ground	(chassis ground)		
Starter Kill	Brown/Blue	+	Starter Relay in Battery Junction Box, plug (A), pin 4
Starter	Blue/White	+	Passenger Dash Fuse Box, rear, green 32 pin plug, pin 18
Ignition Sense	Yellow	+	Passenger Dash Fuse Box, green 41 pin plug, pin 10
Accessory	Green/White (for accessory sense only)	+	Passenger Dash Fuse Box, blue 46 pin plug, pin 30
PTS 1	Brown/Violet	- 250 Ohms	Passenger Dash Fuse Box, bottom, gray 28 pin plug, pin 18
PTS 2	Yellow/Orange	- 250 Ohms	Passenger Dash Fuse Box, bottom, gray 28 pin plug, pin 17
CAN Bus High	Green/Orange (HS CAN)	Data	Passenger Dash Fuse Box, rear, green 32 pin plug, pin 10
CAN Bus Low	Gray/Blue (HS CAN)	Data	Passenger Dash Fuse Box, rear, green 32 pin plug, pin 9
CAN Bus High 2	Yellow/Orange (MS CAN)	Data	Passenger Dash Fuse Box, bottom, gray 28 pin plug, pin 5
CAN Bus Low 2	Yellow/Violet (MS CAN)	Data	Passenger Dash Fuse Box, bottom, gray 28 pin plug, pin 4
CAN Bus High 3	Green/Orange (HS CAN)	Data	OBD-Data Link Connector, 16 pin plug, pin 6
CAN Bus Low 3	Gray/Blue (HS CAN)	Data	OBD-Data Link Connector, 16 pin plug, pin 14
OBD 12 Volts	Yellow/Red (5A)	+	OBD-Data Link Connector, 16 pin plug, pin 16
OBD Ground	Black/Violet	-	OBD-Data Link Connector, 16 pin plug, pin 4

LAND--ROVER



ltem	Wire Color	Polarity	Wire Location
IMMO Data	Violet/White (LIN)	Data	Passenger Dash Fuse Box, bottom, gray 28 pin plug, pin 10
Security Light	White/Violet	-	Passenger Dash Fuse Box, botton, gray 32 pin plug, pin 7
Power Lock	Gray/Brown	-	Passenger Dash Fuse Box, bottom, gray 28 pin plug, pin 9
Power Unlock	Brown/Green	-	Passenger Dash Fuse Box, bottom, gray 28 pin plug, pin 8
Lock Motor	Black	Reverse	Driver Door Module, black 22 pin plug, pin 10
Driver Unlock Motor	Black	Reverse	Driver Door Module, black 22 pin plug, pin 7
Passenger Unlock Motor	Black	Reverse	Passenger Door Module, gray 22 pin plug, pin 7
Factory Alarm Arm	Black (key lock)	-	Driver Door Module, black 22 pin plug, pin 21
Factory Alarm Disarm	Black (key unlock)	Double -	Driver Door Module, black 24 pin plug, pin 22
Disarm No Unlock	(proximity key and push button)		
Parking Lights	Green/Orange (LF); Brown/Yellow (RF)	+	Passenger Dash Fuse Box, green 41 pin plug, pin 35 (LF); pin 33 (RF)
Parking Lights 2	Green/Orange (LR); Brown/Yellow (RR)	+	Passenger Dash Fuse Box, brown 46 pin plug, pin 2 (LR); pin 38 (RR)
Parking Lights -	(LIN)		
Hazards	Yellow/Green	-	Passenger Dash Fuse Box, bottom, gray 28 pin plug, pin 19
Turn Signal (Left)	Blue/Green (LF); Gray/Orange (LR)	+	Passenger Dash Fuse box, green 41 pin plug, pin 32 (LF); brown 46 pin plug, pin 9 (LR)
Turn Signal (Right)	Yellow/Violet (RF); Green/Orange (RR)	+	Passenger Dash Fuse Box, green 41 pin plug, pin 37 (RF); brown 46 pin plug, pin 10 (RR)
Headlight	Brown/Blue (L); Blue/Gray (R)	+	Passenger Dash Fuse Box, green 41 pin plug, pin 38 (L); pin 29 (R)
AutoLights	(LIN)		
Reverse Light	Green/White	+	Passenger Dash Fuse Box, brown 46 pin plug, pin 40





Item	Wire Color	Polarity	Wire Location
Left Front Door Trigger	Green/Violet	-	Passenger Dash Fuse Box, rear, brown 32 pin plug, pin 11
Right Front Door Trigger	White	-	Passenger Dash Fuse Box, rear, brown 32 pin plug, pin 12
Left Rear Door Trigger	Green	-	Passenger Dash Fuse box, rear, brown 32 pin plug, pin 25
Right Rear Door Trigger	Yellow	-	Passenger Dash Fuse Box, rear, brown 32 pin plug, pin 26
Dome Light	Gray/Violet	+	Passenger Dash Fuse Box, blue 46 pin plug, pin 2
Trunk/Hatch Pin	Violet/Orange	-	Passenger Dash Fuse Box, rear, brown 32 pin plug, pin 23
Hood Pin	Black	-	Passenger Dash Fuse box, rear, green 32 pin plug, pin 5
Power Liftgate	Brown	-	Passenger Dash Fuse Box, rear, gray 32 pin plug, pin 8
Trunk/Hatch Release	Brown (rear handle switch)	-	Passenger Dash Fuse Box, bottom, gray 32 pin plug, pin 15
Trunk Release Motor	White/Orange	Reverse	Passenger Dash Fuse Box, brown 46 pin plug, pin 6
Fuel Door Release	Black - Black (lock/unlock)	Reverse	Passenger Dash Fuse box, brown 46 pin plug, pins 34, 32
Tachometer	Brown/Blue	AC	Camshaft Position Sensor, engine driver side top rear, 3 pin plug, pin 3
Fuel Pump	Violet/Green	-	Passenger Dash Fuse Box, rear, green 32 pin plug, pin 13
Rear Defroster	Brown/Blue	+ Latched	Passenger Dash Fuse Box, brown 46 pin plug, pin 23
Mirror Defroster	(MS CAN)		
Wiper Deicer	Gray/Orange	- Latched	Passenger Dash Fuse Box, rear, green 32 pin plug, pin 29
Left Front Heated Seat	(LIN)		
Right Front Heated Seat	(LIN)		

LAND--ROVER



Item	Wire Color	Polarity	Wire Location
Heated Steering Wheel	(inside steering wheel)		
Speed Sense	(wheel speed sensor)		
Brake Wire	Green/Blue	+	Passenger Dash Fuse Box, rear, brown 32 pin plug, pin 6
Parking Brake	(electric parking brake)		
Horn Trigger	Black	-	Passenger Dash Fuse Box, rear, green 32 pin plug, pin 28
Wipers	White	-	Passenger Dash Fuse Box, rear, green 32 pin plug, pin 25
All Windows Up- Down	(not recommended because of factory auto up/down)		
Sun Roof (Open/Close)	Gray/Brown - Green/White (sunroof blind) (function with ignition on only)	-	Overhead Console, gray 20 pin plug, pins 16 - 17
Memory Seat 1	Black	MUX	Memory Switch, green 6 pin plug, pin 3
Memory Seat 2	(same as memory seat 1)		
Memory Seat 3	(same as memory seat 1)		
Radio 12V	Yellow	+	Radio, black 16 pin plug, pin 13 or gray 14 pin plug, pin 1
Radio Ground	Black/Yellow	-	Radio, black 16 pin plug, pin 11 or gray 14 pin plug, pin 8
Radio Ignition	(MS CAN or MOST)		
Power Antenna	Yellow/Orange	+	Radio, blue 12 pin plug, pin 4 or gray 14 pin plug, pin 2
Left Front Speaker (+/-)	Green/Orange - Gray/Orange	+,-	Radio, black 16 pin plug, pins 3 - 7
Right Front Speaker (+/-)	Violet/Orange - Yellow/Orange	+,-	Radio, black 16 pin plug, pins 2 - 6
Left Rear Speaker (+/-)	White/Green - Brown/Yellow	+,-	Radio, black 16 pin plug, pins 4 - 8
Right Rear Speaker (+/-)	Brown/White - Brown/Blue	+,-	Radio, black 16 pin plug, pins 1 - 5
Left Front Speaker - With Amp	White - White/Brown	+,-	Amplifier under driver seat, black 16 pin plug, pins 3 - 11 or gray 16 pin plug, pins 2 - 10
Right Front Speaker - With Amp	White/Violet - White/Orange	+,-	Amplifier under driver seat, black 16 pin plug, pins 6 - 14 or gray 16 pin plug, pins 4 - 12





Item	Wire Color	Polarity	Wire Location
Left Front Tweeter - With Amp	Green/Blue - Gray/Blue (midrange/tweeter)	+,-	Amplifier under driver seat, black 16 pin plug, pins 2 - 10 or gray 16 pin plug, pins 1 - 9
Right Front Tweeter - With Amp	Violet/Gray - Yellow/Gray (midrange/tweeter)	+,-	Amplifier under driver seat, black 16 pin plug, pins 5 - 13 or gray 16 pin plug, pins 3 - 11
Left Rear Speaker - With Amp	White/Green - Brown/Yellow	+,-	Amplifier under driver seat, black 16 pin plug, pins 4 - 12 or gray 16 pin plug, pins 5 - 13
Right Rear Speaker - With Amp	Brown/White - Brown/Blue	+,-	Amplifier under driver seat, black 16 pin plug, pins 7 - 15 or gray 16 pin plug, pins 7 - 15
Subwoofer - With Amp	Green/Violet - Gray (coil 1); Violet - Yellow (coil 2)	+,-	Amplifier under driver seat, brown 8 pin plug, pins 1 - 5; black 16 pin plug, pins 8 - 16 or gray 16 pin plug, pins 6 - 14; 8 - 16
Aux. Audio Input Left (+/-)	Blue - White/Green or Blue - Black	+,-	Radio, green 12 pin plug, pins 10 - 4 or gray 14 pin plug, pins 5 - 7
Aux. Audio Input Right (+/-)	Blue/Green - White/Green or Green - Black	+,-	Radio, green 12 pin plug, pins 3 - 4 or gray 14 pin plug, pins 6 - 7





http://www.directechs.com

What Fits

	Item	Size	Depth	Location
--	------	------	-------	----------